

GUANG YI COMPANY LIMITED
PHYSICAL STOCK OFFER

Price Negotiation Date: Tuesday, 11 December, 2018

Supplier & Grade:				
Below is the important model list:				
Brand	Model	Total - QTY	Grade	Line
Apple	iPhone X (64GB) SIM Free Total	438	N. New Handset	9
Apple	iPhone X (64GB) iCloud lock (namely, ID lock) Total	71	A Handset	44
Apple	iPhone X (256GB) SIM Free Total	49	B Handset (Power Up, Good LCD)	46
Apple	iPhone X (64GB) SIM Free Total	54	B Handset (Power Up, Good LCD)	58
Apple	iPhone X (256GB) (SIM Free, Problematic) Total	37	B Handset (Power Up, Good LCD)	74
Apple	iPhone X (256GB) iCloud lock (namely, ID lock) Total	32	B Handset (Power Up, Good LCD)	76
Apple	iPhone X (64GB) iCloud lock (namely, ID lock) Total	35	B Handset (Power Up, Good LCD)	78
Apple	iPhone X (256GB) SIM Free Total	177	B Handset (Power Up, Bad LCD)	80
Apple	iPhone X (64GB) SIM Free Total	116	B Handset (Power Up, Bad LCD)	89
Apple	iPhone X (256GB) iCloud lock (namely, ID lock) Total	82	B Handset (Power Up, Bad LCD)	105
Apple	iPhone X (64GB) iCloud lock (namely, ID lock) Total	94	B Handset (Power Up, Bad LCD)	107
Apple	iPhone 8 Plus (64GB) SIM Free Total	258	N. New Handset	109
Apple	iPhone 8 Plus (64GB) SIM Free Total	26	A Handset	115
Apple	iPhone 8 Plus (64GB) (SIM Free, Problematic) Total	24	A Handset	123
Apple	iPhone 8 Plus (64GB) iCloud lock (namely, ID lock) Total	23	A Handset	125
Apple	iPhone 8 Plus (64GB) (SIM Free, Problematic) Total	30	B Handset (Power Up, Good LCD)	127
Apple	iPhone 8 Plus (64GB) iCloud lock (namely, ID lock) Total	26	B Handset (Power Up, Good LCD)	129
Apple	iPhone 8 Plus (256GB) iCloud lock (namely, ID lock) Total	33	B Handset (Power Up, Bad LCD)	131
Apple	iPhone 8 Plus (64GB) iCloud lock (namely, ID lock) Total	91	B Handset (Power Up, Bad LCD)	133
Apple	iPhone 8 (256GB) SIM Free Total	87	A Handset	142
Apple	iPhone 8 (64GB) SIM Free Total	91	A Handset	159
Apple	iPhone 8 (64GB) (SIM Free, Problematic) Total	41	B Handset (Power Up, Good LCD)	192
Apple	iPhone 8 (256GB) SIM Free Total	24	B Handset (Power Up, Bad LCD)	194
Apple	iPhone 8 (64GB) SIM Free Total	128	B Handset (Power Up, Bad LCD)	202
Apple	iPhone 8 (64GB) (SIM Free, Problematic) Total	22	B Handset (Power Up, Bad LCD)	209
Apple	iPhone 8 (64GB) iCloud lock (namely, ID lock) Total	42	B Handset (Power Up, Bad LCD)	211
Apple	iPhone 7 Plus (128GB) SIM Free Total	1122	A Handset	213
Apple	iPhone 7 Plus (256GB) SIM Free Total	121	A Handset	252
Apple	iPhone 7 Plus (32GB) (SIM Free, Bad Fingerprint Sensor) Total	141	A Handset	269
Apple	iPhone 7 Plus (32GB) SIM Free Total	433	B Handset (Power Up, Good LCD)	282
Apple	iPhone 7 (128GB) SIM Free Total	811	A Handset	375
Apple	iPhone 7 (256GB) SIM Free Total	136	A Handset	412
Apple	iPhone 7 (32GB) SIM Free Total	163	A Handset	440
Apple	iPhone 7 (32GB) (SIM Free, Problematic) Total	384	B Handset (Power Up, Good LCD)	500
Apple	iPhone 7 (32GB) iCloud lock (namely, ID lock) Total	112	B Handset (Power Up, Good LCD)	504
Apple	iPhone 7 (128GB) SIM Free Total	500	B Handset (Power Up, Bad LCD)	506
Apple	iPhone 7 (32GB) SIM Free Total	558	B Handset (Power Up, Bad LCD)	520
Apple	iPhone 7 (128GB) (SIM Free, Problematic) Total	324	B Handset (Power Up, Bad LCD)	539
Apple	iPhone 7 (32GB) (SIM Free, Problematic) Total	356	B Handset (Power Up, Bad LCD)	541
Apple	iPhone 7 (32GB) (Problematic) Total	120	B Handset (Power Up, Bad LCD)	543
Apple	iPhone 6s Plus (32GB) SIM Free Total	105	A Handset	569
Apple	iPhone 6s Plus (64GB) SIM Free Total	131	A Handset	577
Apple	iPhone 5s (16GB) (SIM Free, Problematic) Total	459	B Handset (Power Up, Good LCD)	747
Apple	iPhone 5s (32GB) iCloud lock (namely, ID lock) Total	536	B Handset (Power Up, Good LCD)	753
Apple	iPhone 5s (16GB) iCloud lock (namely, ID lock) Total	2980	B Handset (Power Up, Bad LCD)	761
Apple	iPhone 5s (32GB) iCloud lock (namely, ID lock) Total	470	B Handset (Power Up, Bad LCD)	763
Apple	iPhone 4s (16GB) iCloud lock (namely, ID lock) Total	3578	B Handset (Power Up, Good LCD)	789
Apple	iPhone 4s (16GB) iCloud lock (namely, ID lock) Total	1115	B Handset (Power Up, Bad LCD)	799
Apple	iPhone 4s (8GB) iCloud lock (namely, ID lock) Total	243	B Handset (Power Up, Bad LCD)	805
Apple	iPhone 4 (16GB) iCloud lock (namely, ID lock) Total	1774	B Handset (Power Up, Good LCD)	829
Apple	iPhone 4 (32GB) iCloud lock (namely, ID lock) Total	285	B Handset (Power Up, Good LCD)	831
Apple	iPhone 4 (8GB) iCloud lock (namely, ID lock) Total	2012	B Handset (Power Up, Good LCD)	833
Apple	iPhone 4 (16GB) iCloud lock (namely, ID lock) Total	232	B Handset (Power Up, Bad LCD)	847
Apple	iPhone 4 (8GB) iCloud lock (namely, ID lock) Total	212	B Handset (Power Up, Bad LCD)	851
Apple	iPhone 4 (8GB) Total	218	B Handset (Power Up, Bad LCD)	855

Below is the detailed list:				
Brand	Model	Total - QTY	Grade	Line
Nokia	225	11	New Handset (No Keypad)	3
Nokia	205 (SIM Free)	21	New Handset	4
Nokia	435 (SIM Free)	20	New Handset	5
Nokia	503 (SIM Free)	2	New Handset	6
Nokia	530 (SIM Free)	3	New Handset	7
Nokia	630 (SIM Free)	4	New Handset	8
Apple	iPhone X (64GB) SIM Free Total	438	N. New Handset	9
Apple	iPhone X (64GB) SIM Free (White)	74	(USA Version S) N. New Handset (Non-Active) (RW-A)	10
Apple	iPhone X (64GB) SIM Free (Black)	181	(USA Version S) N. New Handset (Non-Active) (RW-A)	11
Apple	iPhone X (64GB) SIM Free (White)	13	Around 10 Months Warranty-(USA Version S) N. New Handset (RW-B)	16
Apple	iPhone X (64GB) SIM Free (Black)	63	Around 10 Months Warranty-(USA Version S) N. New Handset (RW-B)	17
Apple	iPhone X (64GB) SIM Free (White)	2	On Warranty-(USA Version S) N. New Handset (RW-B)	20
Apple	iPhone X (64GB) SIM Free (Black)	83	On Warranty-(USA Version S) N. New Handset (RW-B)	21
Apple	iPhone X (64GB) SIM Free (White)	15	(USA Version S) N. New Handset (RW-B)	24
Apple	iPhone X (64GB) SIM Free (Black)	1	(USA Version A) N. New Handset	25
Apple	iPhone X (64GB) SIM Free (Black)	3	(USA Version A) N. New Handset (A+)	26
Apple	iPhone X (64GB) SIM Free (Black)	3	(USA Version A) N. New Handset (Grade B)	27
Apple	iPhone X (64GB) iCloud lock (namely, ID lock) Total	71	A Handset	44
Apple	iPhone X (64GB) iCloud lock (namely, ID lock)	71	Part 2 A Handset	45
Apple	iPhone X (256GB) SIM Free Total	49	B Handset (Power Up, Good LCD)	46
Apple	iPhone X (256GB) SIM Free (White)	1	B Handset (Power Up, Good LCD) (Broken Back Glass)	47
Apple	iPhone X (256GB) SIM Free (White)	2	(USA Version A) B Handset (Power Up, Good LCD) (Good Back Glass)	48
Apple	iPhone X (256GB) SIM Free (Black)	9	(USA Version A) B Handset (Power Up, Good LCD) (Good Back Glass)	49
Apple	iPhone X (256GB) SIM Free (White)	11	(USA Version A) B Handset (Power Up, Good LCD) (Broken Back Glass)	50
Apple	iPhone X (256GB) SIM Free (Black)	12	(USA Version A) B Handset (Power Up, Good LCD) (Broken Back Glass)	51
Apple	iPhone X (256GB) SIM Free (White)	2	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	52
Apple	iPhone X (256GB) SIM Free (Black)	4	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	53
Apple	iPhone X (256GB) SIM Free (White)	1	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Broken Back Glass)	54
Apple	iPhone X (256GB) SIM Free (White)	3	(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	55
Apple	iPhone X (256GB) SIM Free (Black)	3	(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	56
Apple	iPhone X (256GB) SIM Free (Black)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Broken Back Glass)	57
Apple	iPhone X (64GB) SIM Free Total	54	B Handset (Power Up, Good LCD)	58
Apple	iPhone X (64GB) SIM Free (White)	1	B Handset (Power Up, Good LCD) (Good Back Glass)	59
Apple	iPhone X (64GB) SIM Free (Black)	1	B Handset (Power Up, Good LCD) (Broken Back Glass)	60
Apple	iPhone X (64GB) SIM Free (White)	1	(USA Version A) B Handset (Power Up, Good LCD)	61
Apple	iPhone X (64GB) SIM Free (White)	9	(USA Version A) B Handset (Power Up, Good LCD) (Good Back Glass)	62
Apple	iPhone X (64GB) SIM Free (Black)	8	(USA Version A) B Handset (Power Up, Good LCD) (Good Back Glass)	63
Apple	iPhone X (64GB) SIM Free (White)	7	(USA Version A) B Handset (Power Up, Good LCD) (Broken Back Glass)	64
Apple	iPhone X (64GB) SIM Free (Black)	13	(USA Version A) B Handset (Power Up, Good LCD) (Broken Back Glass)	65
Apple	iPhone X (64GB) SIM Free (Black)	2	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	66
Apple	iPhone X (64GB) SIM Free (White)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	67
Apple	iPhone X (64GB) SIM Free (Black)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	68
Apple	iPhone X (64GB) SIM Free (White)	1	(USA Version S) B Handset (Power Up, Good LCD)	69
Apple	iPhone X (64GB) SIM Free (White)	1	(USA Version S) B Handset (Power Up, Good LCD) (Good Back Glass) (RW)	70
Apple	iPhone X (64GB) SIM Free (Black)	1	(USA Version S) B Handset (Power Up, Good LCD) (Good Back Glass) (RW)	71
Apple	iPhone X (64GB) SIM Free (White)	2	(USA Version S) B Handset (Power Up, Good LCD) (Broken Back Glass)	72
Apple	iPhone X (64GB) SIM Free (Black)	5	(USA Version S) B Handset (Power Up, Good LCD) (Broken Back Glass)	73
Apple	iPhone X (256GB) (SIM Free, Problematic) Total	37	B Handset (Power Up, Good LCD)	74
Apple	iPhone X (256GB) (SIM Free, Problematic)	37	Part 2 B Handset (Power Up, Good LCD)	75
Apple	iPhone X (256GB) iCloud lock (namely, ID lock) Total	32	B Handset (Power Up, Good LCD)	76
Apple	iPhone X (256GB) iCloud lock (namely, ID lock)	32	Part 2 B Handset (Power Up, Good LCD)	77
Apple	iPhone X (64GB) iCloud lock (namely, ID lock) Total	35	B Handset (Power Up, Good LCD)	78
Apple	iPhone X (64GB) iCloud lock (namely, ID lock)	35	Part 2 B Handset (Power Up, Good LCD)	79
Apple	iPhone X (256GB) SIM Free Total	177	B Handset (Power Up, Bad LCD)	80
Apple	iPhone X (256GB) SIM Free (White)	2	B Handset (Power Up, Bad LCD)	81
Apple	iPhone X (256GB) SIM Free (Black)	3	B Handset (Power Up, Bad LCD)	82
Apple	iPhone X (256GB) SIM Free (White)	16	(USA Version A) B Handset (Power Up, Bad LCD)	83

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone X (256GB) SIM Free (Black)	30	(USA Version A) B Handset (Power Up, Bad LCD)	84
Apple	iPhone X (256GB) SIM Free (White)	3	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	85
Apple	iPhone X (256GB) SIM Free (Black)	4	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	86
Apple	iPhone X (256GB) SIM Free (White)	48	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	87
Apple	iPhone X (256GB) SIM Free (Black)	71	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	88
Apple	iPhone X (64GB) SIM Free Total	116	B Handset (Power Up, Bad LCD)	89
Apple	iPhone X (64GB) SIM Free (White)	1	B Handset (Power Up, Bad LCD) (Around 10 Months Warranty)	90
Apple	iPhone X (64GB) SIM Free (Black)	2	B Handset (Power Up, Bad LCD) (On Warranty)	91
Apple	iPhone X (64GB) SIM Free (Black)	26	(USA Version A) B Handset (Power Up, Bad LCD)	93
Apple	iPhone X (64GB) SIM Free (Black)	1	Around 10 Months Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	94
Apple	iPhone X (64GB) SIM Free (White)	6	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	95
Apple	iPhone X (64GB) SIM Free (Black)	3	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	96
Apple	iPhone X (64GB) SIM Free (White)	24	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	97
Apple	iPhone X (64GB) SIM Free (Black)	49	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	98
Apple	iPhone X (64GB) SIM Free (White)	4	(USA Version S) B Handset (Power Up, Bad LCD)	99
Apple	iPhone X (256GB) iCloud lock (namely, ID lock) Total	82	B Handset (Power Up, Bad LCD)	105
Apple	iPhone X (256GB) iCloud lock (namely, ID lock)	82	Part 2 B Handset (Power Up, Bad LCD)	106
Apple	iPhone X (64GB) iCloud lock (namely, ID lock) Total	94	B Handset (Power Up, Bad LCD)	107
Apple	iPhone X (64GB) iCloud lock (namely, ID lock)	94	Part 2 B Handset (Power Up, Bad LCD)	108
Apple	iPhone 8 Plus (64GB) SIM Free Total	258	N. New Handset	109
Apple	iPhone 8 Plus (64GB) SIM Free (Red)	1	N. New Handset	110
Apple	iPhone 8 Plus (64GB) SIM Free (White)	32	Around 10 Months Warranty-(USA Version S) N. New Handset (RW-A)	111
Apple	iPhone 8 Plus (64GB) SIM Free (Gold)	120	Around 10 Months Warranty-(USA Version S) N. New Handset (RW-A)	112
Apple	iPhone 8 Plus (64GB) SIM Free (Black)	66	Around 10 Months Warranty-(USA Version S) N. New Handset (RW-A)	113
Apple	iPhone 8 Plus (64GB) SIM Free (Red)	39	Around 10 Months Warranty-(USA Version S) N. New Handset (RW-A)	114
Apple	iPhone 8 Plus (64GB) SIM Free Total	26	A Handset	115
Apple	iPhone 8 Plus (64GB) SIM Free (Gold)	1	A Handset (Broken Back Glass)	116
Apple	iPhone 8 Plus (64GB) SIM Free (Gold)	8	(USA Version A) A Handset (Broken Back Glass)	118
Apple	iPhone 8 Plus (64GB) SIM Free (Black)	8	(USA Version A) A Handset (Broken Back Glass)	119
Apple	iPhone 8 Plus (64GB) SIM Free (Red)	6	(USA Version A) A Handset (Broken Back Glass)	120
Apple	iPhone 8 Plus (64GB) SIM Free (Gold)	2	(USA Version A) A Handset (Broken Back Glass) (Grade B)	121
Apple	iPhone 8 Plus (64GB) SIM Free (Black)	1	(USA Version A) A Handset (Broken Back Glass) (Grade B)	122
Apple	iPhone 8 Plus (64GB) (SIM Free, Problematic) Total	24	A Handset	123
Apple	iPhone 8 Plus (64GB) (SIM Free, Problematic)	24	Part 2 A Handset	124
Apple	iPhone 8 Plus (64GB) iCloud lock (namely, ID lock) Total	23	A Handset	125
Apple	iPhone 8 Plus (64GB) iCloud lock (namely, ID lock)	23	Part 2 A Handset	126
Apple	iPhone 8 Plus (64GB) (SIM Free, Problematic) Total	30	B Handset (Power Up, Good LCD)	127
Apple	iPhone 8 Plus (64GB) (SIM Free, Problematic)	30	Part 2 B Handset (Power Up, Good LCD)	128
Apple	iPhone 8 Plus (64GB) iCloud lock (namely, ID lock) Total	26	B Handset (Power Up, Good LCD)	129
Apple	iPhone 8 Plus (64GB) iCloud lock (namely, ID lock)	26	Part 2 B Handset (Power Up, Good LCD)	130
Apple	iPhone 8 Plus (256GB) iCloud lock (namely, ID lock) Total	33	B Handset (Power Up, Bad LCD)	131
Apple	iPhone 8 Plus (256GB) iCloud lock (namely, ID lock)	33	Part 2 B Handset (Power Up, Bad LCD)	132
Apple	iPhone 8 Plus (64GB) iCloud lock (namely, ID lock) Total	91	B Handset (Power Up, Bad LCD)	133
Apple	iPhone 8 Plus (64GB) iCloud lock (namely, ID lock)	91	Part 2 B Handset (Power Up, Bad LCD)	134
Apple	iPhone 8 (256GB) SIM Free Total	87	A Handset	142
Apple	iPhone 8 (256GB) SIM Free (Black)	1	(USA Version A) A Handset (Good Back Glass)	143
Apple	iPhone 8 (256GB) SIM Free (Gold)	1	(USA Version A) A Handset (Good Back Glass) (Grade B)	144
Apple	iPhone 8 (256GB) SIM Free (Red)	1	(USA Version A) A Handset (Good Back Glass) (Grade B)	145
Apple	iPhone 8 (256GB) SIM Free (Black)	1	(USA Version A) A Handset (Broken Back Glass)	146
Apple	iPhone 8 (256GB) SIM Free (Gold)	1	(USA Version A) A Handset (Broken Back Glass)	147
Apple	iPhone 8 (256GB) SIM Free (White)	1	(USA Version A) A Handset (Broken Back Glass)	148
Apple	iPhone 8 (256GB) SIM Free (Black)	1	On Warranty-(USA Version A-Green Label) A Handset (Broken Back Glass)	149
Apple	iPhone 8 (256GB) SIM Free (Black)	2	Around 10 Months Warranty-(USA Version A-Green Label) A Handset	150
Apple	iPhone 8 (256GB) SIM Free (Gold)	2	Around 10 Months Warranty-(USA Version A-Green Label) A Handset	151
Apple	iPhone 8 (256GB) SIM Free (Black)	9	On Warranty-(USA Version A-Green Label) A Handset	152
Apple	iPhone 8 (256GB) SIM Free (Gold)	4	On Warranty-(USA Version A-Green Label) A Handset	153
Apple	iPhone 8 (256GB) SIM Free (Red)	1	On Warranty-(USA Version A-Green Label) A Handset	154
Apple	iPhone 8 (256GB) SIM Free (Black)	41	(USA Version A-Green Label) A Handset	155
Apple	iPhone 8 (256GB) SIM Free (Gold)	19	(USA Version A-Green Label) A Handset	156
Apple	iPhone 8 (256GB) SIM Free (White)	1	(USA Version A-Green Label) A Handset (Good Back Glass)	157
Apple	iPhone 8 (256GB) SIM Free (Black)	1	(USA Version A-Green Label) A Handset (Broken Back Glass)	158
Apple	iPhone 8 (64GB) SIM Free Total	91	A Handset	159
Apple	iPhone 8 (64GB) SIM Free (Gold)	1	A Handset (Good Back Glass)	160
Apple	iPhone 8 (64GB) SIM Free (Black)	2	A Handset (Good Back Glass)	161
Apple	iPhone 8 (64GB) SIM Free (Black)	1	(USA Version A) A Handset (Good Back Glass)	162
Apple	iPhone 8 (64GB) SIM Free (White)	1	(USA Version A) A Handset (Good Back Glass)	163
Apple	iPhone 8 (64GB) SIM Free (Black)	3	(USA Version A) A Handset (Good Back Glass) (Grade B)	164
Apple	iPhone 8 (64GB) SIM Free (White)	1	(USA Version A) A Handset (Good Back Glass) (Grade B)	165
Apple	iPhone 8 (64GB) SIM Free (Gold)	5	(USA Version A) A Handset (Broken Back Glass)	166
Apple	iPhone 8 (64GB) SIM Free (Black)	4	(USA Version A) A Handset (Broken Back Glass)	167
Apple	iPhone 8 (64GB) SIM Free (Gold)	2	(USA Version A) A Handset (Broken Back Glass) (Grade B)	168
Apple	iPhone 8 (64GB) SIM Free (Black)	2	(USA Version A) A Handset (Broken Back Glass) (Grade B)	169
Apple	iPhone 8 (64GB) SIM Free (White)	1	(USA Version A) A Handset (Broken Back Glass) (Grade B)	170
Apple	iPhone 8 (64GB) SIM Free (Red)	1	Around 10 Months Warranty-(USA Version A-Green Label) A Handset (Good Back Glass)	171
Apple	iPhone 8 (64GB) SIM Free (Black)	1	Around 10 Months Warranty-(USA Version A-Green Label) A Handset (Broken Back Glass)	172
Apple	iPhone 8 (64GB) SIM Free (White)	1	Around 10 Months Warranty-(USA Version A-Green Label) A Handset (Broken Back Glass)	173
Apple	iPhone 8 (64GB) SIM Free (Red)	2	Around 10 Months Warranty-(USA Version A-Green Label) A Handset (Broken Back Glass)	174
Apple	iPhone 8 (64GB) SIM Free (Black)	2	On Warranty-(USA Version A-Green Label) A Handset (Good Back Glass)	175
Apple	iPhone 8 (64GB) SIM Free (White)	1	On Warranty-(USA Version A-Green Label) A Handset (Good Back Glass)	176
Apple	iPhone 8 (64GB) SIM Free (Gold)	1	On Warranty-(USA Version A-Green Label) A Handset (Broken Back Glass)	177
Apple	iPhone 8 (64GB) SIM Free (Black)	2	On Warranty-(USA Version A-Green Label) A Handset (Broken Back Glass)	178
Apple	iPhone 8 (64GB) SIM Free (White)	1	Around 10 Months Warranty-(USA Version A-Green Label) A Handset	179
Apple	iPhone 8 (64GB) SIM Free (Red)	1	Around 10 Months Warranty-(USA Version A-Green Label) A Handset	180
Apple	iPhone 8 (64GB) SIM Free (Gold)	2	On Warranty-(USA Version A-Green Label) A Handset	181
Apple	iPhone 8 (64GB) SIM Free (White)	3	On Warranty-(USA Version A-Green Label) A Handset	182
Apple	iPhone 8 (64GB) SIM Free (Gold)	20	(USA Version A-Green Label) A Handset	183
Apple	iPhone 8 (64GB) SIM Free (White)	13	(USA Version A-Green Label) A Handset	184
Apple	iPhone 8 (64GB) SIM Free (Gold)	1	(USA Version A-Green Label) A Handset (Good Back Glass)	185
Apple	iPhone 8 (64GB) SIM Free (White)	2	(USA Version A-Green Label) A Handset (Good Back Glass)	186
Apple	iPhone 8 (64GB) SIM Free (Gold)	2	(USA Version A-Green Label) A Handset (Broken Back Glass)	187
Apple	iPhone 8 (64GB) SIM Free (Black)	2	(USA Version A-Green Label) A Handset (Broken Back Glass)	188
Apple	iPhone 8 (64GB) SIM Free (White)	2	(USA Version A-Green Label) A Handset (Broken Back Glass)	189
Apple	iPhone 8 (64GB) SIM Free (Black)	6	(USA T Version) A Handset (Good Back Glass)	190
Apple	iPhone 8 (64GB) SIM Free (Black)	2	(USA T Version) A Handset (Broken Back Glass)	191
Apple	iPhone 8 (64GB) (SIM Free, Problematic) Total	41	B Handset (Power Up, Good LCD)	192
Apple	iPhone 8 (64GB) (SIM Free, Problematic)	41	Part 2 B Handset (Power Up, Good LCD)	193
Apple	iPhone 8 (256GB) SIM Free Total	24	B Handset (Power Up, Bad LCD)	194
Apple	iPhone 8 (256GB) SIM Free (White)	1	Around 10 Months Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	195
Apple	iPhone 8 (256GB) SIM Free (Black)	9	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	196
Apple	iPhone 8 (256GB) SIM Free (Gold)	6	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	197
Apple	iPhone 8 (256GB) SIM Free (White)	1	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	198
Apple	iPhone 8 (256GB) SIM Free (Black)	4	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	199
Apple	iPhone 8 (256GB) SIM Free (Gold)	1	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	200
Apple	iPhone 8 (256GB) SIM Free (White)	2	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	201
Apple	iPhone 8 (64GB) SIM Free Total	128	B Handset (Power Up, Bad LCD)	202
Apple	iPhone 8 (64GB) SIM Free (Gold)	16	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	203
Apple	iPhone 8 (64GB) SIM Free (Black)	42	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	204
Apple	iPhone 8 (64GB) SIM Free (White)	2	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	205
Apple	iPhone 8 (64GB) SIM Free (Gold)	28	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	206
Apple	iPhone 8 (64GB) SIM Free (Black)	20	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	207
Apple	iPhone 8 (64GB) SIM Free (White)	20	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	208
Apple	iPhone 8 (64GB) (SIM Free, Problematic) Total	22	B Handset (Power Up, Bad LCD)	209
Apple	iPhone 8 (64GB) (SIM Free, Problematic)	22	Part 2 B Handset (Power Up, Bad LCD)	210
Apple	iPhone 8 (64GB) iCloud lock (namely, ID lock) Total	42	B Handset (Power Up, Bad LCD)	211
Apple	iPhone 8 (64GB) iCloud lock (namely, ID lock)	42	Part 2 B Handset (Power Up, Bad LCD)	212
Apple	iPhone 7 Plus (128GB) SIM Free Total	1122	A Handset	213
Apple	iPhone 7 Plus (128GB) SIM Free (White)	3	(USA Version S) A Handset	214
Apple	iPhone 7 Plus (128GB) SIM Free (Rose Gold)	4	(USA Version S) A Handset	215
Apple	iPhone 7 Plus (128GB) SIM Free (Black)	2	(USA Version S) A Handset	216
Apple	iPhone 7 Plus (128GB) SIM Free (White)	5	A Handset	217

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 7 Plus (128GB) SIM Free (Gold)	7	A Handset	218
Apple	iPhone 7 Plus (128GB) SIM Free (Jet Black)	5	A Handset	219
Apple	iPhone 7 Plus (128GB) SIM Free (Rose Gold)	7	A Handset	220
Apple	iPhone 7 Plus (128GB) SIM Free (Black)	26	A Handset	221
Apple	iPhone 7 Plus (128GB) SIM Free (Red)	5	A Handset	222
Apple	iPhone 7 Plus (128GB) SIM Free (White)	2	(USA Version A) A Handset	223
Apple	iPhone 7 Plus (128GB) SIM Free (Gold)	3	(USA Version A) A Handset	224
Apple	iPhone 7 Plus (128GB) SIM Free (Jet Black)	52	(USA Version A) A Handset	225
Apple	iPhone 7 Plus (128GB) SIM Free (Rose Gold)	10	(USA Version A) A Handset	226
Apple	iPhone 7 Plus (128GB) SIM Free (Black)	258	(USA Version A) A Handset	227
Apple	iPhone 7 Plus (128GB) SIM Free (Red)	4	(USA Version A) A Handset	228
Apple	iPhone 7 Plus (128GB) SIM Free (Rose Gold)	4	(USA Version A) A Handset (A+)	229
Apple	iPhone 7 Plus (128GB) SIM Free (Rose Gold)	2	(USA Version A) A Handset (Grade B)	231
Apple	iPhone 7 Plus (128GB) SIM Free (Red)	1	(USA Version A) A Handset (Grade B)	232
Apple	iPhone 7 Plus (128GB) SIM Free (White)	13	(USA Version A-Green Label) A Handset	233
Apple	iPhone 7 Plus (128GB) SIM Free (Gold)	11	(USA Version A-Green Label) A Handset	234
Apple	iPhone 7 Plus (128GB) SIM Free (Jet Black)	84	(USA Version A-Green Label) A Handset	235
Apple	iPhone 7 Plus (128GB) SIM Free (Rose Gold)	136	(USA Version A-Green Label) A Handset	236
Apple	iPhone 7 Plus (128GB) SIM Free (Black)	124	(USA Version A-Green Label) A Handset	237
Apple	iPhone 7 Plus (128GB) SIM Free (Red)	21	(USA Version A-Green Label) A Handset	238
Apple	iPhone 7 Plus (128GB) SIM Free (White)	34	(USA Version A-Green Label, Grade B) A Handset	239
Apple	iPhone 7 Plus (128GB) SIM Free (Gold)	35	(USA Version A-Green Label, Grade B) A Handset	240
Apple	iPhone 7 Plus (128GB) SIM Free (Jet Black)	49	(USA Version A-Green Label, Grade B) A Handset	241
Apple	iPhone 7 Plus (128GB) SIM Free (Rose Gold)	60	(USA Version A-Green Label, Grade B) A Handset	242
Apple	iPhone 7 Plus (128GB) SIM Free (Black)	98	(USA Version A-Green Label, Grade B) A Handset	243
Apple	iPhone 7 Plus (128GB) SIM Free (Red)	18	(USA Version A-Green Label, Grade B) A Handset	244
Apple	iPhone 7 Plus (128GB) SIM Free (Jet Black)	2	(USA T Version) A Handset	245
Apple	iPhone 7 Plus (128GB) SIM Free (White)	1	(USA T Version) A Handset (RW)	246
Apple	iPhone 7 Plus (128GB) SIM Free (Gold)	4	(USA T Version) A Handset (RW)	247
Apple	iPhone 7 Plus (128GB) SIM Free (Jet Black)	13	(USA T Version) A Handset (RW)	248
Apple	iPhone 7 Plus (128GB) SIM Free (Rose Gold)	5	(USA T Version) A Handset (RW)	249
Apple	iPhone 7 Plus (128GB) SIM Free (Black)	12	(USA T Version) A Handset (RW)	250
Apple	iPhone 7 Plus (128GB) SIM Free (Red)	2	(USA T Version) A Handset (RW)	251
Apple	iPhone 7 Plus (256GB) SIM Free Total	121	A Handset	252
Apple	iPhone 7 Plus (256GB) SIM Free (Jet Black)	3	A Handset	253
Apple	iPhone 7 Plus (256GB) SIM Free (Rose Gold)	1	(USA Version A) A Handset	254
Apple	iPhone 7 Plus (256GB) SIM Free (Black)	1	(USA Version A) A Handset	255
Apple	iPhone 7 Plus (256GB) SIM Free (Red)	2	(USA Version A) A Handset	256
Apple	iPhone 7 Plus (256GB) SIM Free (Rose Gold)	1	(USA Version A) A Handset (Grade B)	257
Apple	iPhone 7 Plus (256GB) SIM Free (Jet Black)	16	(USA Version A-Green Label) A Handset	258
Apple	iPhone 7 Plus (256GB) SIM Free (Rose Gold)	5	(USA Version A-Green Label) A Handset	259
Apple	iPhone 7 Plus (256GB) SIM Free (Black)	29	(USA Version A-Green Label) A Handset	260
Apple	iPhone 7 Plus (256GB) SIM Free (Red)	2	(USA Version A-Green Label) A Handset	261
Apple	iPhone 7 Plus (256GB) SIM Free (Gold)	7	(USA Version A-Green Label) A Handset	262
Apple	iPhone 7 Plus (256GB) SIM Free (White)	8	(USA Version A-Green Label) A Handset	263
Apple	iPhone 7 Plus (256GB) SIM Free (Jet Black)	2	(USA Version A-Green Label, Grade B) A Handset	264
Apple	iPhone 7 Plus (256GB) SIM Free (Rose Gold)	8	(USA Version A-Green Label, Grade B) A Handset	265
Apple	iPhone 7 Plus (256GB) SIM Free (Black)	34	(USA Version A-Green Label, Grade B) A Handset	266
Apple	iPhone 7 Plus (256GB) SIM Free (Gold)	1	(USA Version A-Green Label, Grade B) A Handset	267
Apple	iPhone 7 Plus (256GB) SIM Free (Jet Black)	1	(USA T Version) A Handset	268
Apple	iPhone 7 Plus (32GB) (SIM Free, Bad Fingerprint Sensor) Total	141	A Handset	269
Apple	iPhone 7 Plus (32GB) (SIM Free, Bad Fingerprint Sensor)	141	Part 2 A Handset	270
Apple	iPhone 7 Plus (32GB) (SIM Free, Problematic) Total	25	A Handset	271
Apple	iPhone 7 Plus (32GB) (SIM Free, Problematic)	25	Part 2 A Handset	272
Apple	iPhone 7 Plus (32GB) SIM Free Total	433	B Handset (Power Up, Good LCD)	282
Apple	iPhone 7 Plus (32GB) SIM Free (Gold)	2	B Handset (Power Up, Good LCD)	283
Apple	iPhone 7 Plus (32GB) SIM Free (Rose Gold)	1	B Handset (Power Up, Good LCD)	284
Apple	iPhone 7 Plus (32GB) SIM Free (Black)	2	B Handset (Power Up, Good LCD)	285
Apple	iPhone 7 Plus (32GB) SIM Free (White)	1	(USA Version A) B Handset (Power Up, Good LCD)	286
Apple	iPhone 7 Plus (32GB) SIM Free (Gold)	2	(USA Version A) B Handset (Power Up, Good LCD)	287
Apple	iPhone 7 Plus (32GB) SIM Free (Rose Gold)	4	(USA Version A) B Handset (Power Up, Good LCD)	288
Apple	iPhone 7 Plus (32GB) SIM Free (Black)	7	(USA Version A) B Handset (Power Up, Good LCD)	289
Apple	iPhone 7 Plus (32GB) SIM Free (White)	23	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	290
Apple	iPhone 7 Plus (32GB) SIM Free (Gold)	11	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	291
Apple	iPhone 7 Plus (32GB) SIM Free (Rose Gold)	78	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	292
Apple	iPhone 7 Plus (32GB) SIM Free (Black)	100	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	293
Apple	iPhone 7 Plus (32GB) SIM Free (Jet Black)	3	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	294
Apple	iPhone 7 Plus (32GB) SIM Free (White)	6	(USA Version S) B Handset (Power Up, Good LCD)	295
Apple	iPhone 7 Plus (32GB) SIM Free (Gold)	82	(USA Version S) B Handset (Power Up, Good LCD)	296
Apple	iPhone 7 Plus (32GB) SIM Free (Rose Gold)	57	(USA Version S) B Handset (Power Up, Good LCD)	297
Apple	iPhone 7 Plus (32GB) SIM Free (Black)	54	(USA Version S) B Handset (Power Up, Good LCD)	298
Apple	iPhone 7 Plus (128GB) (SIM Free, Bad Fingerprint Sensor) Total	26	B Handset (Power Up, Good LCD)	299
Apple	iPhone 7 Plus (128GB) (SIM Free, Bad Fingerprint Sensor)	26	Part 2 B Handset (Power Up, Good LCD)	300
Apple	iPhone 7 Plus (32GB) (SIM Free, Bad Fingerprint Sensor) Total	24	B Handset (Power Up, Good LCD)	301
Apple	iPhone 7 Plus (32GB) (SIM Free, Bad Fingerprint Sensor)	24	Part 2 B Handset (Power Up, Good LCD)	302
Apple	iPhone 7 Plus (128GB) (SIM Free, Problematic) Total	39	B Handset (Power Up, Good LCD)	303
Apple	iPhone 7 Plus (128GB) (SIM Free, Problematic)	39	Part 2 B Handset (Power Up, Good LCD)	304
Apple	iPhone 7 Plus (256GB) (SIM Free, Problematic) Total	21	B Handset (Power Up, Good LCD)	305
Apple	iPhone 7 Plus (256GB) (SIM Free, Problematic)	21	Part 2 B Handset (Power Up, Good LCD)	306
Apple	iPhone 7 Plus (32GB) (Problematic) Total	22	B Handset (Power Up, Good LCD)	307
Apple	iPhone 7 Plus (32GB) (Problematic)	22	Part 2 B Handset (Power Up, Good LCD)	308
Apple	iPhone 7 Plus (32GB) iCloud lock (namely, ID lock) Total	23	B Handset (Power Up, Good LCD)	309
Apple	iPhone 7 Plus (32GB) iCloud lock (namely, ID lock)	23	Part 2 B Handset (Power Up, Good LCD)	310
Apple	iPhone 7 Plus (256GB) (SIM Free, Problematic) Total	61	B Handset (Power Up, Bad LCD)	349
Apple	iPhone 7 Plus (256GB) (SIM Free, Problematic)	61	Part 2 B Handset (Power Up, Bad LCD)	350
Apple	iPhone 7 Plus (128GB) iCloud lock (namely, ID lock) Total	54	B Handset (Power Up, Bad LCD)	353
Apple	iPhone 7 Plus (128GB) iCloud lock (namely, ID lock)	54	Part 2 B Handset (Power Up, Bad LCD)	354
Apple	iPhone 7 Plus (32GB) iCloud lock (namely, ID lock) Total	46	B Handset (Power Up, Bad LCD)	355
Apple	iPhone 7 Plus (32GB) iCloud lock (namely, ID lock)	46	Part 2 B Handset (Power Up, Bad LCD)	356
Apple	iPhone 7 (128GB) SIM Free Total	28	14A	357
Apple	iPhone 7 (128GB) SIM Free (Jet Black)	28	14A	358
Apple	iPhone 7 (32GB) SIM Free Total	27	N. New Handset	359
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	1	N. New Handset	360
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	5	(USA Version A-Green Label, Grade B) N. New Handset	361
Apple	iPhone 7 (32GB) SIM Free (Black)	19	(USA Version A-Green Label, Grade B) N. New Handset	362
Apple	iPhone 7 (32GB) SIM Free (Jet Black)	1	(USA Version A-Green Label, Grade B) N. New Handset	363
Apple	iPhone 7 (32GB) SIM Free (Gold)	1	(USA Version A-Green Label) N. New Handset	364
Apple	iPhone 7 (128GB) SIM Free Total	811	A Handset	375
Apple	iPhone 7 (128GB) SIM Free (Gold)	74	(USA Version S) A Handset	376
Apple	iPhone 7 (128GB) SIM Free (Jet Black)	21	(USA Version S) A Handset	377
Apple	iPhone 7 (128GB) SIM Free (Red)	5	(USA Version S) A Handset	378
Apple	iPhone 7 (128GB) SIM Free (Rose Gold)	191	(USA Version S) A Handset	379
Apple	iPhone 7 (128GB) SIM Free (Black)	100	(USA Version S) A Handset	380
Apple	iPhone 7 (128GB) SIM Free (White)	47	(USA Version S) A Handset	381
Apple	iPhone 7 (128GB) SIM Free (Jet Black)	2	(USA Version S) A Handset (RW)	382
Apple	iPhone 7 (128GB) SIM Free (Black)	1	(USA Version S) A Handset (RW)	383
Apple	iPhone 7 (128GB) SIM Free (Gold)	11	A Handset	384
Apple	iPhone 7 (128GB) SIM Free (Jet Black)	33	A Handset	385
Apple	iPhone 7 (128GB) SIM Free (Red)	6	A Handset	386
Apple	iPhone 7 (128GB) SIM Free (Rose Gold)	11	A Handset	387
Apple	iPhone 7 (128GB) SIM Free (Black)	55	A Handset	388
Apple	iPhone 7 (128GB) SIM Free (White)	17	A Handset	389
Apple	iPhone 7 (128GB) SIM Free (Red)	4	(USA Version A) A Handset	390
Apple	iPhone 7 (128GB) SIM Free (Black)	1	(USA Version A) A Handset	391
Apple	iPhone 7 (128GB) SIM Free (Gold)	5	(USA Version A) A Handset (Grade B)	392
Apple	iPhone 7 (128GB) SIM Free (Jet Black)	3	(USA Version A) A Handset (Grade B)	393
Apple	iPhone 7 (128GB) SIM Free (Red)	1	(USA Version A) A Handset (Grade B)	394
Apple	iPhone 7 (128GB) SIM Free (Rose Gold)	15	(USA Version A) A Handset (Grade B)	395
Apple	iPhone 7 (128GB) SIM Free (Black)	29	(USA Version A) A Handset (Grade B)	396
Apple	iPhone 7 (128GB) SIM Free (White)	8	(USA Version A) A Handset (Grade B)	397

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 7 (128GB) SIM Free (Gold)	1	(USA Version A-Green Label) A Handset	398
Apple	iPhone 7 (128GB) SIM Free (Jet Black)	5	(USA Version A-Green Label) A Handset	399
Apple	iPhone 7 (128GB) SIM Free (Red)	2	(USA Version A-Green Label) A Handset	400
Apple	iPhone 7 (128GB) SIM Free (Rose Gold)	3	(USA Version A-Green Label) A Handset	401
Apple	iPhone 7 (128GB) SIM Free (Black)	8	(USA Version A-Green Label) A Handset	402
Apple	iPhone 7 (128GB) SIM Free (White)	3	(USA Version A-Green Label) A Handset	403
Apple	iPhone 7 (128GB) SIM Free (Gold)	6	(USA Version A-Green Label, Grade B) A Handset	404
Apple	iPhone 7 (128GB) SIM Free (Jet Black)	12	(USA Version A-Green Label, Grade B) A Handset	405
Apple	iPhone 7 (128GB) SIM Free (Red)	4	(USA Version A-Green Label, Grade B) A Handset	406
Apple	iPhone 7 (128GB) SIM Free (Rose Gold)	70	(USA Version A-Green Label, Grade B) A Handset	407
Apple	iPhone 7 (128GB) SIM Free (Black)	36	(USA Version A-Green Label, Grade B) A Handset	408
Apple	iPhone 7 (128GB) SIM Free (White)	11	(USA Version A-Green Label, Grade B) A Handset	409
Apple	iPhone 7 (128GB) SIM Free (Jet Black)	9	(USA T Version) A Handset	410
Apple	iPhone 7 (128GB) SIM Free (Black)	1	(USA T Version) A Handset (RW)	411
Apple	iPhone 7 (256GB) SIM Free Total	136	A Handset	412
Apple	iPhone 7 (256GB) SIM Free (Black)	52	(USA Version S) A Handset	413
Apple	iPhone 7 (256GB) SIM Free (White)	8	(USA Version S) A Handset	414
Apple	iPhone 7 (256GB) SIM Free (Rose Gold)	6	(USA Version S) A Handset	415
Apple	iPhone 7 (256GB) SIM Free (Black)	2	A Handset	416
Apple	iPhone 7 (256GB) SIM Free (White)	1	A Handset	417
Apple	iPhone 7 (256GB) SIM Free (Black)	4	(USA Version A) A Handset	418
Apple	iPhone 7 (256GB) SIM Free (White)	4	(USA Version A) A Handset	419
Apple	iPhone 7 (256GB) SIM Free (Rose Gold)	2	(USA Version A) A Handset	420
Apple	iPhone 7 (256GB) SIM Free (Gold)	1	(USA Version A) A Handset	421
Apple	iPhone 7 (256GB) SIM Free (Jet Black)	3	(USA Version A) A Handset (Grade B)	422
Apple	iPhone 7 (256GB) SIM Free (Black)	1	(USA Version A) A Handset (Grade B)	423
Apple	iPhone 7 (256GB) SIM Free (Red)	1	(USA Version A) A Handset (Grade B)	424
Apple	iPhone 7 (256GB) SIM Free (Black)	1	(USA Version A-Green Label) A Handset	425
Apple	iPhone 7 (256GB) SIM Free (White)	1	(USA Version A-Green Label) A Handset	426
Apple	iPhone 7 (256GB) SIM Free (Rose Gold)	5	(USA Version A-Green Label) A Handset	427
Apple	iPhone 7 (256GB) SIM Free (Gold)	1	(USA Version A-Green Label) A Handset	428
Apple	iPhone 7 (256GB) SIM Free (Red)	2	(USA Version A-Green Label) A Handset	429
Apple	iPhone 7 (256GB) SIM Free (Jet Black)	20	(USA Version A-Green Label, Grade B) A Handset	430
Apple	iPhone 7 (256GB) SIM Free (Black)	5	(USA Version A-Green Label, Grade B) A Handset	431
Apple	iPhone 7 (256GB) SIM Free (White)	3	(USA Version A-Green Label, Grade B) A Handset	432
Apple	iPhone 7 (256GB) SIM Free (Rose Gold)	4	(USA Version A-Green Label, Grade B) A Handset	433
Apple	iPhone 7 (256GB) SIM Free (Gold)	3	(USA Version A-Green Label, Grade B) A Handset	434
Apple	iPhone 7 (256GB) SIM Free (Red)	1	(USA Version A-Green Label, Grade B) A Handset	435
Apple	iPhone 7 (256GB) SIM Free (Jet Black)	2	(USA T Version) A Handset	436
Apple	iPhone 7 (256GB) SIM Free (Black)	1	(USA V Version) A Handset (RW)	437
Apple	iPhone 7 (256GB) SIM Free (Rose Gold)	1	(USA V Version) A Handset (RW)	438
Apple	iPhone 7 (256GB) SIM Free (Gold)	1	(USA V Version) A Handset (RW)	439
Apple	iPhone 7 (32GB) SIM Free Total	163	A Handset	440
Apple	iPhone 7 (32GB) SIM Free (Gold)	1	(USA Version S) A Handset	441
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	11	(USA Version S) A Handset	442
Apple	iPhone 7 (32GB) SIM Free (Black)	2	(USA Version S) A Handset	443
Apple	iPhone 7 (32GB) SIM Free (White)	3	(USA Version S) A Handset	444
Apple	iPhone 7 (32GB) SIM Free (Gold)	1	A Handset	445
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	4	A Handset	446
Apple	iPhone 7 (32GB) SIM Free (Black)	7	A Handset	447
Apple	iPhone 7 (32GB) SIM Free (White)	4	A Handset	448
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	1	(USA Version A) A Handset	449
Apple	iPhone 7 (32GB) SIM Free (Black)	1	(USA Version A) A Handset	450
Apple	iPhone 7 (32GB) SIM Free (Gold)	1	(USA Version A-Green Label) A Handset	451
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	3	(USA Version A-Green Label) A Handset	452
Apple	iPhone 7 (32GB) SIM Free (Black)	5	(USA Version A-Green Label) A Handset	453
Apple	iPhone 7 (32GB) SIM Free (White)	14	(USA Version A-Green Label) A Handset	454
Apple	iPhone 7 (32GB) SIM Free (Jet Black)	1	(USA Version A-Green Label) A Handset	455
Apple	iPhone 7 (32GB) SIM Free (Gold)	8	(USA Version A-Green Label, Grade B) A Handset	456
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	41	(USA Version A-Green Label, Grade B) A Handset	457
Apple	iPhone 7 (32GB) SIM Free (Black)	49	(USA Version A-Green Label, Grade B) A Handset	458
Apple	iPhone 7 (32GB) SIM Free (White)	6	(USA Version A-Green Label, Grade B) A Handset	459
Apple	iPhone 7 (128GB) (SIM Free, Bad Fingerprint Sensor) Total	30	A Handset	460
Apple	iPhone 7 (128GB) (SIM Free, Bad Fingerprint Sensor)	30	Part 2 A Handset	461
Apple	iPhone 7 (32GB) (SIM Free, Problematic) Total	45	A Handset	464
Apple	iPhone 7 (32GB) (SIM Free, Problematic)	45	Part 2 A Handset	465
Apple	iPhone 7 (32GB) (Problematic) Total	24	A Handset	466
Apple	iPhone 7 (32GB) (Problematic)	24	Part 2 A Handset	467
Apple	iPhone 7 (128GB) SIM Free Total	34	B Handset (Power Up, Good LCD)	468
Apple	iPhone 7 (128GB) SIM Free (Black)	4	(USA Version A) B Handset (Power Up, Good LCD)	469
Apple	iPhone 7 (128GB) SIM Free (Gold)	7	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	470
Apple	iPhone 7 (128GB) SIM Free (Jet Black)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	471
Apple	iPhone 7 (128GB) SIM Free (Red)	6	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	472
Apple	iPhone 7 (128GB) SIM Free (Rose Gold)	2	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	473
Apple	iPhone 7 (128GB) SIM Free (Black)	10	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	474
Apple	iPhone 7 (128GB) SIM Free (White)	4	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	475
Apple	iPhone 7 (256GB) SIM Free Total	24	B Handset (Power Up, Good LCD)	476
Apple	iPhone 7 (256GB) SIM Free (Jet Black)	3	(USA Version A) B Handset (Power Up, Good LCD)	477
Apple	iPhone 7 (256GB) SIM Free (Black)	6	(USA Version A) B Handset (Power Up, Good LCD)	478
Apple	iPhone 7 (256GB) SIM Free (White)	2	(USA Version A) B Handset (Power Up, Good LCD)	479
Apple	iPhone 7 (256GB) SIM Free (Jet Black)	2	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	480
Apple	iPhone 7 (256GB) SIM Free (Black)	4	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	481
Apple	iPhone 7 (256GB) SIM Free (Rose Gold)	5	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	482
Apple	iPhone 7 (256GB) SIM Free (Gold)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	483
Apple	iPhone 7 (256GB) SIM Free (Red)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	484
Apple	iPhone 7 (32GB) SIM Free Total	45	B Handset (Power Up, Good LCD)	485
Apple	iPhone 7 (32GB) SIM Free (Gold)	1	B Handset (Power Up, Good LCD)	486
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	2	B Handset (Power Up, Good LCD)	487
Apple	iPhone 7 (32GB) SIM Free (Black)	1	B Handset (Power Up, Good LCD)	488
Apple	iPhone 7 (32GB) SIM Free (Gold)	1	(USA Version A) B Handset (Power Up, Good LCD)	489
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	4	(USA Version A) B Handset (Power Up, Good LCD)	490
Apple	iPhone 7 (32GB) SIM Free (Black)	10	(USA Version A) B Handset (Power Up, Good LCD)	491
Apple	iPhone 7 (32GB) SIM Free (Gold)	3	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	492
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	3	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	493
Apple	iPhone 7 (32GB) SIM Free (Black)	10	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	494
Apple	iPhone 7 (32GB) SIM Free (White)	7	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	495
Apple	iPhone 7 (32GB) SIM Free (Jet Black)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	496
Apple	iPhone 7 (32GB) SIM Free (Black)	2	(USA Version S) B Handset (Power Up, Good LCD)	497
Apple	iPhone 7 (128GB) (SIM Free, Problematic) Total	79	B Handset (Power Up, Good LCD)	498
Apple	iPhone 7 (128GB) (SIM Free, Problematic)	79	Part 2 B Handset (Power Up, Good LCD)	499
Apple	iPhone 7 (32GB) (SIM Free, Problematic) Total	384	B Handset (Power Up, Good LCD)	500
Apple	iPhone 7 (32GB) (SIM Free, Problematic)	384	Part 2 B Handset (Power Up, Good LCD)	501
Apple	iPhone 7 (128GB) iCloud lock (namely, ID lock) Total	33	B Handset (Power Up, Good LCD)	502
Apple	iPhone 7 (128GB) iCloud lock (namely, ID lock)	33	Part 2 B Handset (Power Up, Good LCD)	503
Apple	iPhone 7 (32GB) iCloud lock (namely, ID lock) Total	112	B Handset (Power Up, Good LCD)	504
Apple	iPhone 7 (32GB) iCloud lock (namely, ID lock)	112	Part 2 B Handset (Power Up, Good LCD)	505
Apple	iPhone 7 (128GB) SIM Free Total	500	B Handset (Power Up, Bad LCD)	506
Apple	iPhone 7 (128GB) SIM Free (Jet Black)	2	B Handset (Power Up, Bad LCD)	507
Apple	iPhone 7 (128GB) SIM Free (Black)	2	B Handset (Power Up, Bad LCD)	508
Apple	iPhone 7 (128GB) SIM Free (Gold)	1	(USA Version A) B Handset (Power Up, Bad LCD)	509
Apple	iPhone 7 (128GB) SIM Free (Red)	6	(USA Version A) B Handset (Power Up, Bad LCD)	510
Apple	iPhone 7 (128GB) SIM Free (Rose Gold)	3	(USA Version A) B Handset (Power Up, Bad LCD)	511
Apple	iPhone 7 (128GB) SIM Free (Black)	13	(USA Version A) B Handset (Power Up, Bad LCD)	512
Apple	iPhone 7 (128GB) SIM Free (White)	1	(USA Version A) B Handset (Power Up, Bad LCD)	513
Apple	iPhone 7 (128GB) SIM Free (Gold)	44	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	514
Apple	iPhone 7 (128GB) SIM Free (Jet Black)	26	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	515
Apple	iPhone 7 (128GB) SIM Free (Red)	73	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	516
Apple	iPhone 7 (128GB) SIM Free (Rose Gold)	135	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	517
Apple	iPhone 7 (128GB) SIM Free (Black)	143	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	518
Apple	iPhone 7 (128GB) SIM Free (White)	51	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	519

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 7 (32GB) SIM Free Total	558	B Handset (Power Up, Bad LCD)	520
Apple	iPhone 7 (32GB) SIM Free (Gold)	3	B Handset (Power Up, Bad LCD)	521
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	4	B Handset (Power Up, Bad LCD)	522
Apple	iPhone 7 (32GB) SIM Free (Black)	6	B Handset (Power Up, Bad LCD)	523
Apple	iPhone 7 (32GB) SIM Free (White)	4	B Handset (Power Up, Bad LCD)	524
Apple	iPhone 7 (32GB) SIM Free (Gold)	7	(USA Version A) B Handset (Power Up, Bad LCD)	525
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	8	(USA Version A) B Handset (Power Up, Bad LCD)	526
Apple	iPhone 7 (32GB) SIM Free (Black)	22	(USA Version A) B Handset (Power Up, Bad LCD)	527
Apple	iPhone 7 (32GB) SIM Free (White)	3	(USA Version A) B Handset (Power Up, Bad LCD)	528
Apple	iPhone 7 (32GB) SIM Free (Gold)	41	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	529
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	42	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	530
Apple	iPhone 7 (32GB) SIM Free (Black)	176	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	531
Apple	iPhone 7 (32GB) SIM Free (White)	36	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	532
Apple	iPhone 7 (32GB) SIM Free (Jet Black)	2	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	533
Apple	iPhone 7 (32GB) SIM Free (Gold)	38	(USA Version S) B Handset (Power Up, Bad LCD)	534
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	79	(USA Version S) B Handset (Power Up, Bad LCD)	535
Apple	iPhone 7 (32GB) SIM Free (Black)	48	(USA Version S) B Handset (Power Up, Bad LCD)	536
Apple	iPhone 7 (32GB) SIM Free (White)	38	(USA Version S) B Handset (Power Up, Bad LCD)	537
Apple	iPhone 7 (32GB) SIM Free (Jet Black)	1	(USA Version S) B Handset (Power Up, Bad LCD)	538
Apple	iPhone 7 (128GB) (SIM Free, Problematic) Total	324	B Handset (Power Up, Bad LCD)	539
Apple	iPhone 7 (128GB) (SIM Free, Problematic)	324	Part 2 B Handset (Power Up, Bad LCD)	540
Apple	iPhone 7 (32GB) (SIM Free, Problematic) Total	356	B Handset (Power Up, Bad LCD)	541
Apple	iPhone 7 (32GB) (SIM Free, Problematic)	356	Part 2 B Handset (Power Up, Bad LCD)	542
Apple	iPhone 7 (32GB) (Problematic) Total	120	B Handset (Power Up, Bad LCD)	543
Apple	iPhone 7 (32GB) (Problematic)	120	Part 2 B Handset (Power Up, Bad LCD)	544
Apple	iPhone 7 (128GB) iCloud lock (namely, ID lock) Total	26	B Handset (Power Up, Bad LCD)	545
Apple	iPhone 7 (128GB) iCloud lock (namely, ID lock)	26	Part 2 B Handset (Power Up, Bad LCD)	546
Apple	iPhone 7 (32GB) iCloud lock (namely, ID lock) Total	67	B Handset (Power Up, Bad LCD)	547
Apple	iPhone 7 (32GB) iCloud lock (namely, ID lock)	67	Part 2 B Handset (Power Up, Bad LCD)	548
Apple	iPhone 6s Plus (32GB) SIM Free Total	1	A Handset+	549
Apple	iPhone 6s Plus (32GB) SIM Free (Rose Gold)	1	(USA Version A-Green Label) A Handset+	550
Apple	iPhone 6s Plus (128GB) SIM Free Total	65	A Handset	554
Apple	iPhone 6s Plus (128GB) SIM Free (Rose Gold)	1	(USA Version A) A Handset	555
Apple	iPhone 6s Plus (128GB) SIM Free (Black)	11	(USA Version A-Green Label) A Handset	556
Apple	iPhone 6s Plus (128GB) SIM Free (White)	3	(USA Version A-Green Label) A Handset	557
Apple	iPhone 6s Plus (128GB) SIM Free (Rose Gold)	7	(USA Version A-Green Label) A Handset	558
Apple	iPhone 6s Plus (128GB) SIM Free (Gold)	3	(USA Version A-Green Label) A Handset	559
Apple	iPhone 6s Plus (128GB) SIM Free (Black)	9	(USA Version A-Green Label, Grade B) A Handset	560
Apple	iPhone 6s Plus (128GB) SIM Free (White)	6	(USA Version A-Green Label, Grade B) A Handset	561
Apple	iPhone 6s Plus (128GB) SIM Free (Rose Gold)	16	(USA Version A-Green Label, Grade B) A Handset	562
Apple	iPhone 6s Plus (128GB) SIM Free (Gold)	9	(USA Version A-Green Label, Grade B) A Handset	563
Apple	iPhone 6s Plus (16GB) SIM Free Total	29	A Handset	564
Apple	iPhone 6s Plus (16GB) SIM Free (White)	3	(USA Version A-Green Label) A Handset	565
Apple	iPhone 6s Plus (16GB) SIM Free (Gold)	10	(USA Version A-Green Label) A Handset	566
Apple	iPhone 6s Plus (16GB) SIM Free (Rose Gold)	4	(USA Version A-Green Label) A Handset	567
Apple	iPhone 6s Plus (16GB) SIM Free (Black)	12	(USA Version A-Green Label) A Handset	568
Apple	iPhone 6s Plus (32GB) SIM Free Total	105	A Handset	569
Apple	iPhone 6s Plus (32GB) SIM Free (White)	1	A Handset	570
Apple	iPhone 6s Plus (32GB) SIM Free (White)	2	(USA Version A-Green Label) A Handset	571
Apple	iPhone 6s Plus (32GB) SIM Free (Rose Gold)	6	(USA Version A-Green Label) A Handset	572
Apple	iPhone 6s Plus (32GB) SIM Free (Black)	47	(USA Version A-Green Label, Grade B) A Handset	573
Apple	iPhone 6s Plus (32GB) SIM Free (White)	3	(USA Version A-Green Label, Grade B) A Handset	574
Apple	iPhone 6s Plus (32GB) SIM Free (Gold)	6	(USA Version A-Green Label, Grade B) A Handset	575
Apple	iPhone 6s Plus (32GB) SIM Free (Rose Gold)	40	(USA Version A-Green Label, Grade B) A Handset	576
Apple	iPhone 6s Plus (64GB) SIM Free Total	131	A Handset	577
Apple	iPhone 6s Plus (64GB) SIM Free (Gold)	2	A Handset	578
Apple	iPhone 6s Plus (64GB) SIM Free (Black)	2	A Handset	579
Apple	iPhone 6s Plus (64GB) SIM Free (Rose Gold)	1	A Handset	580
Apple	iPhone 6s Plus (64GB) SIM Free (White)	2	A Handset	581
Apple	iPhone 6s Plus (64GB) SIM Free (Rose Gold)	2	(USA Version A) A Handset	582
Apple	iPhone 6s Plus (64GB) SIM Free (White)	2	(USA Version A) A Handset	583
Apple	iPhone 6s Plus (64GB) SIM Free (Gold)	13	(USA Version A-Green Label) A Handset	584
Apple	iPhone 6s Plus (64GB) SIM Free (Black)	17	(USA Version A-Green Label) A Handset	585
Apple	iPhone 6s Plus (64GB) SIM Free (Rose Gold)	13	(USA Version A-Green Label) A Handset	586
Apple	iPhone 6s Plus (64GB) SIM Free (White)	7	(USA Version A-Green Label) A Handset	587
Apple	iPhone 6s Plus (64GB) SIM Free (Gold)	11	(USA Version A-Green Label, Grade B) A Handset	588
Apple	iPhone 6s Plus (64GB) SIM Free (Black)	26	(USA Version A-Green Label, Grade B) A Handset	589
Apple	iPhone 6s Plus (64GB) SIM Free (Rose Gold)	27	(USA Version A-Green Label, Grade B) A Handset	590
Apple	iPhone 6s Plus (64GB) SIM Free (White)	6	(USA Version A-Green Label, Grade B) A Handset	591
Apple	iPhone 6s Plus (64GB) (SIM Free, Bad Fingerprint Sensor) Total	23	A Handset	592
Apple	iPhone 6s Plus (64GB) (SIM Free, Bad Fingerprint Sensor)	23	Part 2 A Handset	593
Apple	iPhone 6s Plus (16GB) SIM Free Total	84	B Handset (Power Up, Bad LCD)	614
Apple	iPhone 6s Plus (16GB) SIM Free (Gold)	1	B Handset (Power Up, Bad LCD)	615
Apple	iPhone 6s Plus (16GB) SIM Free (White)	7	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	616
Apple	iPhone 6s Plus (16GB) SIM Free (Gold)	10	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	617
Apple	iPhone 6s Plus (16GB) SIM Free (Rose Gold)	39	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	618
Apple	iPhone 6s Plus (16GB) SIM Free (Black)	27	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	619
Apple	iPhone 6s Plus (32GB) SIM Free Total	50	B Handset (Power Up, Bad LCD)	620
Apple	iPhone 6s Plus (32GB) SIM Free (Black)	1	(USA Version A) B Handset (Power Up, Bad LCD)	621
Apple	iPhone 6s Plus (32GB) SIM Free (Black)	17	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	622
Apple	iPhone 6s Plus (32GB) SIM Free (White)	3	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	623
Apple	iPhone 6s Plus (32GB) SIM Free (Gold)	4	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	624
Apple	iPhone 6s Plus (32GB) SIM Free (Rose Gold)	25	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	625
Apple	iPhone 6s Plus (64GB) SIM Free Total	177	B Handset (Power Up, Bad LCD)	626
Apple	iPhone 6s Plus (64GB) SIM Free (Gold)	2	B Handset (Power Up, Bad LCD)	627
Apple	iPhone 6s Plus (64GB) SIM Free (Black)	2	B Handset (Power Up, Bad LCD)	628
Apple	iPhone 6s Plus (64GB) SIM Free (Black)	1	(USA Version A) B Handset (Power Up, Bad LCD)	629
Apple	iPhone 6s Plus (64GB) SIM Free (Rose Gold)	3	(USA Version A) B Handset (Power Up, Bad LCD)	630
Apple	iPhone 6s Plus (64GB) SIM Free (Gold)	32	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	631
Apple	iPhone 6s Plus (64GB) SIM Free (Black)	65	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	632
Apple	iPhone 6s Plus (64GB) SIM Free (Rose Gold)	52	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	633
Apple	iPhone 6s Plus (64GB) SIM Free (White)	12	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	634
Apple	iPhone 6s Plus (64GB) SIM Free (Gold)	1	(USA Version S) B Handset (Power Up, Bad LCD)	635
Apple	iPhone 6s Plus (64GB) SIM Free (Black)	1	(USA Version S) B Handset (Power Up, Bad LCD)	636
Apple	iPhone 6s Plus (64GB) SIM Free (Rose Gold)	4	(USA Version S) B Handset (Power Up, Bad LCD)	637
Apple	iPhone 6s Plus (64GB) SIM Free (White)	2	(USA Version S) B Handset (Power Up, Bad LCD)	638
Apple	iPhone 6s (32GB) SIM Free Total	31	A Handset	646
Apple	iPhone 6s (32GB) SIM Free (Black)	2	A Handset	647
Apple	iPhone 6s (32GB) SIM Free (White)	3	A Handset	648
Apple	iPhone 6s (32GB) SIM Free (White)	3	(USA Version A) A Handset	649
Apple	iPhone 6s (32GB) SIM Free (Rose Gold)	1	(USA Version A) A Handset	650
Apple	iPhone 6s (32GB) SIM Free (Gold)	3	(USA Version A) A Handset	651
Apple	iPhone 6s (32GB) SIM Free (Black)	6	(USA Version A-Green Label) A Handset	652
Apple	iPhone 6s (32GB) SIM Free (White)	6	(USA Version A-Green Label) A Handset	653
Apple	iPhone 6s (32GB) SIM Free (Rose Gold)	4	(USA Version A-Green Label) A Handset	654
Apple	iPhone 6s (32GB) SIM Free (Gold)	3	(USA Version A-Green Label) A Handset	655
Apple	iPhone 6s (16GB) iCloud lock (namely, ID lock) Total	50	A Handset	666
Apple	iPhone 6s (16GB) iCloud lock (namely, ID lock)	50	Part 2 A Handset	667
Apple	iPhone 6s (32GB) SIM Free Total	42	B Handset (Power Up, Good LCD)	668
Apple	iPhone 6s (32GB) SIM Free (Black)	1	B Handset (Power Up, Good LCD)	669
Apple	iPhone 6s (32GB) SIM Free (Rose Gold)	3	B Handset (Power Up, Good LCD)	670
Apple	iPhone 6s (32GB) SIM Free (White)	2	(USA Version A) B Handset (Power Up, Good LCD)	671
Apple	iPhone 6s (32GB) SIM Free (Rose Gold)	1	(USA Version A) B Handset (Power Up, Good LCD)	672
Apple	iPhone 6s (32GB) SIM Free (Gold)	3	(USA Version A) B Handset (Power Up, Good LCD)	673
Apple	iPhone 6s (32GB) SIM Free (Black)	7	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	674
Apple	iPhone 6s (32GB) SIM Free (White)	3	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	675
Apple	iPhone 6s (32GB) SIM Free (Rose Gold)	7	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	676
Apple	iPhone 6s (32GB) SIM Free (Gold)	15	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	677
Apple	iPhone 6s (16GB) iCloud lock (namely, ID lock) Total	49	B Handset (Power Up, Good LCD)	678
Apple	iPhone 6s (16GB) iCloud lock (namely, ID lock)	49	Part 2 B Handset (Power Up, Good LCD)	679

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 6s (128GB) SIM Free Total	3	B Handset (Power Up, Bad LCD)	680
Apple	iPhone 6s (128GB) SIM Free (Black)	1	B Handset (Power Up, Bad LCD)	681
Apple	iPhone 6s (128GB) SIM Free (Rose Gold)	2	B Handset (Power Up, Bad LCD)	682
Apple	iPhone 6s (64GB) SIM Free Total	4	B Handset (Power Up, Bad LCD)	695
Apple	iPhone 6s (64GB) SIM Free (Black)	1	B Handset (Power Up, Bad LCD)	696
Apple	iPhone 6s (64GB) SIM Free (Rose Gold)	2	B Handset (Power Up, Bad LCD)	697
Apple	iPhone 6s (64GB) SIM Free (White)	1	B Handset (Power Up, Bad LCD)	698
Apple	iPhone 6 Plus (16GB) SIM Free Total	35	A Handset	703
Apple	iPhone 6 Plus (16GB) SIM Free (Black)	3	(USA Version S) A Handset	704
Apple	iPhone 6 Plus (16GB) SIM Free (Black)	6	A Handset	705
Apple	iPhone 6 Plus (16GB) SIM Free (White)	7	A Handset	706
Apple	iPhone 6 Plus (16GB) SIM Free (Gold)	5	A Handset	707
Apple	iPhone 6 Plus (16GB) SIM Free (Black)	4	(America Version) A Handset	708
Apple	iPhone 6 Plus (16GB) SIM Free (White)	2	(America Version) A Handset	709
Apple	iPhone 6 Plus (16GB) SIM Free (Black)	4	(USA Version A-Green Label) A Handset	710
Apple	iPhone 6 Plus (16GB) SIM Free (White)	2	(USA Version A-Green Label) A Handset	711
Apple	iPhone 6 Plus (16GB) SIM Free (Gold)	2	(USA Version A-Green Label) A Handset	712
Apple	iPhone 6 Plus (64GB) SIM Free Total	32	A Handset	713
Apple	iPhone 6 Plus (64GB) SIM Free (White)	3	A Handset	714
Apple	iPhone 6 Plus (64GB) SIM Free (Gold)	10	(USA Version A-Green Label) A Handset	715
Apple	iPhone 6 Plus (64GB) SIM Free (Black)	18	(USA Version A-Green Label) A Handset	716
Apple	iPhone 6 Plus (64GB) SIM Free (White)	1	(USA Version A-Green Label, Grade B) A Handset	717
Apple	iPhone 6 Plus (16GB) iCloud lock (namely, ID lock) Total	22	B Handset (Power Up, Good LCD)	718
Apple	iPhone 6 Plus (16GB) iCloud lock (namely, ID lock)	22	Part 2 B Handset (Power Up, Good LCD)	719
Apple	iPhone 6 Plus (64GB) (SIM Free, Problematic) Total	20	B Handset (Power Up, Bad LCD)	722
Apple	iPhone 6 Plus (64GB) (SIM Free, Problematic)	20	Part 2 B Handset (Power Up, Bad LCD)	723
Apple	iPhone 6 (16GB) iCloud lock (namely, ID lock) Total	41	A Handset	731
Apple	iPhone 6 (16GB) iCloud lock (namely, ID lock)	41	Part 2 A Handset	732
Apple	iPhone 6 (16GB) iCloud lock (namely, ID lock) Total	42	B Handset (Power Up, Good LCD)	738
Apple	iPhone 6 (16GB) iCloud lock (namely, ID lock)	42	Part 2 B Handset (Power Up, Good LCD)	739
Apple	iPhone 6 (16GB) iCloud lock (namely, ID lock) Total	80	B Handset (Power Up, Bad LCD)	740
Apple	iPhone 6 (16GB) iCloud lock (namely, ID lock)	80	Part 2 B Handset (Power Up, Bad LCD)	741
Apple	iPhone 5s (16GB) (SIM Free, Problematic) Total	459	B Handset (Power Up, Good LCD)	747
Apple	iPhone 5s (16GB) (SIM Free, Problematic)	459	Part 2 B Handset (Power Up, Good LCD)	748
Apple	iPhone 5s (32GB) (SIM Free, Problematic) Total	117	B Handset (Power Up, Good LCD)	749
Apple	iPhone 5s (32GB) (SIM Free, Problematic)	117	Part 2 B Handset (Power Up, Good LCD)	750
Apple	iPhone 5s (16GB) iCloud lock (namely, ID lock) Total	122	B Handset (Power Up, Good LCD)	751
Apple	iPhone 5s (16GB) iCloud lock (namely, ID lock)	122	Part 2 B Handset (Power Up, Good LCD)	752
Apple	iPhone 5s (32GB) iCloud lock (namely, ID lock) Total	536	B Handset (Power Up, Good LCD)	753
Apple	iPhone 5s (32GB) iCloud lock (namely, ID lock)	536	Part 2 B Handset (Power Up, Good LCD)	754
Apple	iPhone 5s (16GB) iCloud lock (namely, ID lock) Total	2980	B Handset (Power Up, Bad LCD)	761
Apple	iPhone 5s (16GB) iCloud lock (namely, ID lock)	2980	Part 2 B Handset (Power Up, Bad LCD)	762
Apple	iPhone 5s (32GB) iCloud lock (namely, ID lock) Total	470	B Handset (Power Up, Bad LCD)	763
Apple	iPhone 5s (32GB) iCloud lock (namely, ID lock)	470	Part 2 B Handset (Power Up, Bad LCD)	764
Apple	iPhone 5 (16GB) (SIM Free, Problematic) Total	53	A Handset	769
Apple	iPhone 5 (16GB) (SIM Free, Problematic)	53	Part 2 A Handset	770
Apple	iPhone 5 (16GB) (Problematic) Total	25	B Handset (Power Up, Bad LCD)	771
Apple	iPhone 5 (16GB) (Problematic)	25	Part 2 B Handset (Power Up, Bad LCD)	772
Apple	iPhone 5 (16GB) Total	53	B Handset (Power Up, Bad LCD)	773
Apple	iPhone 5 (16GB)	53	Part 2 B Handset (Power Up, Bad LCD)	774
Apple	iPhone 5c (32GB) SIM Free Total	1	A Handset	775
Apple	iPhone 5c (32GB) SIM Free	1	(USA Version S) A Handset	776
Apple	iPhone 4s (16GB) (Problematic) Total	21	A Handset	781
Apple	iPhone 4s (16GB) (Problematic)	21	Part 2 A Handset	782
Apple	iPhone 4s (8GB) (Problematic) Total	22	A Handset	783
Apple	iPhone 4s (8GB) (Problematic)	22	Part 2 A Handset	784
Apple	iPhone 4s (16GB) (Problematic) Total	53	B Handset (Power Up, Good LCD)	785
Apple	iPhone 4s (16GB) (Problematic)	53	Part 2 B Handset (Power Up, Good LCD)	786
Apple	iPhone 4s (8GB) (Problematic) Total	66	B Handset (Power Up, Good LCD)	787
Apple	iPhone 4s (8GB) (Problematic)	66	Part 2 B Handset (Power Up, Good LCD)	788
Apple	iPhone 4s (16GB) iCloud lock (namely, ID lock) Total	3578	B Handset (Power Up, Good LCD)	789
Apple	iPhone 4s (16GB) iCloud lock (namely, ID lock)	3578	Part 2 B Handset (Power Up, Good LCD)	790
Apple	iPhone 4s (64GB) iCloud lock (namely, ID lock) Total	22	B Handset (Power Up, Good LCD)	791
Apple	iPhone 4s (64GB) iCloud lock (namely, ID lock)	22	Part 2 B Handset (Power Up, Good LCD)	792
Apple	iPhone 4s (16GB) Total	30	B Handset (Power Up, Good LCD)	793
Apple	iPhone 4s (16GB)	30	Part 2 B Handset (Power Up, Good LCD)	794
Apple	iPhone 4s (8GB) Total	28	B Handset (Power Up, Good LCD)	795
Apple	iPhone 4s (8GB)	28	Part 2 B Handset (Power Up, Good LCD)	796
Apple	iPhone 4s (16GB) (SIM Free, Problematic) Total	21	B Handset (Power Up, Bad LCD)	797
Apple	iPhone 4s (16GB) (SIM Free, Problematic)	21	Part 2 B Handset (Power Up, Bad LCD)	798
Apple	iPhone 4s (16GB) iCloud lock (namely, ID lock) Total	1115	B Handset (Power Up, Bad LCD)	799
Apple	iPhone 4s (16GB) iCloud lock (namely, ID lock)	1115	Part 2 B Handset (Power Up, Bad LCD)	800
Apple	iPhone 4s (32GB) iCloud lock (namely, ID lock) Total	94	B Handset (Power Up, Bad LCD)	801
Apple	iPhone 4s (32GB) iCloud lock (namely, ID lock)	94	Part 2 B Handset (Power Up, Bad LCD)	802
Apple	iPhone 4s (64GB) iCloud lock (namely, ID lock) Total	29	B Handset (Power Up, Bad LCD)	803
Apple	iPhone 4s (64GB) iCloud lock (namely, ID lock)	29	Part 2 B Handset (Power Up, Bad LCD)	804
Apple	iPhone 4s (8GB) iCloud lock (namely, ID lock) Total	243	B Handset (Power Up, Bad LCD)	805
Apple	iPhone 4s (8GB) iCloud lock (namely, ID lock)	243	Part 2 B Handset (Power Up, Bad LCD)	806
Apple	iPhone 4s (8GB) Total	104	B Handset (Power Up, Bad LCD)	807
Apple	iPhone 4s (8GB)	104	Part 2 B Handset (Power Up, Bad LCD)	808
Apple	iPhone 4 (16GB) (SIM Free, Problematic) Total	35	A Handset	809
Apple	iPhone 4 (16GB) (SIM Free, Problematic)	35	Part 2 A Handset	810
Apple	iPhone 4 (8GB) (SIM Free, Problematic) Total	58	A Handset	811
Apple	iPhone 4 (8GB) (SIM Free, Problematic)	58	Part 2 A Handset	812
Apple	iPhone 4 (8GB) (Problematic) Total	28	A Handset	813
Apple	iPhone 4 (8GB) (Problematic)	28	Part 2 A Handset	814
Apple	iPhone 4 (32GB) iCloud lock (namely, ID lock) Total	58	A Handset	815
Apple	iPhone 4 (32GB) iCloud lock (namely, ID lock)	58	Part 2 A Handset	816
Apple	iPhone 4 (8GB) Total	28	A Handset	817
Apple	iPhone 4 (8GB)	28	Part 2 A Handset	818
Apple	iPhone 4 (16GB) SIM Free Total	26	B Handset (Power Up, Good LCD)	819
Apple	iPhone 4 (16GB) SIM Free	26	B Handset (Power Up, Good LCD)	820
Apple	iPhone 4 (16GB) (SIM Free, Problematic) Total	55	B Handset (Power Up, Good LCD)	821
Apple	iPhone 4 (16GB) (SIM Free, Problematic)	55	Part 2 B Handset (Power Up, Good LCD)	822
Apple	iPhone 4 (8GB) (SIM Free, Problematic) Total	69	B Handset (Power Up, Good LCD)	823
Apple	iPhone 4 (8GB) (SIM Free, Problematic)	69	Part 2 B Handset (Power Up, Good LCD)	824
Apple	iPhone 4 (16GB) (Problematic) Total	40	B Handset (Power Up, Good LCD)	825
Apple	iPhone 4 (16GB) (Problematic)	40	Part 2 B Handset (Power Up, Good LCD)	826
Apple	iPhone 4 (8GB) (Problematic) Total	144	B Handset (Power Up, Good LCD)	827
Apple	iPhone 4 (8GB) (Problematic)	144	Part 2 B Handset (Power Up, Good LCD)	828
Apple	iPhone 4 (16GB) iCloud lock (namely, ID lock) Total	1774	B Handset (Power Up, Good LCD)	829
Apple	iPhone 4 (16GB) iCloud lock (namely, ID lock)	1774	Part 2 B Handset (Power Up, Good LCD)	830
Apple	iPhone 4 (32GB) iCloud lock (namely, ID lock) Total	285	B Handset (Power Up, Good LCD)	831
Apple	iPhone 4 (32GB) iCloud lock (namely, ID lock)	285	Part 2 B Handset (Power Up, Good LCD)	832
Apple	iPhone 4 (8GB) iCloud lock (namely, ID lock) Total	2012	B Handset (Power Up, Good LCD)	833
Apple	iPhone 4 (8GB) iCloud lock (namely, ID lock)	2012	Part 2 B Handset (Power Up, Good LCD)	834
Apple	iPhone 4 (32GB) Total	83	B Handset (Power Up, Good LCD)	835
Apple	iPhone 4 (32GB)	83	Part 2 B Handset (Power Up, Good LCD)	836
Apple	iPhone 4 (8GB) Total	20	B Handset (Power Up, Good LCD)	837
Apple	iPhone 4 (8GB)	20	Part 2 B Handset (Power Up, Good LCD)	838
Apple	iPhone 4 (8GB) (CDMA) Total	22	B Handset (Power Up, Good LCD)	839
Apple	iPhone 4 (8GB) (CDMA)	22	Part 2 B Handset (Power Up, Good LCD)	840
Apple	iPhone 4 (16GB) SIM Free Total	55	B Handset (Power Up, Bad LCD)	841
Apple	iPhone 4 (16GB) SIM Free	55	B Handset (Power Up, Bad LCD)	842
Apple	iPhone 4 (8GB) SIM Free Total	41	B Handset (Power Up, Bad LCD)	843
Apple	iPhone 4 (8GB) SIM Free	41	B Handset (Power Up, Bad LCD)	844
Apple	iPhone 4 (8GB) (SIM Free, Problematic) Total	23	B Handset (Power Up, Bad LCD)	845
Apple	iPhone 4 (8GB) (SIM Free, Problematic)	23	Part 2 B Handset (Power Up, Bad LCD)	846
Apple	iPhone 4 (16GB) iCloud lock (namely, ID lock) Total	232	B Handset (Power Up, Bad LCD)	847
Apple	iPhone 4 (16GB) iCloud lock (namely, ID lock)	232	Part 2 B Handset (Power Up, Bad LCD)	848

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 4 (32GB) iCloud lock (namely, ID lock) Total	61	B Handset (Power Up, Bad LCD)	849
Apple	iPhone 4 (32GB) iCloud lock (namely, ID lock)	61	Part 2 B Handset (Power Up, Bad LCD)	850
Apple	iPhone 4 (8GB) iCloud lock (namely, ID lock) Total	212	B Handset (Power Up, Bad LCD)	851
Apple	iPhone 4 (8GB) iCloud lock (namely, ID lock)	212	Part 2 B Handset (Power Up, Bad LCD)	852
Apple	iPhone 4 (16GB) Total	112	B Handset (Power Up, Bad LCD)	853
Apple	iPhone 4 (16GB)	112	Part 2 B Handset (Power Up, Bad LCD)	854
Apple	iPhone 4 (8GB) Total	218	B Handset (Power Up, Bad LCD)	855
Apple	iPhone 4 (8GB)	218	Part 2 B Handset (Power Up, Bad LCD)	856
Apple	iPhone 3G (16GB) Total	24	B Handset (Power Up, Good LCD)	857
Apple	iPhone 3G (16GB)	24	B Handset (Power Up, Good LCD)	858
Apple	iPhone 3G (16GB) Total	81	B Handset (Power Up, Bad LCD/No Power)	859
Apple	iPhone 3G (16GB)	81	B Handset (Power Up, Bad LCD/No Power)	860
Apple	iPhone 3G (8GB) Total	40	B Handset (Power Up, Good LCD)	861
Apple	iPhone 3G (8GB)	40	B Handset (Power Up, Good LCD)	862
Apple	iPhone 3G (8GB) Total	98	B Handset (Power Up, Bad LCD/No Power)	863
Apple	iPhone 3G (8GB)	98	B Handset (Power Up, Bad LCD/No Power)	864
Apple	iPhone 3GS (16GB) Total	100	B Handset (Power Up, Good LCD)	865
Apple	iPhone 3GS (16GB)	100	B Handset (Power Up, Good LCD)	866
Apple	iPhone 3GS (16GB) Total	214	B Handset (Power Up, Bad LCD/No Power)	867
Apple	iPhone 3GS (16GB)	214	B Handset (Power Up, Bad LCD/No Power)	868
Apple	iPhone 3GS (8GB) Total	25	B Handset (Power Up, Good LCD)	869
Apple	iPhone 3GS (8GB)	25	B Handset (Power Up, Good LCD)	870
Apple	iPhone 3GS (8GB) Total	119	B Handset (Power Up, Bad LCD/No Power)	871
Apple	iPhone 3GS (8GB)	119	B Handset (Power Up, Bad LCD/No Power)	872
Samsung	i9195 Total	1	14B	879
Samsung	i9195 (IMEI Cut)	1	14B	881
Ericsson	F5121 Total	22	B Handset (Power Up, Good LCD)	891
Ericsson	F5121	21	B Handset (Power Up, Good LCD)	892
Ericsson	F5121 (With Code)	1	B Handset (Power Up, Good LCD)	893
Ericsson	F8331 Total	66	B Handset (Power Up, Good LCD)	894
Ericsson	F8331	9	B Handset (Power Up, Good LCD)	895
Ericsson	F8331 (SIM Free)	56	B Handset (Power Up, Good LCD)	896
Ericsson	F8331 (With Code)	1	B Handset (Power Up, Good LCD)	897
Nokia	640XL Total	36	B Handset (Power Up, Good LCD)	902
Nokia	640XL (With Code)	1	B Handset (Power Up, Good LCD)	903
Nokia	640XL (SIM Free)	35	B Handset (Power Up, Good LCD)	904
Nokia	635 Total	1	B Handset (Power Up, Good LCD)	905
Nokia	635 (With Code)	1	B Handset (Power Up, Good LCD)	907
Nokia	625 Total	2	B Handset (Power Up, Good LCD)	908
Nokia	625 (With Code)	2	B Handset (Power Up, Good LCD)	909
Apple	iPhone XS (256GB) SIM Free Total	1	14A	911
Apple	iPhone XS (256GB) SIM Free (Black)	1	14A (Around 10 Months Warranty)	912
Apple	iPhone XS (256GB) SIM Free Total	1	B Handset (Power Up, Good LCD)	913
Apple	iPhone XS (256GB) SIM Free (White)	1	B Handset (Power Up, Good LCD)	914
Apple	iPhone XS (64GB) SIM Free Total	1	14A	915
Apple	iPhone XS (64GB) SIM Free (White)	1	14A (Around 10 Months Warranty)	916
Apple	iPhone X (256GB) SIM Free Total	1	N. New	917
Apple	iPhone X (256GB) SIM Free (White)	1	N. New (Around 10 Months Warranty)	918
Apple	iPhone X (256GB) SIM Free Total	7	14A	919
Apple	iPhone X (256GB) SIM Free (Black)	2	14A (Good Back Glass)	920
Apple	iPhone X (256GB) SIM Free (White)	3	14A (On Warranty)	921
Apple	iPhone X (256GB) SIM Free (Black)	2	14A (On Warranty)	922
Apple	iPhone X (256GB) SIM Free Total	13	A Handset	923
Apple	iPhone X (256GB) SIM Free (Black)	1	Around 10 Months Warranty-(USA Version A-Green Label) A Handset (Broken Back Glass)	924
Apple	iPhone X (256GB) SIM Free (White)	1	On Warranty-(USA Version A-Green Label) A Handset (Good Back Glass)	925
Apple	iPhone X (256GB) SIM Free (White)	1	On Warranty-(USA Version A-Green Label) A Handset (Broken Back Glass)	926
Apple	iPhone X (256GB) SIM Free (White)	5	(USA Version A-Green Label) A Handset (Broken Back Glass)	927
Apple	iPhone X (256GB) SIM Free (Black)	5	(USA Version A-Green Label) A Handset (Broken Back Glass)	928
Apple	iPhone X (256GB) SIM Free Total	16	B Handset (No Power)	929
Apple	iPhone X (256GB) SIM Free	16	B Handset (No Power)	930
Apple	iPhone X (64GB) SIM Free Total	13	N. New	931
Apple	iPhone X (64GB) SIM Free (Black)	4	N. New (On Warranty)	932
Apple	iPhone X (64GB) SIM Free (White)	2	N. New	933
Apple	iPhone X (64GB) SIM Free (Black)	7	N. New	934
Apple	iPhone X (64GB) SIM Free Total	1	14B	935
Apple	iPhone X (64GB) SIM Free (Black)	1	14B (On Warranty)	936
Apple	iPhone X (64GB) SIM Free Total	13	B Handset (No Power)	937
Apple	iPhone X (64GB) SIM Free	13	B Handset (No Power)	938
Apple	iPhone X (256GB) (SIM Free FID) Total	1	A Handset	939
Apple	iPhone X (256GB) (SIM Free FID)	1	Part 2 A Handset	940
Apple	iPhone X (256GB) (SIM Free FID) Total	9	B Handset (Power Up, Good LCD)	941
Apple	iPhone X (256GB) (SIM Free FID)	9	Part 2 B Handset (Power Up, Good LCD)	942
Apple	iPhone X (64GB) (SIM Free FID) Total	12	B Handset (Power Up, Good LCD)	943
Apple	iPhone X (64GB) (SIM Free FID)	12	Part 2 B Handset (Power Up, Good LCD)	944
Apple	iPhone X (256GB) (SIM Free, Problematic) Total	4	A Handset	945
Apple	iPhone X (256GB) (SIM Free, Problematic)	4	Part 2 A Handset	946
Apple	iPhone X (64GB) (SIM Free, Problematic) Total	6	A Handset	947
Apple	iPhone X (64GB) (SIM Free, Problematic)	6	Part 2 A Handset	948
Apple	iPhone X (64GB) (SIM Free, Problematic) Total	10	B Handset (Power Up, Good LCD)	949
Apple	iPhone X (64GB) (SIM Free, Problematic)	10	Part 2 B Handset (Power Up, Good LCD)	950
Apple	iPhone X (256GB) (Problematic) Total	7	A Handset	951
Apple	iPhone X (256GB) (Problematic)	7	Part 2 A Handset	952
Apple	iPhone X (256GB) (Problematic) Total	1	B Handset (Power Up, Bad LCD)	953
Apple	iPhone X (256GB) (Problematic)	1	Part 2 B Handset (Power Up, Bad LCD)	954
Apple	iPhone X (64GB) (Problematic) Total	6	A Handset	955
Apple	iPhone X (64GB) (Problematic)	6	Part 2 A Handset	956
Apple	iPhone X (64GB) (Problematic) Total	5	B Handset (Power Up, Bad LCD)	957
Apple	iPhone X (64GB) (Problematic)	5	Part 2 B Handset (Power Up, Bad LCD)	958
Apple	iPhone X (256GB) iCloud lock (namely, ID lock) Total	1	B Handset (No Power)	959
Apple	iPhone X (256GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (No Power)	960
Apple	iPhone X (256GB) Total	2	A Handset	961
Apple	iPhone X (256GB)	2	Part 2 A Handset	962
Apple	iPhone X (256GB) Total	2	B Handset (Power Up, Good LCD)	963
Apple	iPhone X (256GB)	2	Part 2 B Handset (Power Up, Good LCD)	964
Apple	iPhone X (256GB) Total	3	B Handset (Power Up, Bad LCD)	965
Apple	iPhone X (256GB)	3	Part 2 B Handset (Power Up, Bad LCD)	966
Apple	iPhone 8 Plus (256GB) SIM Free Total	1	N. New	967
Apple	iPhone 8 Plus (256GB) SIM Free (Gold)	1	N. New	968
Apple	iPhone 8 Plus (256GB) SIM Free Total	9	B Handset (Power Up, Bad LCD)	972
Apple	iPhone 8 Plus (256GB) SIM Free (Gold)	5	(USA Version A) B Handset (Power Up, Bad LCD)	973
Apple	iPhone 8 Plus (256GB) SIM Free (White)	4	(USA Version A) B Handset (Power Up, Bad LCD)	974
Apple	iPhone 8 Plus (64GB) SIM Free Total	1	N. New	975
Apple	iPhone 8 Plus (64GB) SIM Free (Red)	1	N. New (On Warranty)	976
Apple	iPhone 8 Plus (64GB) SIM Free Total	2	14A	977
Apple	iPhone 8 Plus (64GB) SIM Free (Black)	1	14A (Broken Back Glass)	978
Apple	iPhone 8 Plus (64GB) SIM Free (Red)	1	14A (On Warranty)	979
Apple	iPhone 8 Plus (64GB) SIM Free Total	2	14B	980
Apple	iPhone 8 Plus (64GB) SIM Free (Black)	2	14B (On Warranty)	981
Apple	iPhone 8 Plus (64GB) SIM Free Total	5	A Handset+	982
Apple	iPhone 8 Plus (64GB) SIM Free (Gold)	1	(USA Version A) A Handset+ (Grade A)	983
Apple	iPhone 8 Plus (64GB) SIM Free (White)	1	(USA Version A) A Handset+ (Grade B)	984
Apple	iPhone 8 Plus (64GB) SIM Free (Gold)	1	(USA Version A) A Handset+ (Grade B)	985
Apple	iPhone 8 Plus (64GB) SIM Free (Black)	2	(USA Version A) A Handset+ (Grade B)	986
Apple	iPhone 8 Plus (64GB) SIM Free Total	2	B Handset (Power Up, Good LCD)	987
Apple	iPhone 8 Plus (64GB) SIM Free (Gold)	2	(USA Version A) B Handset (Power Up, Good LCD)	988
Apple	iPhone 8 Plus (64GB) SIM Free Total	8	B Handset (Power Up, Bad LCD)	989
Apple	iPhone 8 Plus (64GB) SIM Free (White)	1	B Handset (Power Up, Bad LCD)	990
Apple	iPhone 8 Plus (64GB) SIM Free (Gold)	1	B Handset (Power Up, Bad LCD)	991
Apple	iPhone 8 Plus (64GB) SIM Free (Black)	2	B Handset (Power Up, Bad LCD)	992
Apple	iPhone 8 Plus (64GB) SIM Free (Black)	1	(USA Version A) B Handset (Power Up, Bad LCD)	993

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 8 Plus (64GB) SIM Free (Red)	1	(USA Version A) B Handset (Power Up, Bad LCD)	994
Apple	iPhone 8 Plus (64GB) SIM Free (Black)	2	(USA Version S) B Handset (Power Up, Bad LCD) (RW)	995
Apple	iPhone 8 Plus (64GB) (SIM Free, Bad Fingerprint Sensor) Total	4	B Handset (Power Up, Good LCD)	996
Apple	iPhone 8 Plus (64GB) (SIM Free, Bad Fingerprint Sensor)	4	Part 2 B Handset (Power Up, Good LCD)	997
Apple	iPhone 8 Plus (256GB) (SIM Free, Problematic) Total	2	A Handset	998
Apple	iPhone 8 Plus (256GB) (SIM Free, Problematic)	2	Part 2 A Handset	999
Apple	iPhone 8 Plus (256GB) (SIM Free, Problematic) Total	17	B Handset (Power Up, Good LCD)	1000
Apple	iPhone 8 Plus (256GB) (SIM Free, Problematic)	17	Part 2 B Handset (Power Up, Good LCD)	1001
Apple	iPhone 8 Plus (256GB) (SIM Free, Problematic) Total	9	B Handset (Power Up, Bad LCD)	1002
Apple	iPhone 8 Plus (256GB) (SIM Free, Problematic)	9	Part 2 B Handset (Power Up, Bad LCD)	1003
Apple	iPhone 8 Plus (64GB) (SIM Free, Problematic) Total	15	B Handset (Power Up, Bad LCD)	1004
Apple	iPhone 8 Plus (64GB) (SIM Free, Problematic)	15	Part 2 B Handset (Power Up, Bad LCD)	1005
Apple	iPhone 8 Plus (64GB) (Problematic) Total	5	A Handset	1006
Apple	iPhone 8 Plus (64GB) (Problematic)	5	Part 2 A Handset	1007
Apple	iPhone 8 Plus (256GB) iCloud lock (namely, ID lock) Total	9	B Handset (Power Up, Good LCD)	1008
Apple	iPhone 8 Plus (256GB) iCloud lock (namely, ID lock)	9	Part 2 B Handset (Power Up, Good LCD)	1009
Apple	iPhone 8 Plus (64GB) Total	1	A Handset	1010
Apple	iPhone 8 Plus (64GB)	1	Part 2 A Handset	1011
Apple	iPhone 8 Plus (64GB) Total	1	B Handset (Power Up, Good LCD)	1012
Apple	iPhone 8 Plus (64GB)	1	Part 2 B Handset (Power Up, Good LCD)	1013
Apple	iPhone 8 (256GB) SIM Free Total	6	N. New	1014
Apple	iPhone 8 (256GB) SIM Free (Red)	6	N. New (On Warranty)	1015
Apple	iPhone 8 (256GB) SIM Free Total	1	14A	1016
Apple	iPhone 8 (256GB) SIM Free (Gold)	1	14A (Good Back Glass)	1017
Apple	iPhone 8 (256GB) SIM Free Total	13	N. New Handset	1018
Apple	iPhone 8 (256GB) SIM Free (Gold)	1	(USA Version A) N. New Handset	1019
Apple	iPhone 8 (256GB) SIM Free (Red)	1	(USA Version A) N. New Handset	1020
Apple	iPhone 8 (256GB) SIM Free (Gold)	1	(USA Version A) N. New Handset (A+)	1021
Apple	iPhone 8 (256GB) SIM Free (Black)	1	Around 10 Months Warranty-(USA Version A-Green Label) N. New Handset	1022
Apple	iPhone 8 (256GB) SIM Free (White)	1	Around 10 Months Warranty-(USA Version A-Green Label) N. New Handset	1023
Apple	iPhone 8 (256GB) SIM Free (Black)	1	On Warranty-(USA Version A-Green Label) N. New Handset	1024
Apple	iPhone 8 (256GB) SIM Free (Red)	1	On Warranty-(USA Version A-Green Label) N. New Handset	1025
Apple	iPhone 8 (256GB) SIM Free (Black)	1	(USA Version A-Green Label) N. New Handset	1026
Apple	iPhone 8 (256GB) SIM Free (Gold)	5	(USA Version A-Green Label) N. New Handset	1027
Apple	iPhone 8 (256GB) SIM Free Total	12	A Handset+	1028
Apple	iPhone 8 (256GB) SIM Free (Black)	1	Around 10 Months Warranty-(USA Version A-Green Label) A Handset+	1029
Apple	iPhone 8 (256GB) SIM Free (Gold)	1	Around 10 Months Warranty-(USA Version A-Green Label) A Handset+	1030
Apple	iPhone 8 (256GB) SIM Free (Black)	4	On Warranty-(USA Version A-Green Label) A Handset+	1031
Apple	iPhone 8 (256GB) SIM Free (Black)	4	(USA Version A-Green Label) A Handset+	1032
Apple	iPhone 8 (256GB) SIM Free (Gold)	2	(USA Version A-Green Label) A Handset+	1033
Apple	iPhone 8 (256GB) SIM Free Total	5	B Handset (Power Up, Good LCD)	1034
Apple	iPhone 8 (256GB) SIM Free (Black)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	1035
Apple	iPhone 8 (256GB) SIM Free (Gold)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	1036
Apple	iPhone 8 (256GB) SIM Free (White)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	1037
Apple	iPhone 8 (256GB) SIM Free (Black)	2	(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Broken Back Glass)	1038
Apple	iPhone 8 (256GB) SIM Free Total	3	B Handset (No Power)	1039
Apple	iPhone 8 (256GB) SIM Free	3	B Handset (No Power)	1040
Apple	iPhone 8 (64GB) SIM Free Total	3	14A	1041
Apple	iPhone 8 (64GB) SIM Free (Black)	1	14A (Good Back Glass)	1042
Apple	iPhone 8 (64GB) SIM Free (Black)	2	14A (On Warranty)	1043
Apple	iPhone 8 (64GB) SIM Free Total	8	14B	1044
Apple	iPhone 8 (64GB) SIM Free (White)	1	14B (Good Back Glass)	1045
Apple	iPhone 8 (64GB) SIM Free (Black)	2	14B (Broken Back Glass)	1046
Apple	iPhone 8 (64GB) SIM Free (White)	1	14B (Around 10 Months Warranty)	1047
Apple	iPhone 8 (64GB) SIM Free (Gold)	2	14B (On Warranty)	1048
Apple	iPhone 8 (64GB) SIM Free (Black)	1	14B (On Warranty)	1049
Apple	iPhone 8 (64GB) SIM Free (White)	1	14B (On Warranty)	1050
Apple	iPhone 8 (64GB) SIM Free Total	2	N. New Handset	1051
Apple	iPhone 8 (64GB) SIM Free (Black)	1	Around 10 Months Warranty-(USA Version A-Green Label) N. New Handset	1052
Apple	iPhone 8 (64GB) SIM Free (Gold)	1	(USA Version A-Green Label) N. New Handset	1053
Apple	iPhone 8 (64GB) SIM Free Total	18	B Handset (Power Up, Good LCD)	1063
Apple	iPhone 8 (64GB) SIM Free (Gold)	1	Around 10 Months Warranty-(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	1064
Apple	iPhone 8 (64GB) SIM Free (Gold)	4	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	1065
Apple	iPhone 8 (64GB) SIM Free (Black)	2	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	1066
Apple	iPhone 8 (64GB) SIM Free (White)	1	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	1067
Apple	iPhone 8 (64GB) SIM Free (Gold)	2	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Broken Back Glass)	1068
Apple	iPhone 8 (64GB) SIM Free (Black)	2	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Broken Back Glass)	1069
Apple	iPhone 8 (64GB) SIM Free (Red)	2	On Warranty-(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Broken Back Glass)	1070
Apple	iPhone 8 (64GB) SIM Free (Black)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Good Back Glass)	1071
Apple	iPhone 8 (64GB) SIM Free (White)	3	(USA Version A-Green Label) B Handset (Power Up, Good LCD) (Broken Back Glass)	1072
Apple	iPhone 8 (64GB) SIM Free Total	7	B Handset (No Power)	1073
Apple	iPhone 8 (64GB) SIM Free	7	B Handset (No Power)	1074
Apple	iPhone 8 (64GB) (SIM Free, Bad Fingerprint Sensor) Total	5	A Handset	1075
Apple	iPhone 8 (64GB) (SIM Free, Bad Fingerprint Sensor)	5	Part 2 A Handset	1076
Apple	iPhone 8 (64GB) (SIM Free, Bad Fingerprint Sensor) Total	10	B Handset (Power Up, Good LCD)	1077
Apple	iPhone 8 (64GB) (SIM Free, Bad Fingerprint Sensor)	10	Part 2 B Handset (Power Up, Good LCD)	1078
Apple	iPhone 8 (256GB) (SIM Free, Problematic) Total	2	A Handset	1079
Apple	iPhone 8 (256GB) (SIM Free, Problematic)	2	Part 2 A Handset	1080
Apple	iPhone 8 (256GB) (SIM Free, Problematic) Total	4	B Handset (Power Up, Good LCD)	1081
Apple	iPhone 8 (256GB) (SIM Free, Problematic)	4	Part 2 B Handset (Power Up, Good LCD)	1082
Apple	iPhone 8 (256GB) (SIM Free, Problematic) Total	18	B Handset (Power Up, Bad LCD)	1083
Apple	iPhone 8 (256GB) (SIM Free, Problematic)	18	Part 2 B Handset (Power Up, Bad LCD)	1084
Apple	iPhone 8 (64GB) (SIM Free, Problematic) Total	17	A Handset	1085
Apple	iPhone 8 (64GB) (SIM Free, Problematic)	17	Part 2 A Handset	1086
Apple	iPhone 8 (256GB) iCloud lock (namely, ID lock) Total	2	B Handset (Power Up, Good LCD)	1089
Apple	iPhone 8 (256GB) iCloud lock (namely, ID lock)	2	Part 2 B Handset (Power Up, Good LCD)	1090
Apple	iPhone 8 (256GB) iCloud lock (namely, ID lock) Total	8	B Handset (Power Up, Bad LCD)	1091
Apple	iPhone 8 (256GB) iCloud lock (namely, ID lock)	8	Part 2 B Handset (Power Up, Bad LCD)	1092
Apple	iPhone 8 (64GB) iCloud lock (namely, ID lock) Total	7	A Handset	1093
Apple	iPhone 8 (64GB) iCloud lock (namely, ID lock)	7	Part 2 A Handset	1094
Apple	iPhone 8 (64GB) iCloud lock (namely, ID lock) Total	2	B Handset (Power Up, Good LCD)	1095
Apple	iPhone 8 (64GB) iCloud lock (namely, ID lock)	2	Part 2 B Handset (Power Up, Good LCD)	1096
Apple	iPhone 8 (64GB) iCloud lock (namely, ID lock) Total	5	B Handset (No Power)	1097
Apple	iPhone 8 (64GB) iCloud lock (namely, ID lock)	5	Part 2 B Handset (No Power)	1098
Apple	iPhone 8 (64GB) Total	3	B Handset (Power Up, Bad LCD)	1099
Apple	iPhone 8 (64GB)	3	Part 2 B Handset (Power Up, Bad LCD)	1100
Apple	iPhone 7 Plus (128GB) SIM Free Total	4	14A	1101
Apple	iPhone 7 Plus (128GB) SIM Free (Jet Black)	1	14A	1102
Apple	iPhone 7 Plus (128GB) SIM Free (Black)	2	14A	1103
Apple	iPhone 7 Plus (128GB) SIM Free (Red)	1	14A	1104
Apple	iPhone 7 Plus (128GB) SIM Free Total	1	B Handset (Power Up, Good LCD)	1110
Apple	iPhone 7 Plus (128GB) SIM Free (Black)	1	(USA Version A) B Handset (Power Up, Good LCD)	1111
Apple	iPhone 7 Plus (256GB) SIM Free Total	1	N. New Handset	1114
Apple	iPhone 7 Plus (256GB) SIM Free (Gold)	1	(USA Version A) N. New Handset	1115
Apple	iPhone 7 Plus (256GB) SIM Free Total	1	A Handset+	1116
Apple	iPhone 7 Plus (256GB) SIM Free (Black)	1	(USA Version A-Green Label, Grade B) A Handset+	1117
Apple	iPhone 7 Plus (32GB) SIM Free Total	9	14A	1118
Apple	iPhone 7 Plus (32GB) SIM Free (Jet Black)	1	14A (On Warranty)	1119
Apple	iPhone 7 Plus (32GB) SIM Free (Rose Gold)	2	14A	1120
Apple	iPhone 7 Plus (32GB) SIM Free (Black)	5	14A	1121
Apple	iPhone 7 Plus (32GB) SIM Free (Jet Black)	1	14A	1122
Apple	iPhone 7 Plus (32GB) SIM Free Total	3	14B	1123
Apple	iPhone 7 Plus (32GB) SIM Free (Gold)	1	14B	1124
Apple	iPhone 7 Plus (32GB) SIM Free (Black)	2	14B	1125
Apple	iPhone 7 Plus (32GB) SIM Free Total	6	A Handset	1126
Apple	iPhone 7 Plus (32GB) SIM Free (Gold)	3	A Handset	1127
Apple	iPhone 7 Plus (32GB) SIM Free (Rose Gold)	1	A Handset	1128
Apple	iPhone 7 Plus (32GB) SIM Free (Gold)	1	(USA Version A-Green Label, Grade B) A Handset	1129
Apple	iPhone 7 Plus (32GB) SIM Free (Rose Gold)	1	(USA Version A-Green Label, Grade B) A Handset	1130
Apple	iPhone 7 Plus (128GB) (SIM Free, Bad Fingerprint Sensor) Total	3	A Handset	1131

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 7 Plus (128GB) (SIM Free, Bad Fingerprint Sensor)	3	Part 2 A Handset	1132
Apple	iPhone 7 Plus (256GB) (SIM Free, Bad Fingerprint Sensor) Total	9	B Handset (Power Up, Good LCD)	1135
Apple	iPhone 7 Plus (256GB) (SIM Free, Bad Fingerprint Sensor)	9	Part 2 B Handset (Power Up, Good LCD)	1136
Apple	iPhone 7 Plus (128GB) (SIM Free, Problematic) Total	1	A Handset	1137
Apple	iPhone 7 Plus (128GB) (SIM Free, Problematic)	1	Part 2 A Handset	1138
Apple	iPhone 7 Plus (256GB) (SIM Free, Problematic) Total	5	A Handset	1139
Apple	iPhone 7 Plus (256GB) (SIM Free, Problematic)	5	Part 2 A Handset	1140
Apple	iPhone 7 Plus (32GB) (SIM Free, Problematic) Total	16	B Handset (Power Up, Good LCD)	1141
Apple	iPhone 7 Plus (32GB) (SIM Free, Problematic)	16	Part 2 B Handset (Power Up, Good LCD)	1142
Apple	iPhone 7 Plus (128GB) (Problematic) Total	2	A Handset	1143
Apple	iPhone 7 Plus (128GB) (Problematic)	2	Part 2 A Handset	1144
Apple	iPhone 7 Plus (128GB) (Problematic) Total	18	B Handset (Power Up, Good LCD)	1145
Apple	iPhone 7 Plus (128GB) (Problematic)	18	Part 2 B Handset (Power Up, Good LCD)	1146
Apple	iPhone 7 Plus (128GB) (Problematic) Total	10	B Handset (Power Up, Bad LCD)	1147
Apple	iPhone 7 Plus (128GB) (Problematic)	10	Part 2 B Handset (Power Up, Bad LCD)	1148
Apple	iPhone 7 Plus (256GB) (Problematic) Total	3	A Handset	1149
Apple	iPhone 7 Plus (256GB) (Problematic)	3	Part 2 A Handset	1150
Apple	iPhone 7 Plus (256GB) (Problematic) Total	1	B Handset (Power Up, Good LCD)	1151
Apple	iPhone 7 Plus (256GB) (Problematic)	1	Part 2 B Handset (Power Up, Good LCD)	1152
Apple	iPhone 7 Plus (32GB) (Problematic) Total	8	A Handset	1153
Apple	iPhone 7 Plus (32GB) (Problematic)	8	Part 2 A Handset	1154
Apple	iPhone 7 Plus (32GB) (Problematic) Total	2	B Handset (Power Up, Bad LCD)	1155
Apple	iPhone 7 Plus (32GB) (Problematic)	2	Part 2 B Handset (Power Up, Bad LCD)	1156
Apple	iPhone 7 Plus (128GB) iCloud lock (namely, ID lock) Total	1	A Handset	1157
Apple	iPhone 7 Plus (128GB) iCloud lock (namely, ID lock)	1	Part 2 A Handset	1158
Apple	iPhone 7 Plus (128GB) iCloud lock (namely, ID lock) Total	6	B Handset (Power Up, Good LCD)	1159
Apple	iPhone 7 Plus (128GB) iCloud lock (namely, ID lock)	6	Part 2 B Handset (Power Up, Good LCD)	1160
Apple	iPhone 7 Plus (128GB) iCloud lock (namely, ID lock) Total	1	B Handset (No Power)	1161
Apple	iPhone 7 Plus (128GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (No Power)	1162
Apple	iPhone 7 Plus (256GB) iCloud lock (namely, ID lock) Total	2	B Handset (Power Up, Good LCD)	1163
Apple	iPhone 7 Plus (256GB) iCloud lock (namely, ID lock)	2	Part 2 B Handset (Power Up, Good LCD)	1164
Apple	iPhone 7 Plus (256GB) iCloud lock (namely, ID lock) Total	2	B Handset (Power Up, Bad LCD)	1165
Apple	iPhone 7 Plus (256GB) iCloud lock (namely, ID lock)	2	Part 2 B Handset (Power Up, Bad LCD)	1166
Apple	iPhone 7 Plus (32GB) iCloud lock (namely, ID lock) Total	1	B Handset (No Power)	1169
Apple	iPhone 7 Plus (32GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (No Power)	1170
Apple	iPhone 7 Plus (128GB) Total	5	B Handset (Power Up, Bad LCD)	1171
Apple	iPhone 7 Plus (128GB) (Black)	1	B Handset (Power Up, Bad LCD)	1172
Apple	iPhone 7 Plus (128GB)	4	Part 2 B Handset (Power Up, Bad LCD)	1173
Apple	iPhone 7 Plus (128GB) Total	4	A Handset	1174
Apple	iPhone 7 Plus (128GB)	4	Part 2 A Handset	1175
Apple	iPhone 7 Plus (128GB) Total	19	B Handset (Power Up, Good LCD)	1176
Apple	iPhone 7 Plus (128GB)	19	Part 2 B Handset (Power Up, Good LCD)	1177
Apple	iPhone 7 Plus (128GB) Total	1	B Handset (No Power)	1178
Apple	iPhone 7 Plus (128GB)	1	Part 2 B Handset (No Power)	1179
Apple	iPhone 7 Plus (32GB) Total	9	A Handset	1182
Apple	iPhone 7 Plus (32GB)	9	Part 2 A Handset	1183
Apple	iPhone 7 Plus (32GB) Total	9	B Handset (Power Up, Good LCD)	1184
Apple	iPhone 7 Plus (32GB)	9	Part 2 B Handset (Power Up, Good LCD)	1185
Apple	iPhone 7 Plus (32GB) Total	4	B Handset (Power Up, Bad LCD)	1186
Apple	iPhone 7 Plus (32GB)	4	Part 2 B Handset (Power Up, Bad LCD)	1187
Apple	iPhone 7 Plus (32GB) Total	1	B Handset (No Power)	1188
Apple	iPhone 7 Plus (32GB)	1	Part 2 B Handset (No Power)	1189
Apple	iPhone 7 (128GB) SIM Free Total	2	14B	1190
Apple	iPhone 7 (128GB) SIM Free (Black)	2	14B	1191
Apple	iPhone 7 (256GB) SIM Free Total	6	N. New Handset	1194
Apple	iPhone 7 (256GB) SIM Free (Jet Black)	1	(USA Version A-Green Label, Grade B) N. New Handset	1195
Apple	iPhone 7 (256GB) SIM Free (Black)	1	(USA Version A-Green Label) N. New Handset	1196
Apple	iPhone 7 (256GB) SIM Free (Rose Gold)	2	(USA Version A-Green Label) N. New Handset	1197
Apple	iPhone 7 (256GB) SIM Free (Red)	1	(USA Version A-Green Label) N. New Handset	1198
Apple	iPhone 7 (256GB) SIM Free (Rose Gold)	1	(USA T Version) N. New Handset	1199
Apple	iPhone 7 (256GB) SIM Free Total	8	A Handset+	1200
Apple	iPhone 7 (256GB) SIM Free (Black)	3	(USA Version A) A Handset+	1201
Apple	iPhone 7 (256GB) SIM Free (White)	2	(USA Version A-Green Label) A Handset+	1202
Apple	iPhone 7 (256GB) SIM Free (Jet Black)	1	(USA Version A-Green Label, Grade B) A Handset+	1203
Apple	iPhone 7 (256GB) SIM Free (Rose Gold)	2	(USA Version A-Green Label, Grade B) A Handset+	1204
Apple	iPhone 7 (256GB) SIM Free Total	18	B Handset (Power Up, Bad LCD)	1205
Apple	iPhone 7 (256GB) SIM Free (Jet Black)	2	(USA Version A) B Handset (Power Up, Bad LCD)	1206
Apple	iPhone 7 (256GB) SIM Free (Black)	2	(USA Version A) B Handset (Power Up, Bad LCD)	1207
Apple	iPhone 7 (256GB) SIM Free (White)	1	(USA Version A) B Handset (Power Up, Bad LCD)	1208
Apple	iPhone 7 (256GB) SIM Free (Rose Gold)	3	(USA Version A) B Handset (Power Up, Bad LCD)	1209
Apple	iPhone 7 (256GB) SIM Free (Gold)	1	(USA Version A) B Handset (Power Up, Bad LCD)	1210
Apple	iPhone 7 (256GB) SIM Free (Red)	1	(USA Version A) B Handset (Power Up, Bad LCD)	1211
Apple	iPhone 7 (256GB) SIM Free (Jet Black)	2	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1212
Apple	iPhone 7 (256GB) SIM Free (Black)	2	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1213
Apple	iPhone 7 (256GB) SIM Free (Gold)	1	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1214
Apple	iPhone 7 (256GB) SIM Free (Red)	1	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1215
Apple	iPhone 7 (256GB) SIM Free (Black)	2	(USA Version S) B Handset (Power Up, Bad LCD)	1216
Apple	iPhone 7 (256GB) SIM Free Total	2	B Handset (No Power)	1217
Apple	iPhone 7 (256GB) SIM Free	2	B Handset (No Power)	1218
Apple	iPhone 7 (32GB) SIM Free Total	3	N. New	1219
Apple	iPhone 7 (32GB) SIM Free (Black)	2	N. New (Around 10 Months Warranty)	1220
Apple	iPhone 7 (32GB) SIM Free (Jet Black)	1	N. New	1221
Apple	iPhone 7 (32GB) SIM Free Total	2	14A	1222
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	2	14A	1223
Apple	iPhone 7 (32GB) SIM Free Total	2	14B	1224
Apple	iPhone 7 (32GB) SIM Free (Black)	1	14B	1225
Apple	iPhone 7 (32GB) SIM Free (Rose Gold)	1	14B (On Warranty)	1226
Apple	iPhone 7 (128GB) (SIM Free, Bad Fingerprint Sensor) Total	9	B Handset (Power Up, Good LCD)	1229
Apple	iPhone 7 (128GB) (SIM Free, Bad Fingerprint Sensor)	9	Part 2 B Handset (Power Up, Good LCD)	1230
Apple	iPhone 7 (256GB) (SIM Free, Bad Fingerprint Sensor) Total	4	A Handset	1231
Apple	iPhone 7 (256GB) (SIM Free, Bad Fingerprint Sensor)	4	Part 2 A Handset	1232
Apple	iPhone 7 (256GB) (SIM Free, Bad Fingerprint Sensor) Total	2	B Handset (Power Up, Good LCD)	1233
Apple	iPhone 7 (256GB) (SIM Free, Bad Fingerprint Sensor)	2	Part 2 B Handset (Power Up, Good LCD)	1234
Apple	iPhone 7 (32GB) (SIM Free, Bad Fingerprint Sensor) Total	4	B Handset (Power Up, Good LCD)	1235
Apple	iPhone 7 (32GB) (SIM Free, Bad Fingerprint Sensor)	4	Part 2 B Handset (Power Up, Good LCD)	1236
Apple	iPhone 7 (128GB) (SIM Free, Problematic) Total	15	A Handset	1237
Apple	iPhone 7 (128GB) (SIM Free, Problematic)	15	Part 2 A Handset	1238
Apple	iPhone 7 (256GB) (SIM Free, Problematic) Total	5	A Handset	1239
Apple	iPhone 7 (256GB) (SIM Free, Problematic)	5	Part 2 A Handset	1240
Apple	iPhone 7 (256GB) (SIM Free, Problematic) Total	5	B Handset (Power Up, Good LCD)	1241
Apple	iPhone 7 (256GB) (SIM Free, Problematic)	5	Part 2 B Handset (Power Up, Good LCD)	1242
Apple	iPhone 7 (256GB) (SIM Free, Problematic) Total	6	B Handset (Power Up, Bad LCD)	1243
Apple	iPhone 7 (256GB) (SIM Free, Problematic)	6	Part 2 B Handset (Power Up, Bad LCD)	1244
Apple	iPhone 7 (128GB) (Problematic) Total	3	A Handset	1245
Apple	iPhone 7 (128GB) (Problematic)	3	Part 2 A Handset	1246
Apple	iPhone 7 (128GB) (Problematic) Total	12	B Handset (Power Up, Good LCD)	1247
Apple	iPhone 7 (128GB) (Problematic)	12	Part 2 B Handset (Power Up, Good LCD)	1248
Apple	iPhone 7 (128GB) (Problematic) Total	6	B Handset (Power Up, Bad LCD)	1249
Apple	iPhone 7 (128GB) (Problematic)	6	Part 2 B Handset (Power Up, Bad LCD)	1250
Apple	iPhone 7 (256GB) (Problematic) Total	1	B Handset (Power Up, Bad LCD)	1251
Apple	iPhone 7 (256GB) (Problematic)	1	Part 2 B Handset (Power Up, Bad LCD)	1252
Apple	iPhone 7 (32GB) (Problematic) Total	1	B Handset (Power Up, Good LCD)	1253
Apple	iPhone 7 (32GB) (Problematic)	1	Part 2 B Handset (Power Up, Good LCD)	1254
Apple	iPhone 7 (128GB) iCloud lock (namely, ID lock) Total	3	A Handset	1255
Apple	iPhone 7 (128GB) iCloud lock (namely, ID lock)	3	Part 2 A Handset	1256
Apple	iPhone 7 (128GB) iCloud lock (namely, ID lock) Total	8	B Handset (No Power)	1257
Apple	iPhone 7 (128GB) iCloud lock (namely, ID lock)	8	Part 2 B Handset (No Power)	1258
Apple	iPhone 7 (256GB) iCloud lock (namely, ID lock) Total	1	B Handset (Power Up, Bad LCD)	1261
Apple	iPhone 7 (256GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Bad LCD)	1262
Apple	iPhone 7 (32GB) iCloud lock (namely, ID lock) Total	8	A Handset	1263

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 7 (32GB) iCloud lock (namely, ID lock)	8	Part 2 A Handset	1264
Apple	iPhone 7 (32GB) iCloud lock (namely, ID lock) Total	8	B Handset (No Power)	1265
Apple	iPhone 7 (32GB) iCloud lock (namely, ID lock)	8	Part 2 B Handset (No Power)	1266
Apple	iPhone 7 (128GB) Total	1	B Handset (Power Up, Good LCD)	1269
Apple	iPhone 7 (128GB)	1	Part 2 B Handset (Power Up, Good LCD)	1270
Apple	iPhone 7 (128GB) Total	2	B Handset (Power Up, Bad LCD)	1271
Apple	iPhone 7 (128GB)	2	Part 2 B Handset (Power Up, Bad LCD)	1272
Apple	iPhone 7 (32GB) Total	7	A Handset	1273
Apple	iPhone 7 (32GB)	7	Part 2 A Handset	1274
Apple	iPhone 7 (32GB) Total	1	B Handset (Power Up, Good LCD)	1275
Apple	iPhone 7 (32GB)	1	Part 2 B Handset (Power Up, Good LCD)	1276
Apple	iPhone 7 (32GB) Total	6	B Handset (Power Up, Bad LCD)	1277
Apple	iPhone 7 (32GB)	6	Part 2 B Handset (Power Up, Bad LCD)	1278
Apple	iPhone 6s Plus (128GB) SIM Free Total	2	B Handset (No Power)	1279
Apple	iPhone 6s Plus (128GB) SIM Free	2	B Handset (No Power)	1280
Apple	iPhone 6s Plus (16GB) SIM Free Total	10	14A	1281
Apple	iPhone 6s Plus (16GB) SIM Free (Gold)	10	14A	1282
Apple	iPhone 6s Plus (16GB) SIM Free Total	5	B Handset (No Power)	1287
Apple	iPhone 6s Plus (16GB) SIM Free	5	B Handset (No Power)	1288
Apple	iPhone 6s Plus (32GB) SIM Free Total	2	N. New	1289
Apple	iPhone 6s Plus (32GB) SIM Free (Black)	1	N. New (On Warranty)	1290
Apple	iPhone 6s Plus (32GB) SIM Free (Black)	1	N. New	1291
Apple	iPhone 6s Plus (32GB) SIM Free Total	1	14B	1292
Apple	iPhone 6s Plus (32GB) SIM Free (Black)	1	14B	1293
Apple	iPhone 6s Plus (32GB) SIM Free Total	18	B Handset (Power Up, Good LCD)	1294
Apple	iPhone 6s Plus (32GB) SIM Free (Black)	8	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	1295
Apple	iPhone 6s Plus (32GB) SIM Free (Gold)	3	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	1296
Apple	iPhone 6s Plus (32GB) SIM Free (Rose Gold)	7	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	1297
Apple	iPhone 6s Plus (32GB) SIM Free Total	1	B Handset (No Power)	1298
Apple	iPhone 6s Plus (32GB) SIM Free	1	B Handset (No Power)	1299
Apple	iPhone 6s Plus (64GB) SIM Free Total	1	14A	1300
Apple	iPhone 6s Plus (64GB) SIM Free (Black)	1	14A	1301
Apple	iPhone 6s Plus (64GB) SIM Free Total	9	B Handset (No Power)	1302
Apple	iPhone 6s Plus (64GB) SIM Free	9	B Handset (No Power)	1303
Apple	iPhone 6s Plus (128GB) (SIM Free, Bad Fingerprint Sensor) Total	2	A Handset	1304
Apple	iPhone 6s Plus (128GB) (SIM Free, Bad Fingerprint Sensor)	2	Part 2 A Handset	1305
Apple	iPhone 6s Plus (128GB) (SIM Free, Bad Fingerprint Sensor) Total	4	B Handset (Power Up, Good LCD)	1306
Apple	iPhone 6s Plus (128GB) (SIM Free, Bad Fingerprint Sensor)	4	Part 2 B Handset (Power Up, Good LCD)	1307
Apple	iPhone 6s Plus (16GB) (SIM Free, Bad Fingerprint Sensor) Total	5	A Handset	1308
Apple	iPhone 6s Plus (16GB) (SIM Free, Bad Fingerprint Sensor)	5	Part 2 A Handset	1309
Apple	iPhone 6s Plus (16GB) (SIM Free, Bad Fingerprint Sensor) Total	2	B Handset (Power Up, Good LCD)	1310
Apple	iPhone 6s Plus (16GB) (SIM Free, Bad Fingerprint Sensor)	2	Part 2 B Handset (Power Up, Good LCD)	1311
Apple	iPhone 6s Plus (32GB) (SIM Free, Bad Fingerprint Sensor) Total	3	A Handset	1312
Apple	iPhone 6s Plus (32GB) (SIM Free, Bad Fingerprint Sensor)	3	Part 2 A Handset	1313
Apple	iPhone 6s Plus (128GB) (SIM Free, Problematic) Total	1	A Handset	1318
Apple	iPhone 6s Plus (128GB) (SIM Free, Problematic)	1	Part 2 A Handset	1319
Apple	iPhone 6s Plus (128GB) (SIM Free, Problematic) Total	2	B Handset (Power Up, Good LCD)	1320
Apple	iPhone 6s Plus (128GB) (SIM Free, Problematic)	2	Part 2 B Handset (Power Up, Good LCD)	1321
Apple	iPhone 6s Plus (128GB) (SIM Free, Problematic) Total	4	B Handset (Power Up, Bad LCD)	1322
Apple	iPhone 6s Plus (128GB) (SIM Free, Problematic)	4	Part 2 B Handset (Power Up, Bad LCD)	1323
Apple	iPhone 6s Plus (32GB) (SIM Free, Problematic) Total	8	B Handset (Power Up, Bad LCD)	1332
Apple	iPhone 6s Plus (32GB) (SIM Free, Problematic)	8	Part 2 B Handset (Power Up, Bad LCD)	1333
Apple	iPhone 6s Plus (64GB) (SIM Free, Problematic) Total	8	A Handset	1334
Apple	iPhone 6s Plus (64GB) (SIM Free, Problematic)	8	Part 2 A Handset	1335
Apple	iPhone 6s Plus (64GB) (SIM Free, Problematic) Total	9	B Handset (Power Up, Bad LCD)	1336
Apple	iPhone 6s Plus (64GB) (SIM Free, Problematic)	9	Part 2 B Handset (Power Up, Bad LCD)	1337
Apple	iPhone 6s Plus (128GB) (Problematic) Total	3	B Handset (Power Up, Bad LCD)	1338
Apple	iPhone 6s Plus (128GB) (Problematic)	3	Part 2 B Handset (Power Up, Bad LCD)	1339
Apple	iPhone 6s Plus (16GB) (Problematic) Total	5	A Handset	1340
Apple	iPhone 6s Plus (16GB) (Problematic)	5	Part 2 A Handset	1341
Apple	iPhone 6s Plus (16GB) (Problematic) Total	9	B Handset (Power Up, Good LCD)	1342
Apple	iPhone 6s Plus (16GB) (Problematic)	9	Part 2 B Handset (Power Up, Good LCD)	1343
Apple	iPhone 6s Plus (32GB) (Problematic) Total	2	A Handset	1344
Apple	iPhone 6s Plus (32GB) (Problematic)	2	Part 2 A Handset	1345
Apple	iPhone 6s Plus (32GB) (Problematic) Total	1	B Handset (Power Up, Good LCD)	1346
Apple	iPhone 6s Plus (32GB) (Problematic)	1	Part 2 B Handset (Power Up, Good LCD)	1347
Apple	iPhone 6s Plus (64GB) (Problematic) Total	3	B Handset (Power Up, Bad LCD)	1348
Apple	iPhone 6s Plus (64GB) (Problematic)	3	Part 2 B Handset (Power Up, Bad LCD)	1349
Apple	iPhone 6s Plus (128GB) iCloud lock (namely, ID lock) Total	1	A Handset	1350
Apple	iPhone 6s Plus (128GB) iCloud lock (namely, ID lock)	1	Part 2 A Handset	1351
Apple	iPhone 6s Plus (128GB) iCloud lock (namely, ID lock) Total	1	B Handset (Power Up, Good LCD)	1352
Apple	iPhone 6s Plus (128GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Good LCD)	1353
Apple	iPhone 6s Plus (128GB) iCloud lock (namely, ID lock) Total	1	B Handset (No Power)	1356
Apple	iPhone 6s Plus (128GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (No Power)	1357
Apple	iPhone 6s Plus (16GB) iCloud lock (namely, ID lock) Total	10	A Handset	1358
Apple	iPhone 6s Plus (16GB) iCloud lock (namely, ID lock)	10	Part 2 A Handset	1359
Apple	iPhone 6s Plus (16GB) iCloud lock (namely, ID lock) Total	4	B Handset (Power Up, Good LCD)	1360
Apple	iPhone 6s Plus (16GB) iCloud lock (namely, ID lock)	4	Part 2 B Handset (Power Up, Good LCD)	1361
Apple	iPhone 6s Plus (16GB) iCloud lock (namely, ID lock) Total	7	B Handset (Power Up, Bad LCD)	1362
Apple	iPhone 6s Plus (16GB) iCloud lock (namely, ID lock)	7	Part 2 B Handset (Power Up, Bad LCD)	1363
Apple	iPhone 6s Plus (16GB) iCloud lock (namely, ID lock) Total	7	B Handset (No Power)	1364
Apple	iPhone 6s Plus (16GB) iCloud lock (namely, ID lock)	7	Part 2 B Handset (No Power)	1365
Apple	iPhone 6s Plus (32GB) iCloud lock (namely, ID lock) Total	5	B Handset (Power Up, Bad LCD)	1366
Apple	iPhone 6s Plus (32GB) iCloud lock (namely, ID lock)	5	Part 2 B Handset (Power Up, Bad LCD)	1367
Apple	iPhone 6s Plus (32GB) iCloud lock (namely, ID lock) Total	2	B Handset (No Power)	1368
Apple	iPhone 6s Plus (32GB) iCloud lock (namely, ID lock)	2	Part 2 B Handset (No Power)	1369
Apple	iPhone 6s Plus (64GB) iCloud lock (namely, ID lock) Total	1	A Handset	1370
Apple	iPhone 6s Plus (64GB) iCloud lock (namely, ID lock)	1	Part 2 A Handset	1371
Apple	iPhone 6s Plus (64GB) iCloud lock (namely, ID lock) Total	1	B Handset (Power Up, Good LCD)	1372
Apple	iPhone 6s Plus (64GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Good LCD)	1373
Apple	iPhone 6s Plus (64GB) iCloud lock (namely, ID lock) Total	3	B Handset (Power Up, Bad LCD)	1374
Apple	iPhone 6s Plus (64GB) iCloud lock (namely, ID lock)	3	Part 2 B Handset (Power Up, Bad LCD)	1375
Apple	iPhone 6s Plus (64GB) iCloud lock (namely, ID lock) Total	3	B Handset (No Power)	1376
Apple	iPhone 6s Plus (64GB) iCloud lock (namely, ID lock)	3	Part 2 B Handset (No Power)	1377
Apple	iPhone 6s Plus (128GB) Total	1	B Handset (Power Up, Good LCD)	1378
Apple	iPhone 6s Plus (128GB)	1	Part 2 B Handset (Power Up, Good LCD)	1379
Apple	iPhone 6s Plus (128GB) Total	1	B Handset (No Power)	1380
Apple	iPhone 6s Plus (128GB)	1	Part 2 B Handset (No Power)	1381
Apple	iPhone 6s Plus (64GB) Total	1	A Handset	1382
Apple	iPhone 6s Plus (64GB)	1	Part 2 A Handset	1383
Apple	iPhone 6s Plus (64GB) Total	2	B Handset (Power Up, Bad LCD)	1384
Apple	iPhone 6s Plus (64GB)	2	Part 2 B Handset (Power Up, Bad LCD)	1385
Apple	iPhone 6s (128GB) SIM Free Total	2	A Handset	1386
Apple	iPhone 6s (128GB) SIM Free (White)	1	A Handset	1387
Apple	iPhone 6s (128GB) SIM Free (Gold)	1	(USA Version A-Green Label) A Handset	1388
Apple	iPhone 6s (128GB) SIM Free Total	1	B Handset (No Power)	1395
Apple	iPhone 6s (128GB) SIM Free	1	B Handset (No Power)	1396
Apple	iPhone 6s (16GB) SIM Free Total	8	14A	1397
Apple	iPhone 6s (16GB) SIM Free (Rose Gold)	8	14A	1398
Apple	iPhone 6s (16GB) SIM Free Total	12	N. New Handset	1399
Apple	iPhone 6s (16GB) SIM Free (Gold)	1	(USA Version A) N. New Handset	1400
Apple	iPhone 6s (16GB) SIM Free (Black)	3	(USA Version A-Green Label, Grade B) N. New Handset	1401
Apple	iPhone 6s (16GB) SIM Free (Gold)	3	(USA Version A-Green Label, Grade B) N. New Handset	1402
Apple	iPhone 6s (16GB) SIM Free (Rose Gold)	1	(USA Version A-Green Label, Grade B) N. New Handset	1403
Apple	iPhone 6s (16GB) SIM Free (Gold)	1	(USA Version A-Green Label) N. New Handset	1404
Apple	iPhone 6s (16GB) SIM Free (Rose Gold)	2	(USA Version A-Green Label) N. New Handset	1405
Apple	iPhone 6s (16GB) SIM Free (White)	1	(USA Version A-Green Label) N. New Handset	1406
Apple	iPhone 6s (16GB) SIM Free Total	1	A Handset+	1407
Apple	iPhone 6s (16GB) SIM Free (Black)	1	(USA Version A-Green Label, Grade B) A Handset+	1408
Apple	iPhone 6s (16GB) SIM Free Total	8	B Handset (Power Up, Good LCD)	1409

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 6s (16GB) SIM Free (Black)	2	B Handset (Power Up, Good LCD)	1410
Apple	iPhone 6s (16GB) SIM Free (Gold)	1	B Handset (Power Up, Good LCD)	1411
Apple	iPhone 6s (16GB) SIM Free (Black)	2	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	1412
Apple	iPhone 6s (16GB) SIM Free (Rose Gold)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	1413
Apple	iPhone 6s (16GB) SIM Free (White)	2	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	1414
Apple	iPhone 6s (16GB) SIM Free Total	11	B Handset (No Power)	1415
Apple	iPhone 6s (16GB) SIM Free	11	B Handset (No Power)	1416
Apple	iPhone 6s (32GB) SIM Free Total	1	14A	1417
Apple	iPhone 6s (32GB) SIM Free (Black)	1	14A	1418
Apple	iPhone 6s (32GB) SIM Free Total	3	14B	1419
Apple	iPhone 6s (32GB) SIM Free (Rose Gold)	1	14B	1420
Apple	iPhone 6s (32GB) SIM Free (Black)	1	14B (Around 10 Months Warranty)	1421
Apple	iPhone 6s (32GB) SIM Free (Gold)	1	14B (On Warranty)	1422
Apple	iPhone 6s (32GB) SIM Free Total	19	B Handset (Power Up, Bad LCD)	1423
Apple	iPhone 6s (32GB) SIM Free (Black)	8	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1424
Apple	iPhone 6s (32GB) SIM Free (White)	1	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1425
Apple	iPhone 6s (32GB) SIM Free (Rose Gold)	8	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1426
Apple	iPhone 6s (32GB) SIM Free (Gold)	2	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1427
Apple	iPhone 6s (32GB) SIM Free Total	4	B Handset (No Power)	1428
Apple	iPhone 6s (32GB) SIM Free	4	B Handset (No Power)	1429
Apple	iPhone 6s (64GB) SIM Free Total	2	N. New Handset	1430
Apple	iPhone 6s (64GB) SIM Free (Black)	1	(USA Version A-Green Label) N. New Handset	1431
Apple	iPhone 6s (64GB) SIM Free (Rose Gold)	1	(USA Version A-Green Label) N. New Handset	1432
Apple	iPhone 6s (64GB) SIM Free Total	6	B Handset (Power Up, Good LCD)	1433
Apple	iPhone 6s (64GB) SIM Free (Rose Gold)	2	(USA Version A) B Handset (Power Up, Good LCD)	1434
Apple	iPhone 6s (64GB) SIM Free (Rose Gold)	3	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	1435
Apple	iPhone 6s (64GB) SIM Free (White)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	1436
Apple	iPhone 6s (64GB) SIM Free Total	17	B Handset (No Power)	1437
Apple	iPhone 6s (64GB) SIM Free	17	B Handset (No Power)	1438
Apple	iPhone 6s (64GB) (SIM Free, Bad Fingerprint Sensor) Total	2	B Handset (Power Up, Good LCD)	1449
Apple	iPhone 6s (64GB) (SIM Free, Bad Fingerprint Sensor)	2	Part 2 B Handset (Power Up, Good LCD)	1450
Apple	iPhone 6s (16GB) (SIM Free, Problematic) Total	3	B Handset (Power Up, Bad LCD)	1459
Apple	iPhone 6s (16GB) (SIM Free, Problematic)	3	Part 2 B Handset (Power Up, Bad LCD)	1460
Apple	iPhone 6s (32GB) (SIM Free, Problematic) Total	1	B Handset (Power Up, Good LCD)	1463
Apple	iPhone 6s (32GB) (SIM Free, Problematic)	1	Part 2 B Handset (Power Up, Good LCD)	1464
Apple	iPhone 6s (64GB) (SIM Free, Problematic) Total	3	B Handset (Power Up, Good LCD)	1469
Apple	iPhone 6s (64GB) (SIM Free, Problematic)	3	Part 2 B Handset (Power Up, Good LCD)	1470
Apple	iPhone 6s (128GB) (Problematic) Total	1	B Handset (Power Up, Good LCD)	1473
Apple	iPhone 6s (128GB) (Problematic)	1	Part 2 B Handset (Power Up, Good LCD)	1474
Apple	iPhone 6s (16GB) (Problematic) Total	2	A Handset	1475
Apple	iPhone 6s (16GB) (Problematic)	2	Part 2 A Handset	1476
Apple	iPhone 6s (16GB) (Problematic) Total	2	B Handset (Power Up, Bad LCD)	1477
Apple	iPhone 6s (16GB) (Problematic)	2	Part 2 B Handset (Power Up, Bad LCD)	1478
Apple	iPhone 6s (128GB) iCloud lock (namely, ID lock) Total	1	A Handset	1479
Apple	iPhone 6s (128GB) iCloud lock (namely, ID lock)	1	Part 2 A Handset	1480
Apple	iPhone 6s (128GB) iCloud lock (namely, ID lock) Total	7	B Handset (Power Up, Bad LCD)	1483
Apple	iPhone 6s (128GB) iCloud lock (namely, ID lock)	7	Part 2 B Handset (Power Up, Bad LCD)	1484
Apple	iPhone 6s (16GB) iCloud lock (namely, ID lock) Total	9	B Handset (Power Up, Bad LCD)	1485
Apple	iPhone 6s (16GB) iCloud lock (namely, ID lock)	9	Part 2 B Handset (Power Up, Bad LCD)	1486
Apple	iPhone 6s (16GB) iCloud lock (namely, ID lock) Total	4	B Handset (No Power)	1487
Apple	iPhone 6s (16GB) iCloud lock (namely, ID lock)	4	Part 2 B Handset (No Power)	1488
Apple	iPhone 6s (32GB) iCloud lock (namely, ID lock) Total	1	A Handset	1489
Apple	iPhone 6s (32GB) iCloud lock (namely, ID lock)	1	Part 2 A Handset	1490
Apple	iPhone 6s (32GB) iCloud lock (namely, ID lock) Total	6	B Handset (Power Up, Bad LCD)	1493
Apple	iPhone 6s (32GB) iCloud lock (namely, ID lock)	6	Part 2 B Handset (Power Up, Bad LCD)	1494
Apple	iPhone 6s (32GB) iCloud lock (namely, ID lock) Total	6	B Handset (No Power)	1495
Apple	iPhone 6s (32GB) iCloud lock (namely, ID lock)	6	Part 2 B Handset (No Power)	1496
Apple	iPhone 6s (64GB) iCloud lock (namely, ID lock) Total	2	B Handset (Power Up, Good LCD)	1499
Apple	iPhone 6s (64GB) iCloud lock (namely, ID lock)	2	Part 2 B Handset (Power Up, Good LCD)	1500
Apple	iPhone 6s (64GB) iCloud lock (namely, ID lock) Total	3	B Handset (No Power)	1503
Apple	iPhone 6s (64GB) iCloud lock (namely, ID lock)	3	Part 2 B Handset (No Power)	1504
Apple	iPhone 6s (128GB) Total	1	B Handset (Power Up, Good LCD)	1505
Apple	iPhone 6s (128GB)	1	Part 2 B Handset (Power Up, Good LCD)	1506
Apple	iPhone 6s (128GB) Total	1	B Handset (No Power)	1507
Apple	iPhone 6s (128GB)	1	Part 2 B Handset (No Power)	1508
Apple	iPhone 6s (16GB) Total	4	A Handset	1509
Apple	iPhone 6s (16GB)	4	Part 2 A Handset	1510
Apple	iPhone 6s (16GB) Total	2	B Handset (No Power)	1511
Apple	iPhone 6s (16GB)	2	Part 2 B Handset (No Power)	1512
Apple	iPhone 6s (64GB) Total	1	A Handset	1515
Apple	iPhone 6s (64GB)	1	Part 2 A Handset	1516
Apple	iPhone 6s (64GB) Total	2	B Handset (Power Up, Bad LCD)	1517
Apple	iPhone 6s (64GB)	2	Part 2 B Handset (Power Up, Bad LCD)	1518
Apple	iPhone 6 Plus (128GB) SIM Free Total	1	B Handset (Power Up, Bad LCD)	1519
Apple	iPhone 6 Plus (128GB) SIM Free (Black)	1	B Handset (Power Up, Bad LCD)	1520
Apple	iPhone 6 Plus (16GB) SIM Free Total	1	N. New Handset	1521
Apple	iPhone 6 Plus (16GB) SIM Free (White)	1	N. New Handset	1522
Apple	iPhone 6 Plus (16GB) SIM Free Total	6	B Handset (Power Up, Good LCD)	1523
Apple	iPhone 6 Plus (16GB) SIM Free (White)	2	(USA Version A) B Handset (Power Up, Good LCD)	1524
Apple	iPhone 6 Plus (16GB) SIM Free (Black)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	1525
Apple	iPhone 6 Plus (16GB) SIM Free (White)	1	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	1526
Apple	iPhone 6 Plus (16GB) SIM Free (Gold)	2	(USA Version A-Green Label) B Handset (Power Up, Good LCD)	1527
Apple	iPhone 6 Plus (16GB) SIM Free Total	3	B Handset (Power Up, Bad LCD)	1528
Apple	iPhone 6 Plus (16GB) SIM Free (White)	1	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1532
Apple	iPhone 6 Plus (16GB) SIM Free (Gold)	2	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1533
Apple	iPhone 6 Plus (64GB) SIM Free Total	1	N. New Handset	1536
Apple	iPhone 6 Plus (64GB) SIM Free (Black)	1	(USA Version A-Green Label, Grade B) N. New Handset	1537
Apple	iPhone 6 Plus (64GB) SIM Free Total	10	B Handset (Power Up, Bad LCD)	1538
Apple	iPhone 6 Plus (64GB) SIM Free (Gold)	2	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1541
Apple	iPhone 6 Plus (64GB) SIM Free (Black)	6	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1542
Apple	iPhone 6 Plus (64GB) SIM Free (White)	2	(USA Version A-Green Label) B Handset (Power Up, Bad LCD)	1543
Apple	iPhone 6 Plus (128GB) (SIM Free, Bad Fingerprint Sensor) Total	1	B Handset (Power Up, Good LCD)	1546
Apple	iPhone 6 Plus (128GB) (SIM Free, Bad Fingerprint Sensor)	1	Part 2 B Handset (Power Up, Good LCD)	1547
Apple	iPhone 6 Plus (16GB) (SIM Free, Bad Fingerprint Sensor) Total	10	A Handset	1548
Apple	iPhone 6 Plus (16GB) (SIM Free, Bad Fingerprint Sensor)	10	Part 2 A Handset	1549
Apple	iPhone 6 Plus (16GB) (SIM Free, Bad Fingerprint Sensor) Total	16	B Handset (Power Up, Good LCD)	1550
Apple	iPhone 6 Plus (16GB) (SIM Free, Bad Fingerprint Sensor)	16	Part 2 B Handset (Power Up, Good LCD)	1551
Apple	iPhone 6 Plus (64GB) (SIM Free, Bad Fingerprint Sensor) Total	2	A Handset	1552
Apple	iPhone 6 Plus (64GB) (SIM Free, Bad Fingerprint Sensor)	2	Part 2 A Handset	1553
Apple	iPhone 6 Plus (64GB) (SIM Free, Bad Fingerprint Sensor) Total	1	B Handset (Power Up, Good LCD)	1554
Apple	iPhone 6 Plus (64GB) (SIM Free, Bad Fingerprint Sensor)	1	Part 2 B Handset (Power Up, Good LCD)	1555
Apple	iPhone 6 Plus (128GB) (SIM Free, Problematic) Total	3	B Handset (Power Up, Bad LCD)	1558
Apple	iPhone 6 Plus (128GB) (SIM Free, Problematic)	3	Part 2 B Handset (Power Up, Bad LCD)	1559
Apple	iPhone 6 Plus (64GB) (SIM Free, Problematic) Total	2	A Handset	1564
Apple	iPhone 6 Plus (64GB) (SIM Free, Problematic)	2	Part 2 A Handset	1565
Apple	iPhone 6 Plus (16GB) (Problematic) Total	1	B Handset (Power Up, Good LCD)	1570
Apple	iPhone 6 Plus (16GB) (Problematic)	1	Part 2 B Handset (Power Up, Good LCD)	1571
Apple	iPhone 6 Plus (16GB) (Problematic) Total	1	B Handset (Power Up, Bad LCD)	1572
Apple	iPhone 6 Plus (16GB) (Problematic)	1	Part 2 B Handset (Power Up, Bad LCD)	1573
Apple	iPhone 6 Plus (64GB) (Problematic) Total	2	A Handset	1574
Apple	iPhone 6 Plus (64GB) (Problematic)	2	Part 2 A Handset	1575
Apple	iPhone 6 Plus (64GB) (Problematic) Total	1	B Handset (Power Up, Good LCD)	1576
Apple	iPhone 6 Plus (64GB) (Problematic)	1	Part 2 B Handset (Power Up, Good LCD)	1577
Apple	iPhone 6 Plus (16GB) iCloud lock (namely, ID lock) Total	15	B Handset (Power Up, Bad LCD)	1584
Apple	iPhone 6 Plus (16GB) iCloud lock (namely, ID lock)	15	Part 2 B Handset (Power Up, Bad LCD)	1585
Apple	iPhone 6 Plus (16GB) iCloud lock (namely, ID lock) Total	6	B Handset (No Power)	1586
Apple	iPhone 6 Plus (16GB) iCloud lock (namely, ID lock)	6	Part 2 B Handset (No Power)	1587
Apple	iPhone 6 Plus (64GB) iCloud lock (namely, ID lock) Total	11	B Handset (Power Up, Good LCD)	1588
Apple	iPhone 6 Plus (64GB) iCloud lock (namely, ID lock)	11	Part 2 B Handset (Power Up, Good LCD)	1589
Apple	iPhone 6 Plus (64GB) iCloud lock (namely, ID lock) Total	4	B Handset (Power Up, Bad LCD)	1590

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 6 Plus (64GB) iCloud lock (namely, ID lock)	4	Part 2 B Handset (Power Up, Bad LCD)	1591
Apple	iPhone 6 Plus (16GB) Total	2	N. New	1594
Apple	iPhone 6 Plus (16GB)	2	Part 2 N. New	1595
Apple	iPhone 6 Plus (16GB) Total	13	B Handset (Power Up, Good LCD)	1598
Apple	iPhone 6 Plus (16GB)	13	Part 2 B Handset (Power Up, Good LCD)	1599
Apple	iPhone 6 Plus (16GB) Total	1	B Handset (Power Up, Bad LCD)	1600
Apple	iPhone 6 Plus (16GB)	1	Part 2 B Handset (Power Up, Bad LCD)	1601
Apple	iPhone 6 (16GB) SIM Free Total	3	B Handset (No Power)	1623
Apple	iPhone 6 (16GB) SIM Free (Black)	1	B Handset (No Power)	1624
Apple	iPhone 6 (16GB) SIM Free	2	B Handset (No Power)	1625
Apple	iPhone 6 (32GB) SIM Free Total	1	B Handset (Power Up, Good LCD)	1626
Apple	iPhone 6 (32GB) SIM Free (Black)	1	B Handset (Power Up, Good LCD)	1627
Apple	iPhone 6 (32GB) SIM Free Total	1	B Handset (No Power)	1630
Apple	iPhone 6 (32GB) SIM Free (Black)	1	B Handset (No Power)	1631
Apple	iPhone 6 (64GB) SIM Free Total	3	B Handset (No Power)	1639
Apple	iPhone 6 (64GB) SIM Free	3	B Handset (No Power)	1640
Apple	iPhone 6 (128GB) (SIM Free, Problematic) Total	1	A Handset	1645
Apple	iPhone 6 (128GB) (SIM Free, Problematic)	1	Part 2 A Handset	1646
Apple	iPhone 6 (32GB) (SIM Free, Problematic) Total	1	A Handset	1651
Apple	iPhone 6 (32GB) (SIM Free, Problematic)	1	Part 2 A Handset	1652
Apple	iPhone 6 (32GB) (SIM Free, Problematic) Total	1	B Handset (Power Up, Bad LCD)	1653
Apple	iPhone 6 (32GB) (SIM Free, Problematic)	1	Part 2 B Handset (Power Up, Bad LCD)	1654
Apple	iPhone 6 (16GB) (Problematic) Total	2	A Handset	1657
Apple	iPhone 6 (16GB) (Problematic)	2	Part 2 A Handset	1658
Apple	iPhone 6 (16GB) (Problematic) Total	1	B Handset (Power Up, Good LCD)	1659
Apple	iPhone 6 (16GB) (Problematic)	1	Part 2 B Handset (Power Up, Good LCD)	1660
Apple	iPhone 6 (16GB) (Problematic) Total	12	B Handset (Power Up, Bad LCD)	1661
Apple	iPhone 6 (16GB) (Problematic)	12	Part 2 B Handset (Power Up, Bad LCD)	1662
Apple	iPhone 6 (32GB) (Problematic) Total	2	B Handset (Power Up, Bad LCD)	1663
Apple	iPhone 6 (32GB) (Problematic)	2	Part 2 B Handset (Power Up, Bad LCD)	1664
Apple	iPhone 6 (128GB) iCloud lock (namely, ID lock) Total	1	B Handset (No Power)	1667
Apple	iPhone 6 (128GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (No Power)	1668
Apple	iPhone 6 (16GB) iCloud lock (namely, ID lock) Total	16	B Handset (No Power)	1669
Apple	iPhone 6 (16GB) iCloud lock (namely, ID lock)	16	Part 2 B Handset (No Power)	1670
Apple	iPhone 6 (32GB) iCloud lock (namely, ID lock) Total	17	B Handset (Power Up, Bad LCD)	1671
Apple	iPhone 6 (32GB) iCloud lock (namely, ID lock)	17	Part 2 B Handset (Power Up, Bad LCD)	1672
Apple	iPhone 6 (128GB) Total	1	B Handset (Power Up, Good LCD)	1679
Apple	iPhone 6 (128GB)	1	Part 2 B Handset (Power Up, Good LCD)	1680
Apple	iPhone 6 (16GB) Total	4	B Handset (Power Up, Bad LCD)	1681
Apple	iPhone 6 (16GB)	4	Part 2 B Handset (Power Up, Bad LCD)	1682
Apple	iPhone 6 (64GB) Total	1	B Handset (Power Up, Good LCD)	1683
Apple	iPhone 6 (64GB)	1	Part 2 B Handset (Power Up, Good LCD)	1684
Apple	iPhone 5s (16GB) SIM Free Total	8	B Handset energized with electricity	1688
Apple	iPhone 5s (16GB) SIM Free	8	B Handset energized with electricity	1689
Apple	iPhone 5s (16GB) SIM Free Total	3	B Handset (No Power)	1690
Apple	iPhone 5s (16GB) SIM Free	3	B Handset (No Power)	1691
Apple	iPhone 5s (32GB) SIM Free Total	8	B Handset (Power Up, Bad LCD)	1696
Apple	iPhone 5s (32GB) SIM Free	6	B Handset (Power Up, Bad LCD)	1697
Apple	iPhone 5s (32GB) SIM Free	2	(USA Version A) B Handset (Power Up, Bad LCD)	1698
Apple	iPhone 5s (16GB) (SIM Free, Bad Fingerprint Sensor) Total	3	B Handset (Power Up, Good LCD)	1706
Apple	iPhone 5s (16GB) (SIM Free, Bad Fingerprint Sensor)	3	Part 2 B Handset (Power Up, Good LCD)	1707
Apple	iPhone 5s (32GB) (SIM Free, Bad Fingerprint Sensor) Total	2	B Handset (Power Up, Good LCD)	1708
Apple	iPhone 5s (32GB) (SIM Free, Bad Fingerprint Sensor)	2	Part 2 B Handset (Power Up, Good LCD)	1709
Apple	iPhone 5s (16GB) (SIM Free, Problematic) Total	4	A Handset	1710
Apple	iPhone 5s (16GB) (SIM Free, Problematic)	4	Part 2 A Handset	1711
Apple	iPhone 5s (32GB) (SIM Free, Problematic) Total	1	A Handset	1712
Apple	iPhone 5s (32GB) (SIM Free, Problematic)	1	Part 2 A Handset	1713
Apple	iPhone 5s (64GB) (SIM Free, Problematic) Total	2	B Handset (Power Up, Bad LCD)	1714
Apple	iPhone 5s (64GB) (SIM Free, Problematic)	2	Part 2 B Handset (Power Up, Bad LCD)	1715
Apple	iPhone 5s (32GB) (Problematic) Total	2	A Handset	1722
Apple	iPhone 5s (32GB) (Problematic)	2	Part 2 A Handset	1723
Apple	iPhone 5s (32GB) (Problematic) Total	2	B Handset (Power Up, Bad LCD)	1724
Apple	iPhone 5s (32GB) (Problematic)	2	Part 2 B Handset (Power Up, Bad LCD)	1725
Apple	iPhone 5s (64GB) (Problematic) Total	3	A Handset	1726
Apple	iPhone 5s (64GB) (Problematic)	3	Part 2 A Handset	1727
Apple	iPhone 5s (64GB) iCloud lock (namely, ID lock) Total	5	A Handset	1730
Apple	iPhone 5s (64GB) iCloud lock (namely, ID lock)	5	Part 2 A Handset	1731
Apple	iPhone 5s (16GB) Total	4	A Handset	1732
Apple	iPhone 5s (16GB)	4	Part 2 A Handset	1733
Apple	iPhone 5s (16GB) Total	2	B Handset (Power Up, Good LCD)	1734
Apple	iPhone 5s (16GB)	2	Part 2 B Handset (Power Up, Good LCD)	1735
Apple	iPhone 5s (16GB) Total	3	B Handset (Power Up, Bad LCD)	1736
Apple	iPhone 5s (16GB)	3	Part 2 B Handset (Power Up, Bad LCD)	1737
Apple	iPhone 5s (16GB) Total	4	B Handset (No Power)	1738
Apple	iPhone 5s (16GB)	4	Part 2 B Handset (No Power)	1739
Apple	iPhone 4 (32GB) SIM Free Total	3	B Handset (Power Up, Good LCD)	1742
Apple	iPhone 4 (32GB) SIM Free	3	B Handset (Power Up, Good LCD)	1743
Apple	iPhone 4 (8GB) SIM Free Total	10	B Handset (Power Up, Good LCD)	1746
Apple	iPhone 4 (8GB) SIM Free	10	B Handset (Power Up, Good LCD)	1747
Apple	iPhone 4s (8GB) SIM Free Total	5	B Handset (Power Up, Good LCD)	1752
Apple	iPhone 4s (8GB) SIM Free	5	B Handset (Power Up, Good LCD)	1753
Apple	iPhone 5 (32GB) SIM Free Total	8	B Handset (Power Up, Good LCD)	1754
Apple	iPhone 5 (32GB) SIM Free	8	B Handset (Power Up, Good LCD)	1755
Apple	iPhone 5c (16GB) SIM Free Total	2	B Handset (No Power)	1756
Apple	iPhone 5c (16GB) SIM Free	2	B Handset (No Power)	1757
Apple	iPhone 5c (32GB) SIM Free Total	5	B Handset (Power Up, Bad LCD)	1758
Apple	iPhone 5c (32GB) SIM Free	5	B Handset (Power Up, Bad LCD)	1759
Apple	iPhone 5c (8GB) SIM Free Total	1	B Handset (No Power)	1760
Apple	iPhone 5c (8GB) SIM Free	1	B Handset (No Power)	1761
Apple	iPhone SE (32GB) SIM Free Total	1	N. New	1764
Apple	iPhone SE (32GB) SIM Free	1	N. New (Non-Active)	1765
Apple	iPhone 6 (128GB) (SIM Free, Bad Fingerprint Sensor) Total	4	B Handset (Power Up, Good LCD)	1774
Apple	iPhone 6 (128GB) (SIM Free, Bad Fingerprint Sensor)	4	Part 2 B Handset (Power Up, Good LCD)	1775
Apple	iPhone 8 (256GB) (SIM Free, Bad Fingerprint Sensor) Total	1	A Handset	1778
Apple	iPhone 8 (256GB) (SIM Free, Bad Fingerprint Sensor)	1	Part 2 A Handset	1779
Apple	iPhone 8 (256GB) (SIM Free, Bad Fingerprint Sensor) Total	4	B Handset (Power Up, Good LCD)	1780
Apple	iPhone 8 (256GB) (SIM Free, Bad Fingerprint Sensor)	4	Part 2 B Handset (Power Up, Good LCD)	1781
Apple	iPhone 4 (32GB) (SIM Free, Problematic) Total	3	A Handset	1782
Apple	iPhone 4 (32GB) (SIM Free, Problematic)	3	Part 2 A Handset	1783
Apple	iPhone 4 (32GB) (SIM Free, Problematic) Total	10	B Handset (Power Up, Good LCD)	1784
Apple	iPhone 4 (32GB) (SIM Free, Problematic)	10	Part 2 B Handset (Power Up, Good LCD)	1785
Apple	iPhone 4s (16GB) (SIM Free, Problematic) Total	4	A Handset	1786
Apple	iPhone 4s (16GB) (SIM Free, Problematic)	4	Part 2 A Handset	1787
Apple	iPhone 4s (16GB) (SIM Free, Problematic) Total	2	B Handset (Power Up, Good LCD)	1788
Apple	iPhone 4s (16GB) (SIM Free, Problematic)	2	Part 2 B Handset (Power Up, Good LCD)	1789
Apple	iPhone 4s (32GB) (SIM Free, Problematic) Total	4	A Handset	1790
Apple	iPhone 4s (32GB) (SIM Free, Problematic)	4	Part 2 A Handset	1791
Apple	iPhone 4s (32GB) (SIM Free, Problematic) Total	14	B Handset (Power Up, Good LCD)	1792
Apple	iPhone 4s (32GB) (SIM Free, Problematic)	14	Part 2 B Handset (Power Up, Good LCD)	1793
Apple	iPhone 4s (64GB) (SIM Free, Problematic) Total	2	A Handset	1794
Apple	iPhone 4s (64GB) (SIM Free, Problematic)	2	Part 2 A Handset	1795
Apple	iPhone 4s (64GB) (SIM Free, Problematic) Total	7	B Handset (Power Up, Good LCD)	1796
Apple	iPhone 4s (64GB) (SIM Free, Problematic)	7	Part 2 B Handset (Power Up, Good LCD)	1797
Apple	iPhone 4s (8GB) (SIM Free, Problematic) Total	8	A Handset	1798
Apple	iPhone 4s (8GB) (SIM Free, Problematic)	8	Part 2 A Handset	1799
Apple	iPhone 4s (8GB) (SIM Free, Problematic) Total	4	B Handset (Power Up, Good LCD)	1800
Apple	iPhone 4s (8GB) (SIM Free, Problematic)	4	Part 2 B Handset (Power Up, Good LCD)	1801
Apple	iPhone 4s (8GB) (SIM Free, Problematic) Total	19	B Handset (Power Up, Bad LCD)	1802
Apple	iPhone 4s (8GB) (SIM Free, Problematic)	19	Part 2 B Handset (Power Up, Bad LCD)	1803
Apple	iPhone 5 (16GB) (SIM Free, Problematic) Total	10	B Handset (Power Up, Good LCD)	1804

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 5 (16GB) (SIM Free, Problematic)	10	Part 2 B Handset (Power Up, Good LCD)	1805
Apple	iPhone 5 (16GB) (SIM Free, Problematic) Total	10	B Handset (Power Up, Bad LCD)	1806
Apple	iPhone 5 (16GB) (SIM Free, Problematic)	10	Part 2 B Handset (Power Up, Bad LCD)	1807
Apple	iPhone 5 (32GB) (SIM Free, Problematic) Total	1	B Handset (Power Up, Good LCD)	1808
Apple	iPhone 5 (32GB) (SIM Free, Problematic)	1	Part 2 B Handset (Power Up, Good LCD)	1809
Apple	iPhone 5 (32GB) (SIM Free, Problematic) Total	2	B Handset (Power Up, Bad LCD)	1810
Apple	iPhone 5 (32GB) (SIM Free, Problematic)	2	Part 2 B Handset (Power Up, Bad LCD)	1811
Apple	iPhone 5 (64GB) (SIM Free, Problematic) Total	2	B Handset (Power Up, Good LCD)	1814
Apple	iPhone 5 (64GB) (SIM Free, Problematic)	2	Part 2 B Handset (Power Up, Good LCD)	1815
Apple	iPhone 5c (16GB) (SIM Free, Problematic) Total	8	B Handset (Power Up, Bad LCD)	1816
Apple	iPhone 5c (16GB) (SIM Free, Problematic)	8	Part 2 B Handset (Power Up, Bad LCD)	1817
Apple	iPhone 5c (8GB) (SIM Free, Problematic) Total	3	B Handset (Power Up, Good LCD)	1818
Apple	iPhone 5c (8GB) (SIM Free, Problematic)	3	Part 2 B Handset (Power Up, Good LCD)	1819
Apple	iPhone 5c (8GB) (SIM Free, Problematic) Total	2	B Handset (Power Up, Bad LCD)	1820
Apple	iPhone 5c (8GB) (SIM Free, Problematic)	2	Part 2 B Handset (Power Up, Bad LCD)	1821
Apple	iPhone SE (16GB) (SIM Free, Problematic) Total	4	B Handset (Power Up, Bad LCD)	1822
Apple	iPhone SE (16GB) (SIM Free, Problematic)	4	Part 2 B Handset (Power Up, Bad LCD)	1823
Apple	iPhone SE (32GB) (SIM Free, Problematic) Total	1	B Handset (Power Up, Bad LCD)	1824
Apple	iPhone SE (32GB) (SIM Free, Problematic)	1	Part 2 B Handset (Power Up, Bad LCD)	1825
Apple	iPhone SE (64GB) (SIM Free, Problematic) Total	3	B Handset (Power Up, Bad LCD)	1826
Apple	iPhone SE (64GB) (SIM Free, Problematic)	3	Part 2 B Handset (Power Up, Bad LCD)	1827
Apple	iPhone 4 (16GB) (Problematic) Total	12	A Handset	1828
Apple	iPhone 4 (16GB) (Problematic)	12	Part 2 A Handset	1829
Apple	iPhone 4 (32GB) (Problematic) Total	4	A Handset	1830
Apple	iPhone 4 (32GB) (Problematic)	4	Part 2 A Handset	1831
Apple	iPhone 4 (32GB) (Problematic) Total	16	B Handset (Power Up, Good LCD)	1832
Apple	iPhone 4 (32GB) (Problematic)	16	Part 2 B Handset (Power Up, Good LCD)	1833
Apple	iPhone 4s (16GB) (Problematic) Total	7	B Handset (Power Up, Bad LCD)	1834
Apple	iPhone 4s (16GB) (Problematic)	7	Part 2 B Handset (Power Up, Bad LCD)	1835
Apple	iPhone 4s (32GB) (Problematic) Total	1	A Handset	1836
Apple	iPhone 4s (32GB) (Problematic)	1	Part 2 A Handset	1837
Apple	iPhone 4s (32GB) (Problematic) Total	5	B Handset (Power Up, Good LCD)	1838
Apple	iPhone 4s (32GB) (Problematic)	5	Part 2 B Handset (Power Up, Good LCD)	1839
Apple	iPhone 4s (64GB) (Problematic) Total	3	B Handset (Power Up, Good LCD)	1840
Apple	iPhone 4s (64GB) (Problematic)	3	Part 2 B Handset (Power Up, Good LCD)	1841
Apple	iPhone 5 (16GB) (Problematic) Total	7	B Handset (Power Up, Good LCD)	1842
Apple	iPhone 5 (16GB) (Problematic)	7	Part 2 B Handset (Power Up, Good LCD)	1843
Apple	iPhone 5 (32GB) (Problematic) Total	1	B Handset (Power Up, Good LCD)	1844
Apple	iPhone 5 (32GB) (Problematic)	1	Part 2 B Handset (Power Up, Good LCD)	1845
Apple	iPhone 5 (32GB) (Problematic) Total	2	B Handset (Power Up, Bad LCD)	1846
Apple	iPhone 5 (32GB) (Problematic)	2	Part 2 B Handset (Power Up, Bad LCD)	1847
Apple	iPhone 5 (64GB) (Problematic) Total	2	B Handset (Power Up, Good LCD)	1848
Apple	iPhone 5 (64GB) (Problematic)	2	Part 2 B Handset (Power Up, Good LCD)	1849
Apple	iPhone 5c (16GB) (Problematic) Total	1	B Handset (Power Up, Good LCD)	1850
Apple	iPhone 5c (16GB) (Problematic)	1	Part 2 B Handset (Power Up, Good LCD)	1851
Apple	iPhone 5c (16GB) (Problematic) Total	1	B Handset (Power Up, Bad LCD)	1852
Apple	iPhone 5c (16GB) (Problematic)	1	Part 2 B Handset (Power Up, Bad LCD)	1853
Apple	iPhone 5c (32GB) (Problematic) Total	1	A Handset	1854
Apple	iPhone 5c (32GB) (Problematic)	1	Part 2 A Handset	1855
Apple	iPhone 5c (32GB) (Problematic) Total	2	B Handset (Power Up, Bad LCD)	1856
Apple	iPhone 5c (32GB) (Problematic)	2	Part 2 B Handset (Power Up, Bad LCD)	1857
Apple	iPhone 5c (8GB) (Problematic) Total	3	A Handset	1858
Apple	iPhone 5c (8GB) (Problematic)	3	Part 2 A Handset	1859
Apple	iPhone 5c (8GB) (Problematic) Total	2	B Handset (Power Up, Bad LCD)	1860
Apple	iPhone 5c (8GB) (Problematic)	2	Part 2 B Handset (Power Up, Bad LCD)	1861
Apple	iPhone SE (32GB) (Problematic) Total	1	B Handset (Power Up, Bad LCD)	1862
Apple	iPhone SE (32GB) (Problematic)	1	Part 2 B Handset (Power Up, Bad LCD)	1863
Apple	iPhone 4 (16GB) (CDMA)iCloud lock (namely, ID lock) Total	2	B Handset (Power Up, Good LCD)	1864
Apple	iPhone 4 (16GB) (CDMA)iCloud lock (namely, ID lock)	2	Part 2 B Handset (Power Up, Good LCD)	1865
Apple	iPhone 4 (16GB) iCloud lock (namely, ID lock) Total	3	A Handset	1866
Apple	iPhone 4 (16GB) iCloud lock (namely, ID lock)	3	Part 2 A Handset	1867
Apple	iPhone 4 (8GB) (CDMA)iCloud lock (namely, ID lock) Total	6	B Handset (Power Up, Good LCD)	1868
Apple	iPhone 4 (8GB) (CDMA)iCloud lock (namely, ID lock)	6	Part 2 B Handset (Power Up, Good LCD)	1869
Apple	iPhone 4 (8GB) iCloud lock (namely, ID lock) Total	12	A Handset	1870
Apple	iPhone 4 (8GB) iCloud lock (namely, ID lock)	12	Part 2 A Handset	1871
Apple	iPhone 4s (16GB) iCloud lock (namely, ID lock) Total	5	A Handset	1872
Apple	iPhone 4s (16GB) iCloud lock (namely, ID lock)	5	Part 2 A Handset	1873
Apple	iPhone 4s (64GB) iCloud lock (namely, ID lock) Total	14	A Handset	1874
Apple	iPhone 4s (64GB) iCloud lock (namely, ID lock)	14	Part 2 A Handset	1875
Apple	iPhone 4s (8GB) iCloud lock (namely, ID lock) Total	1	B Handset (No Power)	1876
Apple	iPhone 4s (8GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (No Power)	1877
Apple	iPhone SE (128GB) iCloud lock (namely, ID lock) Total	1	B Handset (Power Up, Good LCD)	1878
Apple	iPhone SE (128GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Good LCD)	1879
Apple	iPhone SE (16GB) iCloud lock (namely, ID lock) Total	7	B Handset (Power Up, Bad LCD)	1882
Apple	iPhone SE (16GB) iCloud lock (namely, ID lock)	7	Part 2 B Handset (Power Up, Bad LCD)	1883
Apple	iPhone SE (32GB) iCloud lock (namely, ID lock) Total	1	B Handset (Power Up, Bad LCD)	1884
Apple	iPhone SE (32GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Bad LCD)	1885
Apple	iPhone SE (32GB) iCloud lock (namely, ID lock) Total	1	B Handset (No Power)	1886
Apple	iPhone SE (32GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (No Power)	1887
Apple	iPhone SE (64GB) iCloud lock (namely, ID lock) Total	1	A Handset	1888
Apple	iPhone SE (64GB) iCloud lock (namely, ID lock)	1	Part 2 A Handset	1889
Apple	iPhone SE (64GB) iCloud lock (namely, ID lock) Total	2	B Handset (Power Up, Good LCD)	1890
Apple	iPhone SE (64GB) iCloud lock (namely, ID lock)	2	Part 2 B Handset (Power Up, Good LCD)	1891
Apple	iPhone SE (64GB) iCloud lock (namely, ID lock) Total	2	B Handset (Power Up, Bad LCD)	1892
Apple	iPhone SE (64GB) iCloud lock (namely, ID lock)	2	Part 2 B Handset (Power Up, Bad LCD)	1893
Apple	iPhone SE (64GB) iCloud lock (namely, ID lock) Total	1	B Handset (No Power)	1894
Apple	iPhone SE (64GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (No Power)	1895
Apple	iPhone 3GS (32GB) Total	1	B Handset (Power Up, Good LCD)	1896
Apple	iPhone 3GS (32GB)	1	B Handset (Power Up, Good LCD)	1897
Apple	iPhone 4 (16GB) Total	19	A Handset	1898
Apple	iPhone 4 (16GB)	19	Part 2 A Handset	1899
Apple	iPhone 4 (16GB) Total	12	B Handset (Power Up, Good LCD)	1900
Apple	iPhone 4 (16GB)	12	Part 2 B Handset (Power Up, Good LCD)	1901
Apple	iPhone 4 (16GB) (CDMA) Total	10	B Handset (Power Up, Good LCD)	1902
Apple	iPhone 4 (16GB) (CDMA)	10	Part 2 B Handset (Power Up, Good LCD)	1903
Apple	iPhone 4 (32GB) Total	5	A Handset	1904
Apple	iPhone 4 (32GB)	5	Part 2 A Handset	1905
Apple	iPhone 4 (32GB) (CDMA) Total	3	B Handset (Power Up, Good LCD)	1906
Apple	iPhone 4 (32GB) (CDMA)	3	Part 2 B Handset (Power Up, Good LCD)	1907
Apple	iPhone 4 (8GB) Total	1	N. New	1908
Apple	iPhone 4 (8GB)	1	Part 2 N. New	1909
Apple	iPhone 4s (16GB) Total	2	B Handset (Power Up, Bad LCD)	1910
Apple	iPhone 4s (16GB)	2	Part 2 B Handset (Power Up, Bad LCD)	1911
Apple	iPhone 4s (32GB) Total	6	B Handset (Power Up, Good LCD)	1912
Apple	iPhone 4s (32GB)	6	Part 2 B Handset (Power Up, Good LCD)	1913
Apple	iPhone 4s (32GB) Total	10	B Handset (Power Up, Bad LCD)	1914
Apple	iPhone 4s (32GB)	10	Part 2 B Handset (Power Up, Bad LCD)	1915
Apple	iPhone 4s (64GB) Total	2	B Handset (Power Up, Good LCD)	1916
Apple	iPhone 4s (64GB)	2	Part 2 B Handset (Power Up, Good LCD)	1917
Apple	iPhone 4s (64GB) Total	2	B Handset (Power Up, Bad LCD)	1918
Apple	iPhone 4s (64GB)	2	Part 2 B Handset (Power Up, Bad LCD)	1919
Apple	iPhone 5 (32GB) Total	3	B Handset (Power Up, Good LCD)	1920
Apple	iPhone 5 (32GB)	3	Part 2 B Handset (Power Up, Good LCD)	1921
Apple	iPhone 5 (32GB) Total	2	B Handset (Power Up, Bad LCD)	1922
Apple	iPhone 5 (32GB)	2	Part 2 B Handset (Power Up, Bad LCD)	1923
Apple	iPhone 5 (64GB) Total	1	B Handset (Power Up, Good LCD)	1924
Apple	iPhone 5 (64GB)	1	Part 2 B Handset (Power Up, Good LCD)	1925
Apple	iPhone 5 (64GB) Total	1	B Handset (Power Up, Bad LCD)	1926
Apple	iPhone 5 (64GB)	1	Part 2 B Handset (Power Up, Bad LCD)	1927
Apple	iPhone 5c (16GB) Total	16	B Handset (Power Up, Bad LCD)	1930

Brand	Model	Total - QTY	Grade	Line
Apple	iPhone 5c (16GB)	16	Part 2 B Handset (Power Up, Bad LCD)	1931
Apple	iPhone 5c (8GB) Total	2	B Handset (Power Up, Good LCD)	1932
Apple	iPhone 5c (8GB)	2	Part 2 B Handset (Power Up, Good LCD)	1933
Apple	iPhone SE (32GB) Total	1	B Handset (Power Up, Good LCD)	1934
Apple	iPhone SE (32GB)	1	Part 2 B Handset (Power Up, Good LCD)	1935
Apple	iPhone SE (32GB) Total	1	B Handset (No Power)	1936
Apple	iPhone SE (32GB)	1	Part 2 B Handset (No Power)	1937
Samsung	G960 Total	2	B Handset (Power Up, Good LCD)	1940
Samsung	G960-1	2	B Handset (Power Up, Good LCD)	1942
Samsung	G930 Total	1	B Handset (Power Up, Good LCD)	1943
Samsung	G930	1	B Handset (Power Up, Good LCD)	1944
Samsung	J530F Total	9	B Handset (Power Up, Good LCD)	1946
Samsung	J530F	9	B Handset (Power Up, Good LCD)	1947
Samsung	G935F Total	6	B Handset (Power Up, Good LCD)	1949
Samsung	G935F-1	6	B Handset (Power Up, Good LCD)	1951
Samsung	A500F Total	7	B Handset (Power Up, Good LCD)	1961
Samsung	A500F	7	B Handset (Power Up, Good LCD)	1962
Samsung	G850F Total	1	14B	1970
Samsung	G850F (IMEI Cut)	1	14B	1972
Samsung	G903F Total	1	B Handset (Power Up, Good LCD)	1973
Samsung	G903F	1	B Handset (Power Up, Good LCD)	1974
Samsung	G925 (Demo) Total	18	B Handset (Power Up, Good LCD)	1976
Samsung	G925 (Demo)	1	B Handset (Power Up, Good LCD)	1977
Samsung	G925 (Demo) -1	17	B Handset (Power Up, Good LCD)	1978
Samsung	G925F Total	7	B Handset (Power Up, Good LCD)	1979
Samsung	G925F-1	7	B Handset (Power Up, Good LCD)	1981
Samsung	J330F Total	10	B Handset (Power Up, Good LCD)	1982
Samsung	J330F	10	B Handset (Power Up, Good LCD)	1983
Samsung	N9005 Total	1	B Handset (Power Up, Good LCD)	1988
Samsung	N9005	1	B Handset (Power Up, Good LCD)	1989
Samsung	N915F Total	6	B Handset (Power Up, Good LCD)	1991
Samsung	N915F-1	6	B Handset (Power Up, Good LCD)	1993
Huawei	P20 Lite Total	16	B Handset (Power Up, Good LCD)	1997
Huawei	P20 Lite	15	B Handset (Power Up, Good LCD)	1998
Huawei	P20 Lite (With Code)	1	B Handset (Power Up, Good LCD)	1999
Huawei	P10 Plus Total	7	B Handset (Power Up, Good LCD)	2000
Huawei	P10 Plus	6	B Handset (Power Up, Good LCD)	2001
Huawei	P10 Plus (With Code)	1	B Handset (Power Up, Good LCD)	2002
Huawei	P8 Lite 2017 Total	4	B Handset (Power Up, Good LCD)	2003
Huawei	P8 Lite 2017	4	B Handset (Power Up, Good LCD)	2004
Huawei	P9 Total	17	B Handset (Power Up, Good LCD)	2006
Huawei	P9	17	B Handset (Power Up, Good LCD)	2007
Ericsson	D2303 Total	2	B Handset (Power Up, Good LCD)	2009
Ericsson	D2303 (SIM Free)	1	B Handset (Power Up, Good LCD)	2010
Ericsson	D2303 (With Code)	1	B Handset (Power Up, Good LCD)	2011
Ericsson	E2303 Total	7	B Handset (Power Up, Good LCD)	2019
Ericsson	E2303	5	B Handset (Power Up, Good LCD)	2020
Ericsson	E2303 (With Code)	1	B Handset (Power Up, Good LCD)	2021
Ericsson	E2303 (SIM Free)	1	B Handset (Power Up, Good LCD)	2022
Ericsson	E2353 Total	2	B Handset (Power Up, Good LCD)	2023
Ericsson	E2353	1	B Handset (Power Up, Good LCD)	2024
Ericsson	E2353 (SIM Free)	1	B Handset (Power Up, Good LCD)	2025
Ericsson	G3121 Total	2	B Handset (Power Up, Good LCD)	2032
Ericsson	G3121 (SIM Free)	2	B Handset (Power Up, Good LCD)	2034
Nokia	3 Total	4	B Handset (Power Up, Good LCD)	2038
Nokia	3	4	B Handset (Power Up, Good LCD)	2039
Nokia	130 Total	4	14B	2044
Nokia	130	3	14B	2045
Nokia	130 (SIM Free)	1	14B	2046
Other	Google G011C Total	2	B Handset (Power Up, Good LCD)	2047
Other	Google G011C	2	B Handset (Power Up, Good LCD)	2048
Other	Google G-2PW2200 Total	8	B Handset (Power Up, Good LCD)	2050
Other	Google G-2PW2200 (With Code)	8	B Handset (Power Up, Good LCD)	2052
				2053
Apple	iPad 2 Wi-Fi (16GB)	98	B Handset (Power Up, Bad LCD)	2054
Apple	iPad Wi-Fi 3G (32GB)	25	B Handset (Power Up, Bad LCD)	2056
Apple	iPad Wi-Fi 3G (64GB)	27	B Handset (Power Up, Bad LCD)	2057
Apple	iPad 2 Wi-Fi (16GB) iCloud lock (namely, ID lock)	35	Part 2 B Handset (Power Up, Bad LCD)	2058
Apple	iPad 2 Wi-Fi 3G (16GB) iCloud lock (namely, ID lock)	21	Part 2 B Handset (Power Up, Bad LCD)	2059
Apple	iPod Touch 4 (8GB)	53	B Handset (Power Up, Good LCD)	2060
Apple	iPod Touch II (8GB)	33	B Handset (Power Up, Good LCD)	2061
Samsung	G955	33	B Handset (Power Up, Bad LCD)	2062
Samsung	G950	29	B Handset (Power Up, Bad LCD)	2063
Samsung	G930	1185	B Handset (Power Up, Bad LCD)	2064
Samsung	G935	39	B Handset (No Power)	2065
Samsung	G955F	106	B Handset (No Power)	2067
Samsung	N950F	38	B Handset (Power Up, Bad LCD)	2068
Samsung	G920F	38	B Handset (Power Up, Good LCD) LCD 1	2069
Samsung	G920F	414	B Handset (No Power)	2071
Samsung	G930F	381	B Handset (Power Up, Bad LCD)	2073
Samsung	G930F	85	B Handset (No Power)	2074
Samsung	G935F	609	B Handset (Power Up, Bad LCD)	2075
Samsung	G935F	299	B Handset (No Power)	2076
Samsung	A300F	152	B Handset (Power Up, Bad LCD)	2077
Samsung	A500F	41	B Handset (Power Up, Bad LCD)	2078
Samsung	B2100	26	B Handset	2080
Samsung	B3210	33	B Handset	2081
Samsung	B5510	59	B Handset	2082
Samsung	C3300	72	B Handset	2083
Samsung	C3520	198	B Handset	2084
Samsung	C3520	127	B Handset (Power Up, Bad LCD/No Power)	2085
Samsung	C5220	27	B Handset	2086
Samsung	E1170	383	B Handset	2087
Samsung	E1190	652	B Handset (Power Up, Bad LCD/No Power)	2088
Samsung	E1310	44	B Handset	2089
Samsung	E2210	392	B Handset	2090
Samsung	E2370	31	B Handset	2091
Samsung	E2530	123	B Handset (Power Up, Bad LCD/No Power)	2092
Samsung	E2550	40	B Handset	2093
Samsung	F210	30	B Handset	2094
Samsung	F480	40	B Handset	2095
Samsung	G130	20	B Handset	2096
Samsung	G130	114	B Handset (Power Up, Bad LCD/No Power)	2097
Samsung	G310	24	B Handset	2098
Samsung	G318	27	B Handset (Power Up, Bad LCD/No Power)	2099
Samsung	G355	26	B Handset (Power Up, Bad LCD/No Power)	2101
Samsung	G388F	26	B Handset	2104
Samsung	G388F	24	B Handset (Power Up, Bad LCD/No Power)	2105
Samsung	G800F	291	B Handset (Power Up, Bad LCD/No Power)	2106
Samsung	G900	25	B Handset (Power Up, Bad LCD)	2107
Samsung	G901F	25	B Handset (No Power)	2108
Samsung	G903F	23	B Handset (Power Up, Good LCD) LCD 1	2109
Samsung	i5500	91	B Handset	2112
Samsung	i8160	429	B Handset (Power Up, Bad LCD/No Power)	2114
Samsung	i8200	24	B Handset (Power Up, Bad LCD/No Power)	2116
Samsung	i9000	311	B Handset (Power Up, Bad LCD/No Power)	2117
Samsung	i9070	428	B Handset (Power Up, Bad LCD/No Power)	2118
Samsung	i9300	81	B Handset (Power Up, Bad LCD/No Power)	2119
Samsung	i9301	29	B Handset (Power Up, Bad LCD/No Power)	2120
Samsung	i9305	32	B Handset (Power Up, Bad LCD/No Power)	2121

Brand	Model	Total - QTY	Grade	Line
Samsung	J320	35	B Handset (Power Up, Bad LCD)	2122
Samsung	J320F (IMEI Cut)	23	N. New	2123
Samsung	J320F	59	N. New Handset	2125
Samsung	J320F	63	B Handset (Power Up, Bad LCD)	2127
Samsung	J510F	37	B Handset (Power Up, Bad LCD)	2129
Samsung	J730F	26	B Handset (Power Up, Bad LCD)	2130
Samsung	N7000	136	B Handset (Power Up, Bad LCD/No Power)	2131
Samsung	S5280	21	B Handset	2132
Samsung	S5310	62	B Handset	2133
Samsung	S5570	46	B Handset	2134
Samsung	S5600	33	B Handset	2135
Samsung	S5610	48	B Handset (Power Up, Bad LCD/No Power)	2136
Samsung	S5690	141	B Handset (Power Up, Bad LCD/No Power)	2137
Samsung	S5830	1240	B Handset (Power Up, Bad LCD/No Power)	2138
Samsung	S6500	953	B Handset (Power Up, Bad LCD/No Power)	2139
Samsung	S7230	31	B Handset	2140
Samsung	S7500	21	B Handset	2143
Samsung	S7582	26	B Handset (Power Up, Bad LCD/No Power)	2144
Samsung	S8000	52	B Handset	2145
Huawei	P10 Lite	28	B Handset (Power Up, Bad LCD)	2146
Huawei	P10	39	B Handset (No Power)	2147
Huawei	CUN-L01	193	B Handset	2148
Huawei	FIG-LX1	35	B Handset (Power Up, Bad LCD/No Power)	2151
Huawei	G7220	33	B Handset	2152
Huawei	KOB-L09	36	B Handset	2153
Huawei	P8	20	B Handset (Power Up, Bad LCD/No Power)	2154
Huawei	P8 Lite	112	B Handset (Power Up, Bad LCD)	2155
Huawei	P9	31	B Handset (Power Up, Bad LCD)	2159
Huawei	P9 Lite	31	B Handset (Power Up, Bad LCD)	2162
Huawei	RNE-L21	24	B Handset (Power Up, Bad LCD/No Power)	2164
Huawei	U8685	34	B Handset	2165
Huawei	U8800	30	B Handset	2166
Huawei	U8833	40	B Handset	2167
Huawei	U8833	27	B Handset (Power Up, Bad LCD/No Power)	2168
Huawei	Y550	42	B Handset	2170
LG	D280	28	B Handset (Power Up, Bad LCD/No Power)	2174
LG	D320	25	B Handset (Power Up, Bad LCD/No Power)	2175
LG	H440	59	B Handset	2176
LG	P500	447	B Handset	2177
LG	D295	25	B Handset (Power Up, Bad LCD/No Power)	2178
Ericsson	C1504	39	B Handset (Power Up, Bad LCD/No Power)	2179
Ericsson	C1505	114	B Handset (Power Up, Bad LCD/No Power)	2180
Ericsson	C902	22	B Handset	2181
Ericsson	CK13I	562	New	2182
Ericsson	CK13I	302	N. New Handset	2183
Ericsson	D2004	22	B Handset	2184
Ericsson	D2004	41	B Handset (Power Up, Bad LCD/No Power)	2185
Ericsson	D2005	124	B Handset	2186
Ericsson	D2533	22	B Handset	2187
Ericsson	D2533	56	B Handset (Power Up, Bad LCD/No Power)	2188
Ericsson	D5503	82	B Handset (Power Up, Bad LCD/No Power)	2189
Ericsson	E2303	23	B Handset (No Power)	2191
Ericsson	E2306	22	B Handset	2192
Ericsson	F100	35	B Handset	2193
Ericsson	F5121	26	B Handset (Power Up, Bad LCD)	2194
Ericsson	F8331	22	B Handset (Power Up, Bad LCD)	2195
Ericsson	G3311 (SIM Free)	49	N. New Handset	2196
Ericsson	J108	181	B Handset	2197
Ericsson	S500I	94	B Handset	2198
Ericsson	SK17i	22	B Handset	2199
Ericsson	ST21i	49	B Handset	2200
Ericsson	ST21i	54	B Handset (Power Up, Bad LCD/No Power)	2201
Ericsson	ST23i	26	B Handset	2202
Ericsson	W150A (High Frequency, With Code)	125	N. New Handset	2203
Ericsson	W580	124	B Handset	2204
Ericsson	W910	73	B Handset	2205
Ericsson	X8	46	B Handset	2206
BlackBerry	BB8230	20	B Handset	2207
BlackBerry	BB9000	2129	B Handset	2208
BlackBerry	BB9000 (Non-qwerty)	102	B Handset	2209
BlackBerry	BB9300 (Non-qwerty)	34	B Handset	2210
BlackBerry	BB9360	1035	B Handset	2211
BlackBerry	BB9700	147	B Handset	2212
BlackBerry	BB9780	185	B Handset	2213
BlackBerry	BB9790	404	B Handset	2214
BlackBerry	BB9790	130	B Handset (Power Up, Bad LCD/No Power)	2215
BlackBerry	BB9900	353	B Handset	2216
BlackBerry	BB9900	571	B Handset (Power Up, Bad LCD/No Power)	2217
BlackBerry	Z10 4G	48	B Handset (Power Up, Bad LCD/No Power)	2219
Nokia	203 (SIM Free)	67	B Handset (Power Up, Good LCD)	2220
Nokia	203	36	B Handset	2221
Nokia	207	23	B Handset	2222
Nokia	302 (SIM Free)	61	B Handset (Power Up, Good LCD)	2223
Nokia	302	314	B Handset	2224
Nokia	500 (SIM Free)	33	B Handset (Power Up, Good LCD)	2225
Nokia	500	257	B Handset	2226
Nokia	610 (SIM Free)	92	B Handset (Power Up, Good LCD)	2227
Nokia	2690	30	B Handset	2228
Nokia	5800	344	B Handset	2229
Nokia	6100	382	B Handset	2231
Nokia	6233	950	B Handset	2232
Nokia	1800B	30	B Handset	2233
Nokia	2720A	71	B Handset	2234
Nokia	2730C	189	B Handset (Power Up, Bad LCD/No Power)	2235
Nokia	5130C	1672	B Handset	2237
Nokia	6210S	64	B Handset	2238
Nokia	6303C	1836	B Handset	2239
Nokia	6500C	30	B Handset (Power Up, Bad LCD/No Power)	2240
Nokia	C2-02	260	B Handset	2242
Nokia	C3	104	B Handset	2243
Nokia	C5-03	152	B Handset	2244
Nokia	C6	88	B Handset	2245
Nokia	E5	68	B Handset	2246
Nokia	E51	73	B Handset	2247
Nokia	E6	34	B Handset	2249
Nokia	E72	85	B Handset (Power Up, Bad LCD/No Power)	2251
Nokia	N9	233	B Handset	2252
Nokia	N95-2	52	B Handset (Power Up, Bad LCD/No Power)	2253
Nokia	X3-02	64	B Handset	2254
Nokia	X6	127	B Handset	2255
Nokia	520 (With Code)	24	B Handset (Power Up, Good LCD)	2257
Nokia	520	379	B Handset	2258
Nokia	520	29	B Handset (Power Up, Bad LCD/No Power)	2259
Nokia	635	21	B Handset (Power Up, Bad LCD/No Power)	2262
Nokia	108	21	B Handset (Power Up, Bad LCD/No Power)	2264
Nokia	625	36	14B	2265
Nokia	625	308	B Handset	2266
Nokia	625	64	B Handset (Power Up, Bad LCD/No Power)	2267
Nokia	925	59	B Handset (Power Up, Bad LCD/No Power)	2268
Nokia	550	44	B Handset	2269

Brand	Model	Total - QTY	Grade	Line
Nokia	6301	46	B Handset	2270
Nokia	6310	450	B Handset	2271
Nokia	6310	89	B Handset (Power Up, Bad LCD/No Power)	2272
Nokia	101	161	B Handset (Power Up, Bad LCD/No Power)	2273
Nokia	820	59	B Handset (Power Up, Bad LCD/No Power)	2274
Nokia	620 (SIM Free)	29	B Handset (Power Up, Good LCD)	2275
Nokia	620	316	B Handset	2276
Nokia	620	34	B Handset (Power Up, Bad LCD/No Power)	2277
Nokia	920	109	B Handset	2278
Nokia	206	144	B Handset (Power Up, Bad LCD/No Power)	2279
Nokia	720	31	B Handset	2280
Nokia	720	35	B Handset (Power Up, Bad LCD/No Power)	2281
Nokia	630	22	B Handset	2282
Nokia	630	72	B Handset (Power Up, Bad LCD/No Power)	2283
Nokia	535	184	B Handset	2285
Nokia	435 (SIM Free)	141	B Handset (Power Up, Good LCD)	2286
Nokia	435	67	B Handset	2287
Nokia	532	22	N. New	2288
Nokia	532 (SIM Free)	281	B Handset (Power Up, Good LCD)	2289
Nokia	532	121	B Handset	2290
Nokia	532	94	B Handset (Power Up, Bad LCD/No Power)	2291
Nokia	100	225	B Handset	2292
Nokia	105 (SIM Free)	22	B Handset (Power Up, Good LCD)	2293
Nokia	105	74	B Handset	2294
Nokia	208	311	B Handset	2295
Nokia	208	224	B Handset (Power Up, Bad LCD/No Power)	2296
Nokia	301	95	B Handset	2297
Nokia	710	418	B Handset	2298
Nokia	2760	739	B Handset	2301
Nokia	5230	204	B Handset	2302
Nokia	6234	60	B Handset	2303
Nokia	6235	81	B Handset	2304
Nokia	111	87	B Handset	2305
Nokia	220	115	B Handset	2307
Nokia	225	61	B Handset	2308
HTC	85	54	B Handset (Power Up, Bad LCD/No Power)	2309
HTC	Desire 310	61	B Handset (Power Up, Bad LCD/No Power)	2310
HTC	Desire 320	27	B Handset (Power Up, Bad LCD/No Power)	2311
HTC	Desire C	30	B Handset	2312
Motorola	U9	116	B Handset	2313
Vodafone	V527	1080	N. New	2314
Vodafone	V527	500	N. New Handset	2315
Vodafone	V533	300	N. New Handset	2316
Vodafone	V555	125	B Handset	2317
Vodafone	V785	32	B Handset (Power Up, Bad LCD/No Power)	2318
Vodafone	V858	52	B Handset	2319
Vodafone	V895	87	B Handset	2320
Vodafone	VFD 200	230	B Handset	2321
Vodafone	VFD 300	40	B Handset (Power Up, Bad LCD/No Power)	2322
Other	Cat B15	27	B Handset	2323
Other	Cat B15	31	B Handset (Power Up, Bad LCD/No Power)	2324
Other	Cat B25	29	B Handset	2325
Other	Doro 5030	45	B Handset	2326
Other	Doro 8030	30	B Handset	2327
Other	Harrier	53	B Handset	2328
Other	Mixed 平板	33	B Handset (Power Up, Bad LCD/No Power)	2329
ZTE	Blade A452	23	B Handset (Power Up, Bad LCD/No Power)	2331
ZTE	Blade A462	27	B Handset (Power Up, Bad LCD/No Power)	2332
ZTE	Blade L5 Plus	22	B Handset	2333
ZTE	KIS Q	24	B Handset	2334
ZTE	Blade A612	21	B Handset (Power Up, Bad LCD/No Power)	2336
ZTE	Blade L7	22	B Handset	2337
ZTE	Blade L7	33	B Handset (Power Up, Bad LCD/No Power)	2338
ZTE	P736E	24	14B	2339
ZTE	Blade A602	21	B Handset	2340
Alcatel	OT2038	28	B Handset	2341
Alcatel	OT4033	27	B Handset (Power Up, Bad LCD/No Power)	2342
Alcatel	OT4034	28	B Handset	2343
Alcatel	OTS042	49	B Handset (Power Up, Bad LCD/No Power)	2344
Alcatel	OTS095	21	B Handset	2345
Alcatel	OT815	20	B Handset	2346
Alcatel	OT903	28	B Handset	2347
Alcatel	OT922	22	B Handset	2348
Alcatel	OT995	41	B Handset	2349
HP	iPAQ Data Messenger	36	N. New Handset	2350
HP	iPAQ Voice Messenger	92	N. New Handset	2351
Sagem	421Z	1674	N. New Handset	2352
Sagem	W-8	256	N. New Handset	2353
Sharp	550SH	60	N. New	2354
Sharp	880SH	109	N. New Handset	2355
Toshiba	TG01	500	N. New Handset	2356
SFR	SFR STARADDICT II	30	B Handset	2357
SFR	SFR STARTRAIL IV	43	B Handset	2358
SFR	SFR STARTRAIL IV	66	B Handset (Power Up, Bad LCD/No Power)	2359
SFR	SFR STARXTREM V	20	B Handset	2360
Apple	iPad 2 Wi-Fi (16GB)	1	B Handset (No Power)	2361
Apple	iPad 2 Wi-Fi (32GB)	5	B Handset (Power Up, Bad LCD)	2362
Apple	iPad 2 Wi-Fi (64GB)	1	B Handset (No Power)	2363
Apple	iPad 2 Wi-Fi 3G (16GB)	9	B Handset (Power Up, Bad LCD)	2364
Apple	iPad 2 Wi-Fi 3G (32GB)	5	B Handset (Power Up, Bad LCD)	2365
Apple	iPad 2 Wi-Fi 3G (32GB)	1	B Handset (No Power)	2366
Apple	iPad 2 Wi-Fi 3G (64GB)	1	B Handset (Power Up, Bad LCD)	2367
Apple	iPad 2 Wi-Fi 3G (64GB)	2	B Handset (No Power)	2368
Apple	iPad 4 Wi-Fi (32GB)	1	B Handset (No Power)	2369
Apple	iPad Air 2 Wi-Fi (16GB)	1	B Handset (Power Up, Good LCD)	2372
Apple	iPad Air 2 Wi-Fi (32GB)	1	B Handset (Power Up, Bad LCD)	2373
Apple	iPad Air 2 Wi-Fi 4G (16GB)	3	B Handset (Power Up, Good LCD)	2374
Apple	iPad Pro 10.5 Wi-Fi 4G (64GB)	1	B Handset (Power Up, Bad LCD)	2376
Apple	iPad Pro 10.5 Wi-Fi 4G (64GB)	1	B Handset (No Power)	2377
Apple	iPad Pro 9.7 Wi-Fi 4G (32GB)	1	B Handset (Power Up, Bad LCD)	2378
Apple	iPad Pro 9.7 Wi-Fi 4G (32GB)	1	B Handset (No Power)	2379
Apple	iPad Pro Wi-Fi 4G (128GB)	2	B Handset (No Power)	2380
Apple	iPad Wi-Fi (16GB)	2	B Handset (Power Up, Bad LCD)	2381
Apple	iPad Wi-Fi (32GB)	5	B Handset (Power Up, Bad LCD)	2382
Apple	iPad Wi-Fi (32GB)	1	B Handset (No Power)	2383
Apple	iPad Wi-Fi (64GB)	9	B Handset (Power Up, Good LCD)	2384
Apple	iPad Wi-Fi (64GB)	3	B Handset (Power Up, Bad LCD)	2385
Apple	iPad Wi-Fi 3G (16GB)	7	B Handset (Power Up, Bad LCD)	2386
Apple	The New iPad Wi-Fi (16GB)	2	B Handset (No Power)	2387
Apple	The New iPad Wi-Fi 4G (16GB)	1	B Handset (Power Up, Bad LCD)	2388
Apple	iPad 2 Wi-Fi (32GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Bad LCD)	2389
Apple	iPad 2 Wi-Fi (64GB) iCloud lock (namely, ID lock)	2	Part 2 B Handset (Power Up, Bad LCD)	2390
Apple	iPad 2 Wi-Fi 3G (32GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Bad LCD)	2391
Apple	iPad 2 Wi-Fi 3G (64GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Good LCD)	2392
Apple	iPad 2 Wi-Fi 3G (64GB) iCloud lock (namely, ID lock)	4	Part 2 B Handset (Power Up, Bad LCD)	2393
Apple	iPad 4 Wi-Fi (16GB) iCloud lock (namely, ID lock)	2	Part 2 B Handset (Power Up, Bad LCD)	2394
Apple	iPad 4 Wi-Fi (32GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Good LCD)	2395
Apple	iPad Air 2 Wi-Fi (64GB) iCloud lock (namely, ID lock)	3	Part 2 B Handset (Power Up, Good LCD)	2396
Apple	iPad Air 2 Wi-Fi (64GB) iCloud lock (namely, ID lock)	19	Part 2 B Handset (Power Up, Bad LCD)	2397
Apple	iPad Air 2 Wi-Fi 4G (64GB) iCloud lock (namely, ID lock)	17	Part 2 B Handset (Power Up, Bad LCD)	2398

Brand	Model	Total - QTY	Grade	Line
Apple	iPad Air Wi-Fi (16GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Good LCD)	2399
Apple	iPad Mini 2 Wi-Fi (32GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Bad LCD)	2401
Apple	iPad Mini 4 Wi-Fi 4G (32GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Bad LCD)	2402
Apple	iPad Mini Wi-Fi (16GB) iCloud lock (namely, ID lock)	5	Part 2 B Handset (Power Up, Bad LCD)	2404
Apple	iPad Mini Wi-Fi (16GB) iCloud lock (namely, ID lock)	3	Part 2 B Handset (No Power)	2405
Apple	iPad Mini Wi-Fi 4G (16GB) iCloud lock (namely, ID lock)	2	Part 2 B Handset (Power Up, Bad LCD)	2406
Apple	iPad Mini Wi-Fi 4G (64GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Bad LCD)	2407
Apple	iPad Pro 9.7 Wi-Fi 4G (32GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Bad LCD)	2408
Apple	The New iPad Wi-Fi 4G (16GB) iCloud lock (namely, ID lock)	1	Part 2 B Handset (Power Up, Bad LCD)	2409
Apple	iPod Nano 2 (8GB)	1	B Handset (Power Up, Good LCD)	2411
Apple	iPod Nano 4 (8GB)	12	B Handset (Power Up, Good LCD)	2412
Apple	iPod Nano 5 (8GB)	1	B Handset (Power Up, Good LCD)	2413
Apple	iPod Shuffle (1GB)	5	B Handset (Power Up, Good LCD)	2414
Apple	iPod Shuffle 2 (1GB)	3	B Handset (Power Up, Good LCD)	2415
Apple	iPod Shuffle 4 (2GB)	1	B Handset (Power Up, Good LCD)	2416
Apple	iPod Touch (16GB)	18	B Handset (Power Up, Good LCD)	2417
Apple	iPod Touch (16GB)	2	B Handset (Power Up, Bad LCD/No Power)	2418
Apple	iPod Touch (32GB)	1	B Handset (Power Up, Good LCD)	2419
Apple	iPod Touch (8GB)	9	B Handset (Power Up, Good LCD)	2420
Apple	iPod Touch 4 (16GB)	18	B Handset (Power Up, Good LCD)	2421
Apple	iPod Touch 4 (16GB)	4	B Handset (Power Up, Bad LCD/No Power)	2422
Apple	iPod Touch 4 (32GB)	18	B Handset (Power Up, Good LCD)	2423
Apple	iPod Touch 4 (32GB)	1	B Handset (Power Up, Bad LCD/No Power)	2424
Apple	iPod Touch 4 (64GB)	1	B Handset (Power Up, Bad LCD/No Power)	2425
Apple	iPod Touch 4 (8GB)	15	B Handset (Power Up, Bad LCD/No Power)	2426
Apple	iPod Touch 5 (16GB)	10	B Handset (Power Up, Good LCD)	2427
Apple	iPod Touch 5 (16GB)	2	B Handset (Power Up, Bad LCD/No Power)	2428
Apple	iPod Touch 5 (32GB)	1	B Handset (Power Up, Bad LCD/No Power)	2430
Apple	iPod Touch 5 (64GB)	3	B Handset (Power Up, Good LCD)	2431
Apple	iPod Touch 6 (16GB)	7	B Handset (Power Up, Good LCD)	2432
Apple	iPod Touch II (16GB)	4	B Handset (Power Up, Good LCD)	2433
Apple	iPod Touch II (32GB)	1	B Handset (Power Up, Good LCD)	2434
Apple	iPod Touch III (32GB)	5	B Handset (Power Up, Good LCD)	2435
Apple	iPod Touch III (64GB)	2	B Handset (Power Up, Good LCD)	2436
Apple	iPod nano 2 (2GB)	2	B Handset (Power Up, Good LCD)	2437
Apple	iPod Nano 2 (4GB)	1	B Handset (Power Up, Good LCD)	2438
Samsung	G965	6	B Handset (No Power)	2441
Samsung	G955 (Demo)	1	B Handset (Power Up, Bad LCD)	2442
Samsung	G920	1	N. New	2443
Samsung	G920	2	B Handset (Power Up, Good LCD) LCD 1	2444
Samsung	G955-1	1	B Handset (Power Up, Good LCD)	2446
Samsung	G955	5	B Handset (Power Up, Good LCD) LCD 1	2447
Samsung	G955	12	B Handset (No Power)	2448
Samsung	N920	12	B Handset (Power Up, Bad LCD)	2452
Samsung	N920	3	B Handset (No Power)	2453
Samsung	G950F	2	14B	2454
Samsung	G950F-1	2	B Handset (Power Up, Good LCD)	2456
Samsung	G950F	13	B Handset (No Power)	2458
Samsung	G965F-1	8	B Handset (Power Up, Good LCD)	2462
Samsung	G965F	5	B Handset (Power Up, Bad LCD)	2463
Samsung	N950F	1	N. New	2465
Samsung	N950F	1	B Handset (Power Up, Good LCD) LCD 1	2467
Samsung	N950F	11	B Handset (No Power)	2468
Samsung	G920F	2	14A	2469
Samsung	G920F	2	14B	2470
Samsung	G920F	7	N. New Handset	2471
Samsung	G960F	1	B Handset (No Power)	2474
Samsung	J530F	2	14B	2475
Samsung	J530F	2	B Handset (Power Up, Good LCD) LCD 1	2476
Samsung	J530F	5	B Handset (Power Up, Bad LCD)	2477
Samsung	J500F	4	B Handset (No Power)	2482
Samsung	J500	7	B Handset (Power Up, Bad LCD)	2484
Samsung	J710F	3	B Handset (Power Up, Good LCD) LCD 1	2487
Samsung	G930F	1	N. New	2490
Samsung	G935F	2	14B	2493
Samsung	G935F	12	B Handset (Power Up, Good LCD) LCD 1	2494
Samsung	G386	1	B Handset	2495
Samsung	A300	1	B Handset (Power Up, Bad LCD)	2496
Samsung	A300F	6	B Handset (No Power)	2498
Samsung	A310F	1	N. New Handset	2499
Samsung	A310F	2	B Handset (Power Up, Bad LCD)	2500
Samsung	A320F	2	B Handset (Power Up, Bad LCD)	2502
Samsung	A510	1	B Handset (No Power)	2505
Samsung	A510F	6	B Handset (No Power)	2507
Samsung	A520F	4	B Handset (Power Up, Good LCD) LCD 1	2510
Samsung	A530F	1	New	2513
Samsung	A600F	10	B Handset (Power Up, Bad LCD)	2516
Samsung	A800F	1	B Handset (Power Up, Good LCD) LCD 1	2517
Samsung	B270	4	B Handset	2518
Samsung	B2700	10	B Handset	2519
Samsung	B5512	1	B Handset	2520
Samsung	B7510	2	B Handset	2521
Samsung	C101	2	B Handset (Power Up, Bad LCD/No Power)	2522
Samsung	C260	6	B Handset	2523
Samsung	C270	2	B Handset	2524
Samsung	C280	2	B Handset	2525
Samsung	C3050	11	B Handset	2526
Samsung	C3350	1	B Handset	2527
Samsung	C5130	14	B Handset	2528
Samsung	E1080	14	B Handset	2529
Samsung	E1120	1	B Handset	2530
Samsung	E1151	1	B Handset	2531
Samsung	E1200	3	14B	2533
Samsung	E1270	2	B Handset (Power Up, Bad LCD/No Power)	2534
Samsung	E1360	2	B Handset	2535
Samsung	E2120	2	B Handset	2536
Samsung	E2230	4	B Handset	2538
Samsung	E2530	3	B Handset	2539
Samsung	E700F	12	B Handset (Power Up, Bad LCD/No Power)	2541
Samsung	G110	7	B Handset	2542
Samsung	G130	2	N. New	2543
Samsung	G310	11	B Handset (Power Up, Bad LCD/No Power)	2545
Samsung	G313	1	B Handset	2546
Samsung	G313	4	B Handset (Power Up, Bad LCD/No Power)	2547
Samsung	G316	4	B Handset	2548
Samsung	G318	2	B Handset	2549
Samsung	G350	1	N. New	2550
Samsung	G357F	8	B Handset	2554
Samsung	G357F	5	B Handset (Power Up, Bad LCD/No Power)	2555
Samsung	G360F	1	B Handset	2557
Samsung	G360F	1	B Handset (Power Up, Bad LCD/No Power)	2558
Samsung	G361F	15	B Handset (Power Up, Bad LCD/No Power)	2560
Samsung	G3815	1	B Handset (Power Up, Bad LCD/No Power)	2562
Samsung	G3859	1	B Handset (Power Up, Bad LCD/No Power)	2563
Samsung	G389F	1	B Handset	2564
Samsung	G530F	2	B Handset	2565
Samsung	G531F	1	B Handset (Power Up, Bad LCD/No Power)	2568
Samsung	G570	6	B Handset (Power Up, Bad LCD/No Power)	2571
Samsung	G710	2	B Handset	2572
Samsung	G7102	3	B Handset	2573

Brand	Model	Total - QTY	Grade	Line
Samsung	G7105	2	B Handset	2574
Samsung	G800	2	B Handset (Power Up, Bad LCD/No Power)	2575
Samsung	G800F	1	N. New	2576
Samsung	G800F	6	14B	2577
Samsung	G850F	10	B Handset	2579
Samsung	G850F	2	B Handset (Power Up, Bad LCD/No Power)	2580
Samsung	G870	1	B Handset (Power Up, Bad LCD/No Power)	2581
Samsung	G900	4	B Handset (No Power)	2582
Samsung	G900 (Demo)	7	B Handset (Power Up, Good LCD) LCD 1	2583
Samsung	G900 (Demo)	6	B Handset (Power Up, Bad LCD/No Power)	2584
Samsung	G900F-1	2	B Handset (Power Up, Good LCD)	2586
Samsung	G900F	1	B Handset (No Power)	2589
Samsung	G903F	7	B Handset (Power Up, Bad LCD)	2592
Samsung	G903F	1	B Handset (No Power)	2593
Samsung	G920 (Demo)	7	B Handset (Power Up, Bad LCD)	2594
Samsung	G920 (Demo)	10	B Handset (No Power)	2595
Samsung	G925 (Demo)	7	B Handset (Power Up, Bad LCD)	2596
Samsung	G925 (Demo)	2	B Handset (No Power)	2597
Samsung	G928	1	A Handset	2600
Samsung	G928 (Demo) -1	2	B Handset (Power Up, Good LCD)	2601
Samsung	G928 (Demo)	7	B Handset (Power Up, Bad LCD)	2602
Samsung	G928F	3	B Handset (Power Up, Good LCD) LCD 1	2604
Samsung	G930 (Demo) -1	1	B Handset (Power Up, Good LCD)	2607
Samsung	i317	4	B Handset (Power Up, Bad LCD/No Power)	2608
Samsung	i545	1	B Handset	2609
Samsung	i5510	1	B Handset	2610
Samsung	i605	1	B Handset (Power Up, Bad LCD/No Power)	2611
Samsung	i747	1	B Handset	2612
Samsung	i757	1	B Handset	2613
Samsung	i8000	4	B Handset	2614
Samsung	i8150	2	14B	2615
Samsung	i8160	2	B Handset	2616
Samsung	i8190	9	B Handset	2617
Samsung	i8190	2	B Handset (Power Up, Bad LCD/No Power)	2618
Samsung	i8260	3	B Handset (Power Up, Bad LCD/No Power)	2619
Samsung	i8262	1	B Handset	2620
Samsung	i8730	2	B Handset (Power Up, Bad LCD/No Power)	2621
Samsung	i8750	18	B Handset (Power Up, Bad LCD/No Power)	2622
Samsung	i897	3	B Handset	2623
Samsung	i9000	2	14B	2624
Samsung	i9003	3	B Handset	2625
Samsung	i9060	4	B Handset (Power Up, Bad LCD/No Power)	2627
Samsung	i9070	5	B Handset	2629
Samsung	i9080	1	B Handset	2630
Samsung	i9080	5	B Handset (Power Up, Bad LCD/No Power)	2631
Samsung	i9082	16	B Handset (Power Up, Bad LCD/No Power)	2632
Samsung	i9190	1	B Handset	2636
Samsung	i9195	6	B Handset	2637
Samsung	i9195	1	B Handset (Power Up, Bad LCD/No Power)	2638
Samsung	i9195 (Demo)	1	B Handset (Power Up, Bad LCD/No Power)	2639
Samsung	i9250	5	B Handset (Power Up, Bad LCD/No Power)	2641
Samsung	i9295	4	B Handset	2642
Samsung	i9295	5	B Handset (Power Up, Bad LCD/No Power)	2643
Samsung	i9300	9	B Handset	2644
Samsung	i9505	8	B Handset (Power Up, Bad LCD/No Power)	2646
Samsung	i9505 (Demo)	3	B Handset (Power Up, Bad LCD/No Power)	2647
Samsung	i9515	1	B Handset (Power Up, Bad LCD/No Power)	2648
Samsung	J100	4	B Handset (Power Up, Bad LCD/No Power)	2650
Samsung	J105f	1	B Handset	2651
Samsung	J106	6	B Handset	2652
Samsung	J106	1	B Handset (Power Up, Bad LCD/No Power)	2653
Samsung	J110	1	14B	2654
Samsung	J120F	2	B Handset	2656
Samsung	J330	1	B Handset	2659
Samsung	J330F	3	N. New Handset	2661
Samsung	J330F	1	B Handset (Power Up, Bad LCD)	2662
Samsung	J510F	9	14B	2665
Samsung	J510F	7	B Handset (Power Up, Good LCD) LCD 1	2666
Samsung	J730	1	B Handset (Power Up, Good LCD) LCD 1	2673
Samsung	J730F	5	B Handset (No Power)	2674
Samsung	L700	15	B Handset	2675
Samsung	L720	2	B Handset	2676
Samsung	N7000	1	B Handset	2677
Samsung	N7100	4	B Handset	2678
Samsung	N7100	2	B Handset (Power Up, Bad LCD/No Power)	2679
Samsung	N7105	2	B Handset	2680
Samsung	N7505	1	B Handset	2681
Samsung	N7505	2	B Handset (Power Up, Bad LCD/No Power)	2682
Samsung	N900	1	B Handset (No Power)	2685
Samsung	N9005	10	B Handset (No Power)	2688
Samsung	N910 (Demo)	3	B Handset (Power Up, Good LCD) LCD 1	2689
Samsung	N910 (Demo)	2	B Handset (Power Up, Bad LCD)	2690
Samsung	N910 (Demo)	7	B Handset (Power Up, Bad LCD/No Power)	2691
Samsung	N9100	3	B Handset (Power Up, Bad LCD)	2692
Samsung	N910F	2	B Handset (Power Up, Good LCD) LCD 1	2693
Samsung	N915-1	1	B Handset (Power Up, Good LCD)	2695
Samsung	N9150	1	B Handset (Power Up, Bad LCD/No Power)	2696
Samsung	N915F (IMEI Cut)	1	14A	2697
Samsung	N915F	2	A Handset	2698
Samsung	N915F	3	B Handset (Power Up, Good LCD) LCD 1	2699
Samsung	N915F	3	B Handset (Power Up, Bad LCD)	2700
Samsung	N915F	13	B Handset (No Power)	2701
Samsung	P1000	1	B Handset (Power Up, Bad LCD/No Power)	2702
Samsung	P3110	1	B Handset (Power Up, Bad LCD/No Power)	2703
Samsung	P6800	1	B Handset (Power Up, Bad LCD/No Power)	2704
Samsung	P7300	1	B Handset (Power Up, Bad LCD/No Power)	2705
Samsung	S3350	8	B Handset	2706
Samsung	S3370	15	B Handset	2707
Samsung	S3650	3	B Handset	2708
Samsung	S5220	15	B Handset	2709
Samsung	S5230	11	B Handset	2710
Samsung	S5260	3	B Handset	2711
Samsung	S5360	4	B Handset	2712
Samsung	S5363	13	B Handset	2713
Samsung	S5570	2	B Handset (Power Up, Good LCD)	2714
Samsung	S5570	1	B Handset (Power Up, Bad LCD/No Power)	2715
Samsung	S5610	2	N. New	2716
Samsung	S5610	10	14B	2717
Samsung	S5620	14	B Handset	2718
Samsung	S5660	1	B Handset	2719
Samsung	S5670	12	B Handset	2720
Samsung	S5690	1	B Handset	2721
Samsung	S5830	14	B Handset	2722
Samsung	S6310	6	B Handset	2723
Samsung	S6310	1	B Handset (Power Up, Bad LCD/No Power)	2724
Samsung	S6500	1	B Handset	2725
Samsung	S6790	1	B Handset	2726
Samsung	S6810	8	B Handset	2727
Samsung	S6810	1	B Handset (Power Up, Bad LCD/No Power)	2728
Samsung	S7070	2	B Handset	2729

Brand	Model	Total - QTY	Grade	Line
Samsung	S7250	1	B Handset	2730
Samsung	S7392	1	B Handset	2731
Samsung	S7560	3	B Handset	2732
Samsung	S7560	1	B Handset (Power Up, Bad LCD/No Power)	2733
Samsung	S7562	1	B Handset	2734
Samsung	S7580	9	B Handset (Power Up, Bad LCD/No Power)	2735
Samsung	S7582	1	B Handset	2736
Samsung	S8300	9	B Handset	2737
Samsung	S8530	7	B Handset	2738
Samsung	S8600	2	B Handset	2739
Samsung	T110	6	B Handset (Power Up, Bad LCD/No Power)	2740
Samsung	T113	2	B Handset (Power Up, Bad LCD/No Power)	2741
Samsung	T116	1	B Handset (Power Up, Bad LCD/No Power)	2742
Samsung	T280	1	B Handset (Power Up, Bad LCD/No Power)	2743
Samsung	T479	4	B Handset	2744
Samsung	T520	1	B Handset (Power Up, Bad LCD/No Power)	2745
Samsung	T535	1	B Handset (Power Up, Bad LCD/No Power)	2746
Samsung	T555	1	B Handset (Power Up, Bad LCD/No Power)	2747
Samsung	T560 (IMEI Cut)	1	14B	2748
Samsung	T560	1	B Handset (Power Up, Bad LCD/No Power)	2749
Samsung	T585	3	B Handset (Power Up, Bad LCD/No Power)	2751
Samsung	T679	10	B Handset	2752
Samsung	T710	4	B Handset (Power Up, Bad LCD/No Power)	2753
Samsung	T810	5	B Handset (Power Up, Bad LCD/No Power)	2754
Samsung	T813	5	14B	2755
Samsung	T813	2	B Handset (Power Up, Bad LCD/No Power)	2756
Samsung	T815	2	B Handset (Power Up, Bad LCD/No Power)	2757
Samsung	T819	11	B Handset (Power Up, Bad LCD/No Power)	2758
Samsung	T999	4	B Handset	2759
Samsung	B5330	6	N. New Handset	2760
Samsung	P7510	1	B Handset (Power Up, Bad LCD/No Power)	2761
Samsung	P605	1	14B	2763
Samsung	G950-1	1	B Handset (Power Up, Good LCD)	2765
Samsung	G950	5	B Handset (Power Up, Good LCD) LCD 1	2766
Samsung	G950	14	B Handset (No Power)	2767
Samsung	G610	1	B Handset	2768
Samsung	J710	3	B Handset (Power Up, Bad LCD)	2770
Samsung	J710	1	B Handset (No Power)	2771
Samsung	T311 (IMEI Cut)	1	14B	2772
Samsung	T311	1	B Handset (Power Up, Bad LCD/No Power)	2773
Samsung	S5150	1	B Handset	2774
Samsung	A710F	2	B Handset (Power Up, Bad LCD)	2775
Samsung	A710F	1	B Handset (No Power)	2776
Samsung	A605F	2	B Handset (Power Up, Bad LCD)	2777
Samsung	I8700	1	B Handset	2778
Samsung	S8500	1	B Handset	2779
Samsung	E2152	1	B Handset	2780
Samsung	P5200	1	B Handset (Power Up, Bad LCD/No Power)	2781
Samsung	i535	1	B Handset	2783
Samsung	T580	2	B Handset	2785
Samsung	T580	5	B Handset (Power Up, Bad LCD/No Power)	2786
Samsung	J105	6	B Handset	2787
Samsung	J105	3	B Handset (Power Up, Bad LCD/No Power)	2788
Samsung	T700	5	B Handset (Power Up, Bad LCD/No Power)	2789
Huawei	P20 Lite	5	B Handset (No Power)	2793
Huawei	P20	3	B Handset (Power Up, Bad LCD)	2796
Huawei	7D-501L	1	B Handset	2797
Huawei	AGS-L09	8	B Handset	2798
Huawei	BG2-W09	1	B Handset	2801
Huawei	BG2-W09	3	B Handset (Power Up, Bad LCD/No Power)	2802
Huawei	BLA-L09	3	B Handset (Power Up, Bad LCD)	2803
Huawei	CAN-L11	1	B Handset	2808
Huawei	CUN-L01	1	N. New	2810
Huawei	CUN-L01	9	B Handset (Power Up, Bad LCD/No Power)	2811
Huawei	CUN-L02	1	B Handset	2812
Huawei	CUN-L21	1	B Handset (Power Up, Bad LCD/No Power)	2813
Huawei	FDR-A01L	8	B Handset	2815
Huawei	FIG-LX1	1	B Handset (Power Up, Bad LCD)	2817
Huawei	G510	8	B Handset (Power Up, Bad LCD/No Power)	2819
Huawei	G525	4	B Handset	2820
Huawei	G525	1	B Handset (Power Up, Bad LCD/No Power)	2821
Huawei	G526	5	B Handset	2822
Huawei	G535	2	B Handset	2823
Huawei	G535	1	B Handset (Power Up, Bad LCD/No Power)	2824
Huawei	G6	1	B Handset	2825
Huawei	G610	14	B Handset	2826
Huawei	G610	17	B Handset (Power Up, Bad LCD/No Power)	2827
Huawei	G620	1	B Handset	2828
Huawei	G620	9	B Handset (Power Up, Bad LCD/No Power)	2829
Huawei	G630	2	B Handset	2830
Huawei	G630	9	B Handset (Power Up, Bad LCD/No Power)	2831
Huawei	G6600	19	B Handset	2832
Huawei	G7	5	B Handset (Power Up, Bad LCD)	2834
Huawei	G700	2	B Handset	2835
Huawei	G700	4	B Handset (Power Up, Bad LCD/No Power)	2836
Huawei	G7210	5	B Handset	2837
Huawei	G730	1	B Handset	2838
Huawei	G730	3	B Handset (Power Up, Bad LCD/No Power)	2839
Huawei	G740	5	B Handset	2840
Huawei	G750	2	B Handset	2841
Huawei	G750	1	B Handset (Power Up, Bad LCD/No Power)	2842
Huawei	GEM-701L	1	B Handset (Power Up, Bad LCD/No Power)	2845
Huawei	H1512 (SIM Free)	1	N. New Handset	2846
Huawei	H1512	1	B Handset (Power Up, Bad LCD)	2847
Huawei	KII-L33	1	B Handset	2849
Huawei	KOB-L09	1	B Handset (Power Up, Bad LCD/No Power)	2854
Huawei	LUA-L01	2	B Handset (Power Up, Bad LCD/No Power)	2857
Huawei	LUA-L02	1	B Handset (Power Up, Bad LCD/No Power)	2858
Huawei	LUA-L03	1	B Handset (Power Up, Bad LCD/No Power)	2859
Huawei	LUA-L21	1	B Handset	2860
Huawei	LUA-L21	1	B Handset (Power Up, Bad LCD/No Power)	2861
Huawei	MHA-L09	9	B Handset (Power Up, Bad LCD/No Power)	2864
Huawei	MT1-U06	1	14B	2865
Huawei	MT1-U06	1	B Handset	2866
Huawei	MT1-U06	5	B Handset (Power Up, Bad LCD/No Power)	2867
Huawei	MT2-L03	1	B Handset	2868
Huawei	MT7-L09	1	B Handset	2869
Huawei	MYA-L11	2	B Handset (Power Up, Bad LCD/No Power)	2870
Huawei	P10 Lite	19	B Handset (Power Up, Good LCD)	2874
Huawei	P6	3	B Handset (Power Up, Bad LCD/No Power)	2876
Huawei	P7	2	B Handset	2877
Huawei	P7 Mini	3	B Handset	2879
Huawei	P8	1	B Handset (Power Up, Bad LCD)	2881
Huawei	P8	6	B Handset (No Power)	2882
Huawei	P9 Lite	3	B Handset (No Power)	2884
Huawei	P9 Plus	5	B Handset (No Power)	2887
Huawei	PLK-L01	2	B Handset	2888
Huawei	S7-201	1	B Handset	2889
Huawei	SCL-L01	1	B Handset	2890
Huawei	SCL-L01	4	B Handset (Power Up, Bad LCD/No Power)	2891

Brand	Model	Total - QTY	Grade	Line
Huawei	SCL-L02	1	B Handset	2892
Huawei	SCL-L21	4	B Handset	2893
Huawei	U8150	11	B Handset	2897
Huawei	U8180	7	B Handset	2898
Huawei	U8180	2	B Handset (Power Up, Bad LCD/No Power)	2899
Huawei	U8185	2	B Handset	2900
Huawei	U8220	2	B Handset	2901
Huawei	U8230	1	B Handset	2902
Huawei	U8510	3	B Handset (Power Up, Bad LCD/No Power)	2903
Huawei	U8650	10	B Handset	2904
Huawei	U8655	1	14B	2905
Huawei	U8655	11	B Handset	2906
Huawei	U8666	4	B Handset	2907
Huawei	U8685	7	14B	2908
Huawei	U8815	1	B Handset	2909
Huawei	U8815	1	B Handset (Power Up, Bad LCD/No Power)	2910
Huawei	U8825	1	B Handset	2911
Huawei	U8825	5	B Handset (Power Up, Bad LCD/No Power)	2912
Huawei	U8860	2	B Handset	2913
Huawei	U8860	2	B Handset (Power Up, Bad LCD/No Power)	2914
Huawei	U9200	2	B Handset (Power Up, Bad LCD/No Power)	2915
Huawei	U9202	1	B Handset (Power Up, Bad LCD/No Power)	2916
Huawei	U9508	1	B Handset (Power Up, Bad LCD/No Power)	2917
Huawei	U9510	6	B Handset	2918
Huawei	Y221	11	B Handset	2919
Huawei	Y330	9	B Handset	2920
Huawei	Y330	19	B Handset (Power Up, Bad LCD/No Power)	2921
Huawei	Y360	6	B Handset	2922
Huawei	Y360	1	B Handset (Power Up, Bad LCD/No Power)	2923
Huawei	Y511	4	B Handset	2924
Huawei	Y520	3	B Handset	2925
Huawei	Y530	14	B Handset	2926
Huawei	Y530	15	B Handset (Power Up, Bad LCD/No Power)	2927
Huawei	Y540	6	B Handset	2928
Huawei	Y540	3	B Handset (Power Up, Bad LCD/No Power)	2929
Huawei	Y550	3	B Handset (Power Up, Bad LCD/No Power)	2930
Huawei	Y560	9	B Handset	2931
Huawei	Y560	3	B Handset (Power Up, Bad LCD/No Power)	2932
Huawei	Y560-U02	3	B Handset	2933
Huawei	Y600	6	B Handset (Power Up, Bad LCD/No Power)	2934
Huawei	Y625	4	B Handset (Power Up, Bad LCD/No Power)	2935
Huawei	Y635	4	B Handset	2936
Huawei	Y635	9	B Handset (Power Up, Bad LCD/No Power)	2937
Huawei	CHC-U01	1	B Handset	2938
Huawei	DLI-L22	6	B Handset	2939
Huawei	DLI-L22	2	B Handset (Power Up, Bad LCD/No Power)	2940
Huawei	MYA-L02	1	B Handset	2943
Huawei	MLA-L01	1	B Handset	2944
Huawei	S7-722	2	B Handset (Power Up, Bad LCD/No Power)	2946
Huawei	Y220	1	B Handset	2947
Huawei	P2	1	B Handset	2948
Huawei	P2	2	B Handset (Power Up, Bad LCD/No Power)	2949
Huawei	CHC-U03	1	B Handset	2950
Huawei	M886	1	N. New	2951
Huawei	RNE-L03	6	B Handset (Power Up, Bad LCD/No Power)	2955
Huawei	U8950	2	B Handset	2956
Huawei	S10-231	2	B Handset	2961
Huawei	T1-701	1	B Handset (Power Up, Bad LCD/No Power)	2962
Huawei	GEM-701	1	B Handset (Power Up, Bad LCD/No Power)	2963
Huawei	HOL-U19	1	B Handset	2964
Huawei	CRO-L03	1	B Handset	2965
Huawei	CHE2-UL00	1	B Handset	2966
Huawei	DRA-L21	4	B Handset	2970
Huawei	DRA-L21	2	B Handset (Power Up, Bad LCD/No Power)	2971
Huawei	LDN-L21	1	B Handset (Power Up, Bad LCD/No Power)	2974
Huawei	LND-L29	6	B Handset (Power Up, Bad LCD/No Power)	2975
LG	G350	8	B Handset	2978
LG	G350	1	B Handset (Power Up, Bad LCD/No Power)	2979
LG	G360	1	B Handset	2980
LG	G360	1	B Handset (Power Up, Bad LCD/No Power)	2981
LG	D321	1	B Handset	2982
LG	F200	1	B Handset	2983
LG	F320	1	B Handset	2984
LG	C900	1	B Handset	2985
LG	D120	6	B Handset	2986
LG	D120	1	B Handset (Power Up, Bad LCD/No Power)	2987
LG	D213N	1	B Handset	2988
LG	D213N	1	B Handset (Power Up, Bad LCD/No Power)	2989
LG	D280	14	14B	2990
LG	D280	3	B Handset	2991
LG	D290	12	B Handset (Power Up, Bad LCD/No Power)	2992
LG	D315	1	14B	2993
LG	D315	1	B Handset (Power Up, Bad LCD/No Power)	2994
LG	D320	2	B Handset	2995
LG	D331	1	B Handset (Power Up, Bad LCD/No Power)	2996
LG	D373	1	B Handset	2997
LG	D390	2	B Handset (Power Up, Bad LCD/No Power)	2998
LG	D400	1	B Handset (Power Up, Bad LCD/No Power)	2999
LG	D405	12	B Handset (Power Up, Bad LCD/No Power)	3000
LG	D410	3	B Handset (Power Up, Bad LCD/No Power)	3001
LG	D505	2	14B	3002
LG	D605	4	B Handset	3003
LG	D620	1	14B	3004
LG	D620	6	B Handset	3005
LG	D620	12	B Handset (Power Up, Bad LCD/No Power)	3006
LG	D722	3	14B	3007
LG	D722	3	B Handset	3008
LG	D722	2	B Handset (Power Up, Bad LCD/No Power)	3009
LG	D802	1	B Handset (Power Up, Bad LCD/No Power)	3010
LG	D852	1	B Handset (No Power)	3011
LG	D855	3	14B	3012
LG	E400	1	N. New Handset	3015
LG	E425	12	B Handset	3016
LG	E435	1	14B	3017
LG	E435	1	B Handset	3018
LG	E435	1	B Handset (Power Up, Bad LCD/No Power)	3019
LG	E440	7	B Handset	3020
LG	E455	5	B Handset	3021
LG	E460	3	B Handset	3022
LG	E460	4	B Handset (Power Up, Bad LCD/No Power)	3023
LG	E510	3	B Handset	3024
LG	E730	1	B Handset	3025
LG	E900	1	14B	3026
LG	E900	2	B Handset	3027
LG	E960	9	B Handset	3028
LG	E960	3	B Handset (Power Up, Bad LCD/No Power)	3029
LG	E986	3	B Handset	3030
LG	E986	3	B Handset (Power Up, Bad LCD/No Power)	3031
LG	GW305	9	B Handset	3032
LG	H221	14	B Handset	3033

Brand	Model	Total - QTY	Grade	Line
LG	H221	10	B Handset (Power Up, Bad LCD/No Power)	3034
LG	H320	3	B Handset (Power Up, Bad LCD/No Power)	3035
LG	H410	6	B Handset	3036
LG	H420	3	B Handset	3037
LG	H420	2	B Handset (Power Up, Bad LCD/No Power)	3038
LG	H440	12	B Handset (Power Up, Bad LCD/No Power)	3039
LG	H500	3	B Handset (Power Up, Bad LCD/No Power)	3041
LG	H525	14	B Handset	3043
LG	H525	5	B Handset (Power Up, Bad LCD/No Power)	3044
LG	H635	1	B Handset	3045
LG	H635	4	B Handset (Power Up, Bad LCD/No Power)	3046
LG	H735	1	B Handset	3047
LG	H735	4	B Handset (Power Up, Bad LCD/No Power)	3048
LG	H815	3	B Handset (Power Up, Bad LCD/No Power)	3050
LG	H850	2	B Handset (Power Up, Good LCD)	3051
LG	H870	1	B Handset (Power Up, Good LCD)	3053
LG	H955	5	B Handset (Power Up, Good LCD)	3055
LG	H955	2	B Handset	3056
LG	H955	7	B Handset (Power Up, Bad LCD)	3057
LG	H955	7	B Handset (No Power)	3058
LG	K100	4	B Handset	3059
LG	K100	4	B Handset (Power Up, Bad LCD/No Power)	3060
LG	K120	1	B Handset (Power Up, Good LCD)	3061
LG	K120	5	B Handset	3062
LG	K120	1	B Handset (Power Up, Bad LCD/No Power)	3063
LG	K130	3	B Handset (Power Up, Bad LCD/No Power)	3064
LG	K500	3	B Handset (Power Up, Bad LCD/No Power)	3072
LG	K580	2	B Handset (Power Up, Bad LCD/No Power)	3073
LG	KP215	1	B Handset	3074
LG	KP500	7	B Handset	3075
LG	KP501	5	B Handset	3076
LG	KP505	1	B Handset	3077
LG	M160	3	New	3078
LG	M160	2	14B	3079
LG	M200	1	14B	3081
LG	P350	9	B Handset	3087
LG	P500	1	14B	3088
LG	P690	2	B Handset	3089
LG	P700	5	B Handset	3090
LG	P705	1	B Handset	3091
LG	P710	8	14B	3092
LG	P710	12	B Handset	3093
LG	P712	1	B Handset (Power Up, Bad LCD/No Power)	3094
LG	P715	1	B Handset	3095
LG	P760	11	B Handset	3096
LG	P768	4	B Handset (Power Up, Bad LCD/No Power)	3097
LG	P769	1	B Handset (Power Up, Bad LCD/No Power)	3098
LG	P875	1	B Handset	3099
LG	P880	6	B Handset	3100
LG	P880	10	B Handset (Power Up, Bad LCD/No Power)	3101
LG	P920	5	B Handset	3102
LG	P970	17	B Handset	3103
LG	P990	14	B Handset	3104
LG	T375	2	B Handset	3105
LG	T385	2	14B	3106
LG	X140	1	B Handset	3107
LG	X210	7	B Handset	3108
LG	X210	3	B Handset (Power Up, Bad LCD/No Power)	3109
LG	H650	3	B Handset (Power Up, Bad LCD/No Power)	3110
LG	V700	1	B Handset	3111
LG	K121	1	B Handset	3113
LG	M151	1	B Handset	3114
LG	E410	1	N. New Handset	3115
LG	V490	7	14B	3116
LG	V490	5	B Handset	3117
LG	V490	1	B Handset (Power Up, Bad LCD/No Power)	3118
LG	D213	1	B Handset (Power Up, Bad LCD/No Power)	3119
LG	E450	1	B Handset	3120
LG	E612	1	B Handset	3121
LG	D685	3	B Handset (Power Up, Bad LCD/No Power)	3122
LG	X190	1	B Handset (Power Up, Bad LCD/No Power)	3123
LG	AS695	2	N. New	3124
LG	AS730	1	N. New	3125
LG	D806	1	B Handset	3127
LG	D806	1	B Handset (Power Up, Bad LCD/No Power)	3128
LG	H326	1	B Handset	3129
LG	L75c	1	N. New	3130
LG	LGL23	1	B Handset	3131
LG	X150	4	B Handset	3132
LG	X150	3	B Handset (Power Up, Bad LCD/No Power)	3133
LG	K200	2	B Handset (Power Up, Bad LCD/No Power)	3134
LG	H220	9	14B	3135
LG	H220	7	B Handset	3136
LG	D335	1	B Handset	3137
LG	KP570	1	B Handset	3138
LG	D325	1	B Handset	3139
LG	H345	1	B Handset	3140
LG	H634	1	B Handset	3141
LG	V400	1	B Handset (Power Up, Bad LCD/No Power)	3142
LG	F490	1	B Handset	3143
LG	D610	1	B Handset	3144
LG	X320	1	B Handset	3146
LG	F100	1	B Handset	3147
Ericsson	C1504 (SIM Free)	2	B Handset (Power Up, Good LCD)	3148
Ericsson	C1504	3	B Handset	3149
Ericsson	C1505	2	14B	3150
Ericsson	C1505 (SIM Free)	4	B Handset (Power Up, Good LCD)	3151
Ericsson	C1505	2	B Handset	3152
Ericsson	C1605	3	B Handset	3153
Ericsson	C1605	2	B Handset (Power Up, Bad LCD/No Power)	3154
Ericsson	C1905	1	B Handset (Power Up, Bad LCD/No Power)	3156
Ericsson	C2005	1	B Handset	3157
Ericsson	C2105	1	B Handset (Power Up, Bad LCD/No Power)	3158
Ericsson	C5303 (SIM Free)	1	B Handset (Power Up, Good LCD)	3159
Ericsson	C5502	5	B Handset	3160
Ericsson	C5503 (SIM Free)	1	B Handset (Power Up, Good LCD)	3161
Ericsson	C5503	2	B Handset	3162
Ericsson	C5503	1	B Handset (Power Up, Bad LCD/No Power)	3163
Ericsson	C6503	1	B Handset (Power Up, Bad LCD/No Power)	3164
Ericsson	C6802	1	B Handset (Power Up, Bad LCD/No Power)	3165
Ericsson	C6903	1	B Handset (No Power)	3167
Ericsson	C6906	1	B Handset (Power Up, Bad LCD/No Power)	3168
Ericsson	C6943	1	B Handset (Power Up, Bad LCD/No Power)	3169
Ericsson	CK151	1	B Handset	3171
Ericsson	CK151	2	B Handset (Power Up, Bad LCD/No Power)	3172
Ericsson	D2005	15	B Handset (Power Up, Bad LCD/No Power)	3174
Ericsson	D2105	1	B Handset (Power Up, Bad LCD/No Power)	3175
Ericsson	D2303	12	B Handset	3176
Ericsson	D2303	6	B Handset (Power Up, Bad LCD/No Power)	3177
Ericsson	D2306	3	B Handset	3178

Brand	Model	Total - QTY	Grade	Line
Ericsson	D2306	3	B Handset (Power Up, Bad LCD/No Power)	3179
Ericsson	D2403	6	B Handset	3180
Ericsson	D2403	1	B Handset (Power Up, Bad LCD/No Power)	3181
Ericsson	D2502 (SIM Free)	1	B Handset (Power Up, Good LCD)	3182
Ericsson	D2502	2	B Handset	3183
Ericsson	D2502	2	B Handset (Power Up, Bad LCD/No Power)	3184
Ericsson	D5303 (SIM Free)	2	B Handset (Power Up, Good LCD)	3186
Ericsson	D5303	1	B Handset	3187
Ericsson	D5306	7	B Handset	3189
Ericsson	E2003	6	B Handset	3196
Ericsson	E2053	6	B Handset (Power Up, Bad LCD/No Power)	3197
Ericsson	E2105	1	B Handset	3199
Ericsson	E2303	1	N. New	3200
Ericsson	E2303	3	B Handset (Power Up, Bad LCD)	3202
Ericsson	E2306	2	B Handset (Power Up, Bad LCD)	3203
Ericsson	E2306	2	B Handset (No Power)	3204
Ericsson	E2333	1	B Handset (Power Up, Good LCD)	3205
Ericsson	E2353	2	B Handset (Power Up, Bad LCD)	3206
Ericsson	E2353	4	B Handset (No Power)	3207
Ericsson	E5303 (SIM Free)	1	B Handset (Power Up, Good LCD)	3208
Ericsson	E5306	4	B Handset (Power Up, Good LCD)	3209
Ericsson	E5333	1	B Handset (No Power)	3210
Ericsson	E5353	3	B Handset (Power Up, Good LCD)	3211
Ericsson	E5353	3	B Handset	3212
Ericsson	E5353	2	B Handset (Power Up, Bad LCD)	3213
Ericsson	E5363 (SIM Free)	1	B Handset (Power Up, Good LCD)	3214
Ericsson	E5506	1	B Handset (No Power)	3215
Ericsson	E5533	1	B Handset (Power Up, Bad LCD)	3216
Ericsson	E5563	1	B Handset (Power Up, Bad LCD)	3217
Ericsson	E5603	1	B Handset (Power Up, Good LCD)	3219
Ericsson	E5603	1	B Handset (Power Up, Bad LCD)	3220
Ericsson	E5653	1	B Handset (No Power)	3221
Ericsson	E5823	2	N. New	3222
Ericsson	E5823	3	B Handset (No Power)	3224
Ericsson	E6533	3	B Handset (Power Up, Bad LCD)	3225
Ericsson	E6553 (SIM Free)	1	B Handset (Power Up, Good LCD)	3226
Ericsson	E6553	2	B Handset (No Power)	3227
Ericsson	E6603	11	B Handset (Power Up, Good LCD)	3228
Ericsson	E6853	3	B Handset (Power Up, Good LCD)	3230
Ericsson	E6853	2	B Handset (Power Up, Bad LCD)	3231
Ericsson	F3115 (SIM Free)	2	B Handset (Power Up, Good LCD)	3233
Ericsson	F3211	1	14B	3234
Ericsson	F3211 (SIM Free)	1	B Handset (Power Up, Good LCD)	3235
Ericsson	F3211	5	B Handset (Power Up, Bad LCD)	3236
Ericsson	F3212	1	B Handset (Power Up, Good LCD)	3237
Ericsson	F5121	9	B Handset (No Power)	3241
Ericsson	F8131	5	B Handset (Power Up, Bad LCD)	3242
Ericsson	F8131	3	B Handset (No Power)	3243
Ericsson	F8331 (SIM Free)	2	N. New Handset	3244
Ericsson	F8331 (SIM Free)	8	A Handset	3245
Ericsson	F8331	2	B Handset	3246
Ericsson	F8331	6	B Handset (No Power)	3247
Ericsson	G3121 (With Code)	2	N. New	3248
Ericsson	G3121	1	B Handset (No Power)	3250
Ericsson	G3311 (With Code)	1	New	3251
Ericsson	G3311	2	B Handset	3252
Ericsson	G3311	7	B Handset (No Power)	3254
Ericsson	G3313	3	B Handset (Power Up, Bad LCD)	3256
Ericsson	G8141	4	B Handset (No Power)	3257
Ericsson	G8231	1	B Handset (Power Up, Bad LCD)	3258
Ericsson	G8231	1	B Handset (No Power)	3259
Ericsson	G8341 (With Code)	1	New	3260
Ericsson	G8441	2	B Handset (No Power)	3261
Ericsson	H8216 (With Code)	1	N. New	3265
Ericsson	K810	2	B Handset	3266
Ericsson	LT22i	3	B Handset (Power Up, Bad LCD/No Power)	3267
Ericsson	LT25i	1	B Handset	3268
Ericsson	LT28i (SIM Free)	2	B Handset (Power Up, Good LCD)	3269
Ericsson	LT28i	2	B Handset (Power Up, Bad LCD/No Power)	3270
Ericsson	LT36	2	B Handset (Power Up, Bad LCD/No Power)	3272
Ericsson	MK16i (SIM Free)	8	B Handset (Power Up, Good LCD)	3273
Ericsson	MK16i	5	B Handset	3274
Ericsson	MT11i	7	B Handset	3275
Ericsson	MT15i	2	B Handset	3276
Ericsson	R800	1	B Handset (Power Up, Bad LCD/No Power)	3277
Ericsson	SGPT111	1	B Handset	3278
Ericsson	SGPT311 (SIM Free)	2	B Handset (Power Up, Good LCD)	3279
Ericsson	SGPT311	1	B Handset (Power Up, Bad LCD/No Power)	3280
Ericsson	SGPT321 (SIM Free)	2	B Handset (Power Up, Good LCD)	3281
Ericsson	SGPT321	1	B Handset	3282
Ericsson	SGPT321	3	B Handset (Power Up, Bad LCD/No Power)	3283
Ericsson	SGPT511 (SIM Free)	2	B Handset (Power Up, Good LCD)	3284
Ericsson	SGPT511	2	B Handset (Power Up, Bad LCD/No Power)	3285
Ericsson	SGPT621	1	B Handset (Power Up, Bad LCD)	3286
Ericsson	SGPT621	1	B Handset (No Power)	3287
Ericsson	SGPT771	1	B Handset (Power Up, Bad LCD)	3288
Ericsson	SK17i (SIM Free)	1	B Handset (Power Up, Good LCD)	3289
Ericsson	SO-02G	1	B Handset	3290
Ericsson	SO-04G	1	B Handset	3291
Ericsson	ST15i (SIM Free)	1	B Handset (Power Up, Good LCD)	3292
Ericsson	ST17i	14	B Handset	3293
Ericsson	ST17i	4	B Handset (Power Up, Bad LCD/No Power)	3294
Ericsson	ST18i (SIM Free)	1	B Handset (Power Up, Good LCD)	3295
Ericsson	ST21i (SIM Free)	2	B Handset (Power Up, Good LCD)	3296
Ericsson	ST25i	13	B Handset (Power Up, Bad LCD/No Power)	3297
Ericsson	ST27i (SIM Free)	1	B Handset (Power Up, Good LCD)	3298
Ericsson	ST27i	8	B Handset (Power Up, Bad LCD/No Power)	3299
Ericsson	T700	5	B Handset	3300
Ericsson	U10i	8	B Handset	3301
Ericsson	W20i	2	B Handset	3302
Ericsson	W350	1	B Handset	3303
Ericsson	W508	8	B Handset	3304
Ericsson	W715	1	B Handset	3305
Ericsson	X8 (SIM Free)	3	B Handset (Power Up, Good LCD)	3306
Ericsson	Z750	2	B Handset	3307
Ericsson	E5663 (SIM Free)	1	B Handset (Power Up, Good LCD)	3308
Ericsson	G3221	1	14B	3309
Ericsson	G3221	4	B Handset (Power Up, Bad LCD)	3310
Ericsson	C2304	1	B Handset	3311
Ericsson	SGPT521	3	B Handset (Power Up, Good LCD)	3313
Ericsson	SGPT521	1	B Handset (Power Up, Bad LCD)	3314
Ericsson	D2305 (SIM Free)	1	N. New Handset	3315
Ericsson	D5322 (SIM Free)	2	B Handset (Power Up, Good LCD)	3316
Ericsson	SGPT512 (SIM Free)	1	B Handset (Power Up, Good LCD)	3317
Ericsson	SGPT712	1	B Handset (Power Up, Bad LCD)	3318
Ericsson	C6902	1	B Handset (Power Up, Bad LCD/No Power)	3319
Ericsson	SGPT611	1	B Handset (No Power)	3320
Ericsson	C5302 (SIM Free)	1	B Handset (Power Up, Good LCD)	3321
BlackBerry	BB8520	6	B Handset	3322
BlackBerry	BB9000	1	B Handset (Power Up, Bad LCD/No Power)	3323

Brand	Model	Total - QTY	Grade	Line
BlackBerry	BB9105	1	B Handset (Power Up, Bad LCD/No Power)	3326
BlackBerry	BB9300	6	B Handset	3327
BlackBerry	BB9360	7	B Handset (Power Up, Bad LCD/No Power)	3328
BlackBerry	BB9700	1	B Handset (Power Up, Bad LCD/No Power)	3329
BlackBerry	BB9780	2	B Handset (Power Up, Bad LCD/No Power)	3331
BlackBerry	BB9780 (Non-qwerty)	14	B Handset	3332
BlackBerry	BB9800	17	B Handset	3333
BlackBerry	BB9810	18	B Handset	3334
BlackBerry	BB9810 (Non-qwerty)	7	B Handset	3335
BlackBerry	BB9810 (Non-qwerty)	2	B Handset (Power Up, Bad LCD/No Power)	3336
BlackBerry	BB9860	13	B Handset	3337
BlackBerry	BB9900 (Non-qwerty)	2	B Handset (Power Up, Bad LCD/No Power)	3338
BlackBerry	Keyone	2	B Handset (Power Up, Good LCD)	3339
BlackBerry	Keyone (Non-qwerty)	3	B Handset (Power Up, Good LCD)	3340
BlackBerry	Leap (With Code)	2	B Handset (Power Up, Good LCD)	3341
BlackBerry	Leap	15	B Handset (Power Up, Bad LCD/No Power)	3342
BlackBerry	Playbook (16GB)	1	B Handset	3344
BlackBerry	Playbook (16GB)	1	B Handset (Power Up, Bad LCD/No Power)	3345
BlackBerry	Playbook (32GB)	1	B Handset	3346
BlackBerry	Playbook (32GB)	2	B Handset (Power Up, Bad LCD/No Power)	3347
BlackBerry	Playbook (64GB)	1	B Handset	3348
BlackBerry	Playbook (64GB)	1	B Handset (Power Up, Bad LCD/No Power)	3349
BlackBerry	Priv (Non-qwerty)	7	B Handset	3353
BlackBerry	Q20	1	B Handset (Power Up, Good LCD)	3354
BlackBerry	Z10	7	14B	3355
BlackBerry	Z10 (SIM Free)	1	B Handset (Power Up, Good LCD)	3356
BlackBerry	Z10	2	B Handset	3357
BlackBerry	Z10	18	B Handset (Power Up, Bad LCD/No Power)	3358
BlackBerry	Z3 (SIM Free)	4	B Handset (Power Up, Good LCD)	3359
BlackBerry	Z3	14	B Handset	3360
BlackBerry	Z3	1	B Handset (Power Up, Bad LCD/No Power)	3361
BlackBerry	Z30 4G	5	B Handset (Power Up, Bad LCD/No Power)	3362
BlackBerry	BB9790 (Non-qwerty)	1	B Handset (Power Up, Bad LCD/No Power)	3364
BlackBerry	P9982	1	B Handset (Power Up, Good LCD)	3365
BlackBerry	BB8820	2	B Handset	3366
Nokia	N900	3	B Handset	3367
Nokia	N900	4	B Handset (Power Up, Bad LCD/No Power)	3368
Nokia	2730C-1B	2	B Handset	3369
Nokia	6600S-1C	5	B Handset	3370
Nokia	E61-1	5	B Handset	3371
Nokia	928	1	B Handset (Power Up, Bad LCD/No Power)	3372
Nokia	109	2	B Handset	3373
Nokia	205	8	B Handset	3374
Nokia	215	1	N. New Handset	3375
Nokia	222	1	14B	3376
Nokia	222	2	B Handset	3377
Nokia	300	1	B Handset	3378
Nokia	302	8	14B	3379
Nokia	303 (SIM Free)	3	B Handset (Power Up, Good LCD)	3380
Nokia	305 (SIM Free)	2	B Handset (Power Up, Good LCD)	3381
Nokia	540	4	B Handset (Power Up, Bad LCD/No Power)	3382
Nokia	636 (SIM Free)	2	B Handset (Power Up, Good LCD)	3383
Nokia	636	2	B Handset	3384
Nokia	700 (SIM Free)	1	B Handset (Power Up, Good LCD)	3385
Nokia	700	3	B Handset	3386
Nokia	735	3	B Handset (Power Up, Bad LCD/No Power)	3388
Nokia	930 (SIM Free)	1	B Handset (Power Up, Good LCD)	3389
Nokia	1508	9	B Handset	3391
Nokia	1606	3	B Handset	3392
Nokia	2505	3	B Handset	3393
Nokia	2520	1	B Handset	3394
Nokia	3100	3	B Handset	3395
Nokia	5000	1	B Handset	3396
Nokia	5220	2	B Handset	3397
Nokia	6276	6	B Handset	3398
Nokia	7370	14	B Handset	3399
Nokia	8820	1	B Handset	3400
Nokia	130 (2017)	1	N. New Handset	3401
Nokia	1680C	3	B Handset	3402
Nokia	2220S	16	B Handset	3403
Nokia	2323C	1	B Handset	3404
Nokia	2330C	1	B Handset	3405
Nokia	2600C	4	B Handset	3406
Nokia	3109C	5	B Handset	3407
Nokia	3110C	9	B Handset	3408
Nokia	3310 (2017) (With Code)	8	14B	3409
Nokia	3720C	1	B Handset	3410
Nokia	6310i	4	B Handset (Power Up, Bad LCD/No Power)	3411
Nokia	640XL	1	B Handset (Power Up, Bad LCD/No Power)	3412
Nokia	6600S	4	B Handset	3413
Nokia	6700C	16	B Handset (Power Up, Bad LCD/No Power)	3414
Nokia	6760s	3	B Handset	3415
Nokia	7210S	6	B Handset	3416
Nokia	7230S	18	B Handset	3417
Nokia	C1	3	B Handset	3418
Nokia	C1-01	1	B Handset	3419
Nokia	C1-02	1	B Handset	3420
Nokia	C2-01	1	B Handset	3421
Nokia	E60	1	B Handset	3422
Nokia	E7	1	B Handset	3424
Nokia	E90	17	B Handset (Power Up, Bad LCD/No Power)	3425
Nokia	N78	2	B Handset	3426
Nokia	N81 (8GB)	2	B Handset	3428
Nokia	N9	3	B Handset (Power Up, Bad LCD/No Power)	3429
Nokia	N95	7	B Handset (Power Up, Bad LCD/No Power)	3430
Nokia	N97	14	B Handset	3431
Nokia	N97	10	B Handset (Power Up, Bad LCD/No Power)	3432
Nokia	N97 Mini	1	B Handset	3433
Nokia	N-Gage	2	B Handset	3434
Nokia	1	1	B Handset (Power Up, Bad LCD/No Power)	3435
Nokia	2	1	B Handset (No Power)	3436
Nokia	2	1	B Handset (Power Up, Bad LCD/No Power)	3437
Nokia	3	1	B Handset	3439
Nokia	6	17	B Handset (Power Up, Good LCD)	3441
Nokia	7 Plus (With Code)	1	B Handset (Power Up, Good LCD)	3443
Nokia	8	1	B Handset (Power Up, Bad LCD)	3444
Nokia	X (SIM Free)	1	B Handset (Power Up, Good LCD)	3445
Nokia	X	7	B Handset	3446
Nokia	X	8	B Handset (Power Up, Bad LCD/No Power)	3447
Nokia	XL (SIM Free)	1	B Handset (Power Up, Good LCD)	3448
Nokia	XL	4	B Handset	3449
Nokia	XL	8	B Handset (Power Up, Bad LCD/No Power)	3450
Nokia	X1	5	B Handset	3451
Nokia	X1-01	2	B Handset	3452
Nokia	X2-02	3	B Handset	3453
Nokia	X2-02	6	B Handset (Power Up, Bad LCD/No Power)	3454
Nokia	X7	5	B Handset	3455
Nokia	306 (SIM Free)	2	B Handset (Power Up, Good LCD)	3456
Nokia	306	1	B Handset	3457
Nokia	520	2	N. New	3458

Brand	Model	Total - QTY	Grade	Line
Nokia	520	1	14C	3459
Nokia	635 (SIM Free)	1	N. New Handset	3460
Nokia	640	15	N. New	3461
Nokia	640 (SIM Free)	3	N. New Handset	3463
Nokia	640	7	B Handset (Power Up, Bad LCD/No Power)	3464
Nokia	830	12	B Handset	3465
Nokia	830	3	B Handset (Power Up, Bad LCD/No Power)	3466
Nokia	106	9	B Handset	3467
Nokia	130	3	N. New Handset	3468
Nokia	130	18	B Handset (Power Up, Bad LCD/No Power)	3469
Nokia	625	1	N. New	3470
Nokia	625	1	14C	3471
Nokia	650	1	N. New Handset	3472
Nokia	650	4	B Handset (Power Up, Bad LCD)	3473
Nokia	650	4	B Handset (Power Up, Bad LCD/No Power)	3474
Nokia	925 (SIM Free)	18	14B	3476
Nokia	925 (SIM Free)	1	B Handset (Power Up, Good LCD)	3477
Nokia	925	10	B Handset	3478
Nokia	1800	18	B Handset	3479
Nokia	2610	11	B Handset	3480
Nokia	3120	3	B Handset	3481
Nokia	550	3	14B	3482
Nokia	550 (SIM Free)	5	N. New Handset	3483
Nokia	550 (With Code)	1	B Handset (Power Up, Good LCD)	3484
Nokia	550	7	B Handset (Power Up, Bad LCD/No Power)	3485
Nokia	1208	6	B Handset (Power Up, Bad LCD/No Power)	3486
Nokia	6301	13	B Handset (Power Up, Bad LCD/No Power)	3487
Nokia	8600	3	B Handset (Power Up, Bad LCD/No Power)	3488
Nokia	900	1	B Handset (Power Up, Bad LCD/No Power)	3489
Nokia	101 (SIM Free)	2	B Handset (Power Up, Good LCD)	3490
Nokia	101	7	B Handset	3491
Nokia	820 (With Code)	1	B Handset (Power Up, Good LCD)	3492
Nokia	820	2	B Handset	3493
Nokia	110	4	B Handset (Power Up, Bad LCD/No Power)	3494
Nokia	620 (SIM Free)	1	N. New Handset	3495
Nokia	920 (SIM Free)	1	14B	3496
Nokia	920	18	B Handset (Power Up, Bad LCD/No Power)	3497
Nokia	206	9	B Handset	3498
Nokia	308	1	B Handset (Power Up, Bad LCD/No Power)	3499
Nokia	2228	3	B Handset	3500
Nokia	2228	1	B Handset (Power Up, Bad LCD/No Power)	3501
Nokia	505	3	B Handset	3502
Nokia	505	2	B Handset (Power Up, Bad LCD/No Power)	3503
Nokia	630 (With Code)	1	B Handset (Power Up, Good LCD)	3504
Nokia	1320	1	B Handset	3505
Nokia	535	4	N. New	3507
Nokia	535 (SIM Free)	2	N. New Handset	3508
Nokia	535	5	B Handset (Power Up, Bad LCD/No Power)	3509
Nokia	435	9	B Handset (Power Up, Bad LCD/No Power)	3510
Nokia	532	7	14B	3511
Nokia	8208	8	B Handset	3512
Nokia	8208	1	B Handset (Power Up, Bad LCD/No Power)	3513
Nokia	1506	4	B Handset	3514
Nokia	1506	1	B Handset (Power Up, Bad LCD/No Power)	3515
Nokia	150	2	B Handset	3516
Nokia	150	4	B Handset (Power Up, Bad LCD/No Power)	3517
Nokia	100 (With Code)	2	B Handset (Power Up, Good LCD)	3518
Nokia	301 (With Code)	2	B Handset (Power Up, Good LCD)	3519
Nokia	1100	3	B Handset	3520
Nokia	1600	4	B Handset	3521
Nokia	1616	11	B Handset	3522
Nokia	1661	2	B Handset	3523
Nokia	2112	17	B Handset	3524
Nokia	2626	7	B Handset	3525
Nokia	2630	1	B Handset	3526
Nokia	6300	2	B Handset	3527
Nokia	6600	3	B Handset	3528
Nokia	111 (SIM Free)	8	B Handset (Power Up, Good LCD)	3529
Nokia	105 (2017)	4	B Handset (Power Up, Bad LCD/No Power)	3530
Nokia	6015	5	B Handset	3531
Nokia	107	6	B Handset	3532
Nokia	107	6	B Handset (Power Up, Bad LCD/No Power)	3533
Nokia	8910	1	B Handset	3534
Nokia	1661B	3	B Handset	3535
Nokia	5220B	1	B Handset	3536
Nokia	5800B	1	B Handset	3537
Nokia	X2DS	1	B Handset	3538
HTC	10	2	B Handset (Power Up, Good LCD)	3540
HTC	7 Mozart	7	B Handset	3541
HTC	7 Trophy	17	B Handset	3542
HTC	85	8	B Handset	3543
HTC	8X	1	B Handset	3544
HTC	8X	11	B Handset (Power Up, Bad LCD/No Power)	3545
HTC	Desire	1	14B	3546
HTC	Desire	8	B Handset	3547
HTC	Desire	1	B Handset (Power Up, Bad LCD/No Power)	3548
HTC	Desire 10 Lifestyle	1	B Handset	3550
HTC	Desire 200	8	B Handset	3551
HTC	Desire 310	2	B Handset	3553
HTC	Desire 320	6	B Handset	3554
HTC	Desire 510	1	B Handset (Power Up, Bad LCD/No Power)	3556
HTC	Desire 516	1	B Handset	3557
HTC	Desire 516	9	B Handset (Power Up, Bad LCD/No Power)	3558
HTC	Desire 520	2	B Handset	3559
HTC	Desire 520	1	B Handset (Power Up, Bad LCD/No Power)	3560
HTC	Desire 610	2	B Handset (Power Up, Bad LCD/No Power)	3563
HTC	Desire 620	1	B Handset	3564
HTC	Desire 620	1	B Handset (Power Up, Bad LCD/No Power)	3565
HTC	Desire 820	1	B Handset	3569
HTC	Desire 825	5	B Handset	3570
HTC	Desire C	1	N. New	3572
HTC	Desire C	10	B Handset (Power Up, Bad LCD/No Power)	3573
HTC	Desire Eye	1	B Handset	3574
HTC	Desire HD	2	B Handset	3575
HTC	Desire S	7	B Handset	3576
HTC	Desire Z	1	B Handset	3577
HTC	Droid	10	B Handset	3578
HTC	First	1	B Handset	3579
HTC	Incredible S	13	B Handset	3580
HTC	One A9	12	B Handset (Power Up, Bad LCD)	3582
HTC	One A9	12	B Handset (No Power)	3583
HTC	One A9S	1	B Handset (No Power)	3584
HTC	One M9	2	B Handset	3588
HTC	One M9 Plus	1	B Handset (Power Up, Bad LCD)	3589
HTC	One Mini	6	B Handset	3590
HTC	One Mini	2	B Handset (Power Up, Bad LCD/No Power)	3591
HTC	One Mini II	3	B Handset (Power Up, Bad LCD/No Power)	3593
HTC	One S9	1	B Handset (Power Up, Bad LCD/No Power)	3595
HTC	One SV 4G	2	B Handset (Power Up, Bad LCD/No Power)	3596
HTC	One V	4	B Handset	3597

Brand	Model	Total - QTY	Grade	Line
HTC	One X	1	B Handset	3598
HTC	One X	12	B Handset (Power Up, Bad LCD/No Power)	3599
HTC	One X+	1	B Handset	3600
HTC	One X9	1	B Handset	3601
HTC	One X9	1	B Handset (No Power)	3602
HTC	Radar	15	B Handset	3603
HTC	Raider 4G	1	B Handset	3604
HTC	Rhyme	6	B Handset	3605
HTC	Rhyme	2	B Handset (Power Up, Bad LCD/No Power)	3606
HTC	Sensation	2	B Handset (Power Up, Bad LCD/No Power)	3607
HTC	Sensation XL	18	B Handset	3608
HTC	Sensation XL	18	B Handset (Power Up, Bad LCD/No Power)	3609
HTC	Titan	14	B Handset	3610
HTC	U11	6	B Handset (Power Up, Good LCD)	3613
HTC	U11 Life (With Code)	1	B Handset (Power Up, Good LCD)	3615
HTC	U11 Life	2	B Handset (No Power)	3616
HTC	Velocity 4G	1	B Handset	3617
HTC	Velocity 4G	2	B Handset (Power Up, Bad LCD/No Power)	3618
HTC	Wildfire S	6	B Handset	3619
HTC	Desire 526	14	B Handset	3620
HTC	Dragon	1	N. New	3622
HTC	Dragon	1	B Handset	3623
HTC	Hero	4	14B	3625
Motorola	XT1723	4	B Handset	3626
Motorola	ES400	5	B Handset	3627
Motorola	MB511	1	B Handset	3628
Motorola	MB526	1	B Handset	3629
Motorola	MB526	5	B Handset (Power Up, Bad LCD/No Power)	3630
Motorola	MB860	4	B Handset	3631
Motorola	V3i	3	B Handset	3632
Motorola	V8	18	B Handset (Power Up, Bad LCD/No Power)	3633
Motorola	V9	1	B Handset	3634
Motorola	XT1021	1	B Handset	3635
Motorola	XT1021	14	B Handset (Power Up, Bad LCD/No Power)	3636
Motorola	XT1022	2	B Handset	3637
Motorola	XT1032	1	B Handset	3638
Motorola	XT1032	9	B Handset (Power Up, Bad LCD/No Power)	3639
Motorola	XT1039	10	B Handset	3640
Motorola	XT1039	3	B Handset (Power Up, Bad LCD/No Power)	3641
Motorola	XT1052	1	B Handset (Power Up, Bad LCD/No Power)	3642
Motorola	XT1063	4	B Handset (Power Up, Bad LCD/No Power)	3643
Motorola	XT1068	3	B Handset (Power Up, Bad LCD/No Power)	3645
Motorola	XT1527	1	B Handset (Power Up, Bad LCD/No Power)	3649
Motorola	XT1541	3	B Handset	3650
Motorola	XT1541	6	B Handset (Power Up, Bad LCD/No Power)	3651
Motorola	XT1621	1	B Handset (Power Up, Bad LCD/No Power)	3652
Motorola	XT1622	15	B Handset	3653
Motorola	XT1622	7	B Handset (Power Up, Bad LCD/No Power)	3654
Motorola	XT1675	7	B Handset	3656
Motorola	XT1676	2	B Handset	3657
Motorola	XT1754	2	N. New Handset	3658
Motorola	XT1754	7	B Handset	3659
Motorola	XT1754	12	B Handset (Power Up, Bad LCD/No Power)	3660
Motorola	XT1756	1	B Handset (Power Up, Bad LCD/No Power)	3661
Motorola	XT1761	1	B Handset (Power Up, Bad LCD/No Power)	3662
Motorola	XT1771	1	B Handset	3663
Motorola	XT316	8	B Handset	3664
Motorola	XT611	4	B Handset	3665
Motorola	XT615	1	B Handset	3666
Motorola	XT860	4	B Handset	3667
Motorola	XT890	1	B Handset	3668
Motorola	MZ601	3	B Handset (Power Up, Bad LCD/No Power)	3669
Motorola	MZ616	2	B Handset (Power Up, Bad LCD/No Power)	3670
Motorola	MB865	6	B Handset	3671
Motorola	MB865	1	B Handset (Power Up, Bad LCD/No Power)	3672
Motorola	XT1758	1	B Handset (Power Up, Bad LCD/No Power)	3676
Motorola	MZ605	1	B Handset (Power Up, Bad LCD/No Power)	3677
Motorola	XT1040	3	B Handset (Power Up, Bad LCD/No Power)	3678
Motorola	XT1023	1	B Handset	3679
Motorola	XT1058	1	B Handset (Power Up, Bad LCD/No Power)	3680
Motorola	XT1550	1	B Handset (Power Up, Bad LCD/No Power)	3682
Motorola	XT1254	1	B Handset	3683
Vodafone	Smart 4G	1	B Handset	3685
Vodafone	V1497	2	B Handset	3686
Vodafone	V655	5	B Handset	3687
Vodafone	V685	4	B Handset	3688
Vodafone	V795	5	B Handset	3689
Vodafone	V795	15	B Handset (Power Up, Bad LCD/No Power)	3690
Vodafone	V860	3	B Handset	3691
Vodafone	V875	19	B Handset (Power Up, Bad LCD/No Power)	3692
Vodafone	V888	1	B Handset (Power Up, Bad LCD/No Power)	3693
Vodafone	V975	2	B Handset	3694
Vodafone	V995	1	B Handset	3695
Vodafone	VFD 1400	1	B Handset	3696
Vodafone	VFD 200	11	B Handset (Power Up, Bad LCD/No Power)	3697
Vodafone	VFD 300	6	B Handset	3698
Vodafone	VFD 500	9	B Handset	3699
Vodafone	VFD 500	1	B Handset (Power Up, Bad LCD/No Power)	3700
Vodafone	VFD 501	2	B Handset	3701
Vodafone	VFD 511	2	14B	3702
Vodafone	VFD 511	2	N. New Handset	3703
Vodafone	VFD 511	1	B Handset	3704
Vodafone	VFD 513	4	B Handset (Power Up, Bad LCD/No Power)	3705
Vodafone	VFD 600	15	B Handset	3707
Vodafone	VFD 610	7	14B	3708
Vodafone	VFD 610	3	B Handset	3709
Vodafone	VFD 610	2	B Handset (Power Up, Bad LCD/No Power)	3710
Vodafone	VFD 700	1	B Handset	3711
Vodafone	VFD 700	2	B Handset (Power Up, Bad LCD/No Power)	3712
Vodafone	V695	1	B Handset	3713
Vodafone	VFD 510	3	B Handset	3714
Vodafone	VFD 900	2	B Handset (Power Up, Bad LCD/No Power)	3716
Vodafone	VFD 301	1	B Handset	3717
PC	Home Server SD	4	14A	3718
PC	Q10 Air	1	14A	3720
Other	LDN-L21	1	B Handset	3721
Other	Cat B30	1	14B	3725
Other	Cat B30	2	B Handset	3726
Other	Cat B30	3	B Handset (Power Up, Bad LCD/No Power)	3727
Other	Cat S30	6	B Handset	3728
Other	Cat S40	13	B Handset	3729
Other	Cat S40	5	B Handset (Power Up, Bad LCD/No Power)	3730
Other	Cat S50	15	B Handset	3731
Other	Cat S60	9	B Handset	3732
Other	Cat S60	2	B Handset (Power Up, Bad LCD/No Power)	3733
Other	Doro 5030	1	N. New	3734
Other	Doro 5030	1	N. New Handset	3735
Other	Doro 5030	4	B Handset (Power Up, Bad LCD/No Power)	3736
Other	Doro 6030	2	B Handset	3737
Other	Doro 6030	2	B Handset (Power Up, Bad LCD/No Power)	3738

Brand	Model	Total - QTY	Grade	Line
Other	Doro 6520	12	B Handset	3739
Other	Doro 6520	3	B Handset (Power Up, Bad LCD/No Power)	3740
Other	Doro 6530	2	B Handset	3741
Other	Doro 8042	1	B Handset	3742
Other	Doro PE413	12	B Handset	3743
Other	Doro PE612	2	B Handset	3744
Other	Doro PE612	1	B Handset (Power Up, Bad LCD/No Power)	3745
Other	Doro PE820	1	B Handset (Power Up, Bad LCD/No Power)	3746
Other	Doro PE820 Mini	1	N. New Handset	3747
Other	Doro PE820 Mini	1	B Handset	3748
Other	Doro PE820 Mini	1	B Handset (Power Up, Bad LCD/No Power)	3749
Other	Google G011A	1	B Handset (No Power)	3750
Other	Google G011C	1	B Handset (Power Up, Bad LCD)	3751
Other	Google G-2PW2200 (With Code)	1	14B	3753
Other	Google G-2PW4200 (With Code)	2	B Handset (Power Up, Good LCD)	3756
Other	Google G-2PW4200	1	B Handset (Power Up, Bad LCD)	3757
Other	Google G-2PW4200	9	B Handset (No Power)	3758
Other	Harrier	5	B Handset (Power Up, Bad LCD/No Power)	3759
Other	Harrier Mini	10	B Handset	3760
Other	Harrier Rook	8	N. New Handset	3761
Other	Harrier Rook	5	B Handset	3762
Other	Harrier Rook	2	B Handset (Power Up, Bad LCD/No Power)	3763
Other	Harrier Tab	3	B Handset	3764
Other	Kazam Thunder 2 5.0	1	B Handset	3766
Other	Lenovo A1010	1	B Handset	3767
Other	Lenovo A2016	4	14B	3768
Other	Lenovo A2016	1	B Handset	3769
Other	Lenovo A2016	2	B Handset (Power Up, Bad LCD/No Power)	3770
Other	Lenovo A316	1	B Handset	3771
Other	Lenovo A319	1	B Handset	3772
Other	Lenovo A369	5	B Handset	3773
Other	Lenovo A526	1	B Handset	3774
Other	Lenovo A536	1	B Handset	3775
Other	Lenovo A6000	2	N. New	3776
Other	Lenovo A6020	1	B Handset	3777
Other	Lenovo A706	1	B Handset (Power Up, Bad LCD/No Power)	3778
Other	Lenovo A816	1	B Handset	3780
Other	Lenovo A850	1	B Handset	3781
Other	Lenovo A859	1	B Handset	3782
Other	Lenovo K10A40	5	B Handset	3783
Other	Lenovo P1MA40	14	14B	3784
Other	Lenovo P1MA40	4	B Handset	3785
Other	Lenovo Tab 2 A10-70	1	B Handset	3786
Other	Lenovo Tab 2 A7-20	1	B Handset	3787
Other	Lenovo Tab 2 X30	2	B Handset	3788
Other	Lenovo Tab 2 X30	2	B Handset (Power Up, Bad LCD/No Power)	3789
Other	Lenovo Tab 3-710F	1	B Handset	3790
Other	One Plus	1	B Handset	3791
Other	One Plus X	4	B Handset (Power Up, Bad LCD/No Power)	3793
Other	Wiko HIGHWAY SIGNS	2	B Handset	3794
Other	Wiko LENNY 2	1	B Handset	3795
Other	Wiko RAINBOW JAM	2	B Handset	3796
Other	Wiko RIDGE 4G	6	B Handset	3797
Other	Wiko RIDGE FAB 4G	1	B Handset	3798
Other	Xiaomi Redmi Note 4X	5	B Handset	3799
Other	Mixed 平板	12	B Handset	3800
Other	Lenovo B8000	2	B Handset	3801
Other	Lenovo S6000	3	B Handset	3802
Other	Wiko LENNY	14	B Handset	3803
Other	BQ Aquaris x Pro	2	B Handset	3804
Other	Lenovo P2A42	2	B Handset (Power Up, Bad LCD/No Power)	3805
Other	Lenovo A1000	1	B Handset	3806
Other	Lenovo K33a48	8	B Handset	3807
Other	AZ210	2	B Handset	3808
Other	Doro 5516	2	B Handset	3809
Other	Doro PE508	1	B Handset	3810
Other	Amazon Firephone	1	B Handset	3812
Other	Amazon Firephone	1	B Handset (Power Up, Bad LCD/No Power)	3813
Other	Lenovo A2010	1	14B	3816
Other	Lenovo A2010	1	B Handset (Power Up, Bad LCD/No Power)	3817
Other	BQ Aquaris U2	2	B Handset	3819
Other	Kazam Life B7	4	B Handset	3820
Other	Acer ESW60	1	14C	3821
Other	NDS	4	14C	3822
Other	Play Station 2	1	14C	3823
Other	Wii	1	14C	3824
Other	Lenovo A7700	1	B Handset	3825
Other	Lenovo S856	1	B Handset (Power Up, Bad LCD/No Power)	3826
Other	Lenovo a3500	3	B Handset	3827
Other	Lenovo Tab2 A7-20	1	B Handset	3828
Other	Lenovo Tab2 A7-30	3	B Handset	3829
Other	Xiaomi Redmi 3	1	B Handset (Power Up, Bad LCD/No Power)	3830
Other	Telenor K530	7	14B	3833
Other	Lenovo S1LA40	9	14B	3835
ZTE	DUA-L22	1	B Handset	3841
ZTE	Blade A110	1	N. New Handset	3842
ZTE	Blade A110	5	B Handset	3843
ZTE	Blade A110	2	B Handset (Power Up, Bad LCD/No Power)	3844
ZTE	Blade A430	1	B Handset	3845
ZTE	Blade A452	4	B Handset	3846
ZTE	Blade A462	19	B Handset	3847
ZTE	Blade Apex II	1	B Handset (Power Up, Bad LCD/No Power)	3848
ZTE	Blade Apex III	1	B Handset	3849
ZTE	Blade C2	7	B Handset	3850
ZTE	Blade C341	2	N. New	3851
ZTE	Blade C341	1	B Handset	3852
ZTE	Blade L110	3	B Handset	3853
ZTE	Blade L110	1	B Handset (Power Up, Bad LCD/No Power)	3854
ZTE	Blade L2	4	B Handset	3855
ZTE	Blade L2	1	B Handset (Power Up, Bad LCD/No Power)	3856
ZTE	Blade L3	13	B Handset	3857
ZTE	Blade L3	17	B Handset (Power Up, Bad LCD/No Power)	3858
ZTE	Blade L5	1	N. New	3859
ZTE	Blade L5	1	B Handset	3860
ZTE	Blade L5 Plus	13	B Handset (Power Up, Bad LCD/No Power)	3861
ZTE	Blade Q Maxi	1	B Handset	3862
ZTE	Blade V220	1	B Handset	3863
ZTE	E8QP	12	B Handset	3864
ZTE	E8QP	10	B Handset (Power Up, Bad LCD/No Power)	3865
ZTE	F160	7	B Handset	3866
ZTE	KIS	3	B Handset	3867
ZTE	Kis Pro	1	B Handset	3868
ZTE	N295	10	B Handset	3869
ZTE	Open	2	B Handset	3870
ZTE	Open C2	5	B Handset	3871
ZTE	Open II	6	B Handset	3872
ZTE	P729	9	B Handset	3873
ZTE	P743	8	B Handset	3874
ZTE	R286	6	B Handset	3875
ZTE	R3100	1	B Handset	3876

Brand	Model	Total - QTY	Grade	Line
ZTE	V795	13	B Handset	3877
ZTE	V970	9	B Handset	3878
ZTE	Blade L6	4	B Handset	3879
ZTE	Grand S Flex	1	B Handset (Power Up, Bad LCD/No Power)	3882
ZTE	T83	5	B Handset (Power Up, Bad LCD/No Power)	3883
ZTE	R239	4	N. New Handset	3884
ZTE	S236	10	N. New Handset	3885
ZTE	Blade X3	2	B Handset (Power Up, Bad LCD/No Power)	3886
ZTE	Open C	1	B Handset	3888
ZTE	F286	1	B Handset	3889
ZTE	Z831	1	B Handset	3890
ZTE	Z899	1	B Handset	3891
ZTE	Blade Apex 2	1	B Handset	3892
ZTE	Blade L7	1	N. New	3893
ZTE	B2016	2	B Handset (Power Up, Bad LCD/No Power)	3895
Alcatel	LDN-L21	2	B Handset (Power Up, Bad LCD/No Power)	3897
Alcatel	OT2004	5	B Handset	3898
Alcatel	OT1016	1	New	3899
Alcatel	OT1016	1	N. New	3900
Alcatel	OT1016	3	14B	3901
Alcatel	OT1016	3	B Handset	3902
Alcatel	OT1016	1	B Handset (Power Up, Bad LCD/No Power)	3903
Alcatel	OT1030	7	B Handset	3904
Alcatel	OT1035	2	B Handset	3905
Alcatel	OT1052	1	B Handset	3906
Alcatel	OT1054	7	B Handset	3907
Alcatel	OT1066	8	N. New	3908
Alcatel	OT1066	3	B Handset	3909
Alcatel	OT1066	7	B Handset (Power Up, Bad LCD/No Power)	3910
Alcatel	OT2001	1	B Handset (Power Up, Bad LCD/No Power)	3911
Alcatel	OT2005	18	B Handset	3912
Alcatel	OT2010	19	B Handset	3913
Alcatel	OT2010	2	B Handset (Power Up, Bad LCD/No Power)	3914
Alcatel	OT2035	3	14B	3915
Alcatel	OT2035	2	N. New Handset	3916
Alcatel	OT2035	1	B Handset	3917
Alcatel	OT2035	5	B Handset (Power Up, Bad LCD/No Power)	3918
Alcatel	OT2038	1	N. New Handset	3919
Alcatel	OT2038	9	B Handset (Power Up, Bad LCD/No Power)	3920
Alcatel	OT2045	18	B Handset	3921
Alcatel	OT2050	1	B Handset	3922
Alcatel	OT2050	11	B Handset (Power Up, Bad LCD/No Power)	3923
Alcatel	OT2051	1	N. New	3924
Alcatel	OT2051	1	N. New Handset	3925
Alcatel	OT2051	2	B Handset	3926
Alcatel	OT2067	2	B Handset	3927
Alcatel	OT292	1	B Handset	3928
Alcatel	OT3003	3	B Handset	3929
Alcatel	OT3041	8	B Handset (Power Up, Bad LCD/No Power)	3930
Alcatel	OT4003	2	B Handset	3931
Alcatel	OT4009	3	N. New Handset	3932
Alcatel	OT4009	8	B Handset	3933
Alcatel	OT4009	1	B Handset (Power Up, Bad LCD/No Power)	3934
Alcatel	OT4010	1	B Handset	3935
Alcatel	OT4015	2	B Handset	3936
Alcatel	OT4015	8	B Handset (Power Up, Bad LCD/No Power)	3937
Alcatel	OT4017	8	B Handset (Power Up, Bad LCD/No Power)	3938
Alcatel	OT4018	9	14B	3939
Alcatel	OT4018	3	B Handset	3940
Alcatel	OT4018	10	B Handset (Power Up, Bad LCD/No Power)	3941
Alcatel	OT4019	1	B Handset	3942
Alcatel	OT4019	1	B Handset (Power Up, Bad LCD/No Power)	3943
Alcatel	OT4024	2	B Handset (Power Up, Bad LCD/No Power)	3944
Alcatel	OT4027	5	B Handset	3945
Alcatel	OT4027	3	B Handset (Power Up, Bad LCD/No Power)	3946
Alcatel	OT4030	13	B Handset	3947
Alcatel	OT4032	4	B Handset	3948
Alcatel	OT4033	2	14B	3949
Alcatel	OT4034	4	N. New Handset	3950
Alcatel	OT4034	9	B Handset (Power Up, Bad LCD/No Power)	3951
Alcatel	OT4035	4	B Handset	3952
Alcatel	OT4035	8	B Handset (Power Up, Bad LCD/No Power)	3953
Alcatel	OT4037	2	B Handset	3954
Alcatel	OT4044	6	B Handset	3955
Alcatel	OT5015	2	B Handset	3956
Alcatel	OT5015	1	B Handset (Power Up, Bad LCD/No Power)	3957
Alcatel	OT5017	6	B Handset	3958
Alcatel	OT5020	3	B Handset (Power Up, Bad LCD/No Power)	3959
Alcatel	OT5022	1	B Handset	3960
Alcatel	OT5022	5	B Handset (Power Up, Bad LCD/No Power)	3961
Alcatel	OT5038	2	B Handset (Power Up, Bad LCD/No Power)	3962
Alcatel	OT5044	1	14B	3963
Alcatel	OT5044	1	B Handset (Power Up, Bad LCD/No Power)	3965
Alcatel	OT5045	1	B Handset (Power Up, Good LCD)	3966
Alcatel	OT5045	6	B Handset	3967
Alcatel	OT5045	2	B Handset (Power Up, Bad LCD/No Power)	3968
Alcatel	OT5046	1	B Handset	3969
Alcatel	OT5046	6	B Handset (Power Up, Bad LCD/No Power)	3970
Alcatel	OT5050	12	B Handset	3971
Alcatel	OT5050	1	B Handset (Power Up, Bad LCD/No Power)	3972
Alcatel	OT5051	5	B Handset	3973
Alcatel	OT5051	6	B Handset (Power Up, Bad LCD/No Power)	3974
Alcatel	OT5065	1	B Handset	3975
Alcatel	OT5095	4	B Handset (Power Up, Bad LCD/No Power)	3976
Alcatel	OT6010	2	B Handset	3977
Alcatel	OT6010	2	B Handset (Power Up, Bad LCD/No Power)	3978
Alcatel	OT6012	5	B Handset (Power Up, Bad LCD/No Power)	3979
Alcatel	OT6016	6	B Handset (Power Up, Bad LCD/No Power)	3980
Alcatel	OT6030	5	B Handset	3981
Alcatel	OT6030	4	B Handset (Power Up, Bad LCD/No Power)	3982
Alcatel	OT6033	6	B Handset	3983
Alcatel	OT6033	1	B Handset (Power Up, Bad LCD/No Power)	3984
Alcatel	OT6034	4	B Handset (Power Up, Bad LCD/No Power)	3985
Alcatel	OT6036	2	B Handset (Power Up, Bad LCD/No Power)	3986
Alcatel	OT6039	2	B Handset	3987
Alcatel	OT6040	2	B Handset	3988
Alcatel	OT6040	4	B Handset (Power Up, Bad LCD/No Power)	3989
Alcatel	OT6045	5	B Handset	3990
Alcatel	OT6055	1	B Handset	3991
Alcatel	OT6055	7	B Handset (Power Up, Bad LCD/No Power)	3992
Alcatel	OT665	2	B Handset	3993
Alcatel	OT668	3	B Handset	3994
Alcatel	OT7041	3	B Handset	3995
Alcatel	OT7041	11	B Handset (Power Up, Bad LCD/No Power)	3996
Alcatel	OT799	1	B Handset	3997
Alcatel	OT8008	1	B Handset	3998
Alcatel	OT8055	2	B Handset	3999
Alcatel	OT8055	1	B Handset (Power Up, Bad LCD/No Power)	4000
Alcatel	OT8056	1	B Handset (Power Up, Bad LCD/No Power)	4001
Alcatel	OT8063	1	B Handset (Power Up, Bad LCD/No Power)	4002

Brand	Model	Total - QTY	Grade	Line
Alcatel	OT9001	4	B Handset	4003
Alcatel	OT9007	2	B Handset	4004
Alcatel	OT9007	1	B Handset (Power Up, Bad LCD/No Power)	4005
Alcatel	OT9022	1	B Handset	4006
Alcatel	OT983	1	B Handset	4007
Alcatel	OT991	6	B Handset	4008
Alcatel	OT993	6	B Handset	4009
Alcatel	OT995	4	14B	4010
Alcatel	OT996	2	B Handset (Power Up, Bad LCD/No Power)	4011
Alcatel	OT997	4	B Handset	4012
Alcatel	OT-1216	1	B Handset (Power Up, Bad LCD/No Power)	4013
Alcatel	OT-P320	1	B Handset	4014
Alcatel	OT5056	1	B Handset (Power Up, Bad LCD/No Power)	4016
Alcatel	OT4013	3	B Handset	4017
Alcatel	OT5010	8	B Handset	4018
Alcatel	OT602	1	B Handset (Power Up, Bad LCD/No Power)	4021
Alcatel	OT4047	3	14B	4023
Alcatel	OT7024	2	B Handset	4026
Alcatel	OT7047	3	B Handset	4027
Alcatel	OT7047	4	B Handset (Power Up, Bad LCD/No Power)	4028
Alcatel	OT7048	2	B Handset (Power Up, Bad LCD/No Power)	4029
Alcatel	OT6050	3	B Handset	4031
Alcatel	OT6050	2	B Handset (Power Up, Bad LCD/No Power)	4032
Alcatel	OT4049	1	B Handset	4033
Alcatel	OT9010	1	B Handset	4034
Alcatel	OT8079	2	B Handset (Power Up, Bad LCD/No Power)	4035
Alcatel	OT8070	1	B Handset (Power Up, Bad LCD/No Power)	4037
Acer	B3-A20	2	B Handset	4038
Acer	B3-A30	2	B Handset	4039
Acer	E380	3	B Handset	4040
Acer	E380	2	B Handset (Power Up, Bad LCD/No Power)	4041
Acer	M220	1	B Handset	4042
Acer	S500	1	B Handset	4043
Acer	S56	1	B Handset	4044
Acer	S56	1	B Handset (Power Up, Bad LCD/No Power)	4045
Acer	S57	4	B Handset	4046
Acer	S57	3	B Handset (Power Up, Bad LCD/No Power)	4047
Acer	T07	2	B Handset (Power Up, Bad LCD/No Power)	4048
Acer	T08	4	B Handset	4049
Acer	T08	9	B Handset (Power Up, Bad LCD/No Power)	4050
Acer	T09	12	B Handset	4051
Acer	T09	3	B Handset (Power Up, Bad LCD/No Power)	4052
Acer	V360	2	B Handset	4053
Acer	V370	1	B Handset	4054
Acer	V370	8	B Handset (Power Up, Bad LCD/No Power)	4055
Acer	Z220	4	B Handset	4056
Acer	Z220	7	B Handset (Power Up, Bad LCD/No Power)	4057
Acer	Z330	4	B Handset	4058
Acer	Z330	3	B Handset (Power Up, Bad LCD/No Power)	4059
Acer	Z500	3	B Handset	4060
Acer	Z520	5	B Handset (Power Up, Bad LCD/No Power)	4061
Acer	Z530	1	B Handset (Power Up, Bad LCD/No Power)	4062
Acer	Z630	5	B Handset	4063
Acer	A3-A10	2	B Handset	4064
Acer	S510	1	B Handset	4065
Acer	T02	1	B Handset (Power Up, Bad LCD/No Power)	4066
Acer	T06	3	B Handset	4067
Acer	T06	2	B Handset (Power Up, Bad LCD/No Power)	4068
Acer	E350	1	B Handset	4069
Acer	Z150	3	B Handset	4070
Acer	B1-A71	1	B Handset	4071
Acer	S55	1	B Handset	4072
Acer	S55	1	B Handset (Power Up, Bad LCD/No Power)	4073
Acer	T11	3	B Handset (Power Up, Bad LCD/No Power)	4074
Asus	DRA-L21	1	B Handset	4075
Asus	A007	1	B Handset (Power Up, Bad LCD/No Power)	4076
Asus	K011	1	B Handset	4077
Asus	Nexus 7	5	B Handset	4078
Asus	Z00ED	18	B Handset	4079
Asus	Z00LD	3	B Handset	4080
Asus	K00B	3	B Handset	4081
Asus	K004	1	B Handset	4082
Asus	K00E	2	B Handset	4083
Asus	K012	1	B Handset	4084
Asus	T100T	1	B Handset	4085
Asus	K013	2	B Handset	4086
Asus	K0W	1	B Handset	4087
Asus	K017	1	B Handset	4088
Asus	ASUS ZE500KL	4	B Handset (Power Up, Bad LCD/No Power)	4089
HP	HP Slate 7	1	B Handset	4090
SFR	SFR STARACTIVE	2	B Handset	4091
SFR	SFR STARADDICT 6	4	B Handset	4092
SFR	SFR STARADDICT II Plus	1	B Handset (Power Up, Bad LCD/No Power)	4093
SFR	SFR STARNAUTE III	2	B Handset	4094
SFR	SFR STARNAUTE IV	1	B Handset	4095
SFR	SFR STARTRAIL 6 4G	3	B Handset (Power Up, Bad LCD/No Power)	4096
SFR	SFR STARXTREM	2	B Handset (Power Up, Bad LCD/No Power)	4097
LCD	Apple iPhone 6	169	LCD (Grade A)	4098
LCD	Apple iPhone 6	154	LCD (Grade B)	4099
LCD	Ericsson D2303	9	LCD (Grade B)	4100
LCD	Ericsson D5803	89	LCD (Grade B)	4101
LCD	Ericsson D6603	168	LCD (Grade B)	4102
LCD	Ericsson E2303	76	LCD (Grade B)	4103
LCD	Ericsson E6653	62	LCD (Grade B)	4104
LCD	Ericsson F3111	8	LCD (Grade B)	4105
LCD	Ericsson F3311	62	LCD (Grade B)	4106
LCD	Ericsson F5121	19	LCD (Grade B)	4107
LCD	Ericsson G3121	2	LCD (Grade B)	4108
LCD	Ericsson G8341	1	LCD (Grade B)	4109
LCD	Ericsson LT36	25	LCD (Grade B)	4110
LCD	Ericsson ST26i	40	LCD (Grade B)	4111
LCD	Ericsson X12	35	LCD (Grade B)	4112
LCD	Motorola XT1072	5	LCD (Grade B)	4113
Other	Gini E6	17	LCD (Grade B)	4114
Other	Meizu Pro 6	21	LCD (Grade B)	4115
LCD	Alcatel OT6012	183	LCD (Power Up, Bad LCD)	4116
LCD	Apple iPhone 6	446	LCD (Power Up, Bad LCD)	4117
LCD	X00QD	3	LCD (Power Up, Bad LCD)	4118
LCD	Z00AD	1	LCD (Power Up, Bad LCD)	4119
LCD	Ericsson D2303	7	LCD (Power Up, Bad LCD)	4120
LCD	Ericsson D5803	14	LCD (Power Up, Bad LCD)	4121
LCD	Ericsson D6603	108	LCD (Power Up, Bad LCD)	4122
LCD	Ericsson E2303	92	LCD (Power Up, Bad LCD)	4123
LCD	Ericsson E6653	62	LCD (Power Up, Bad LCD)	4124
LCD	Ericsson F3111	51	LCD (Power Up, Bad LCD)	4125
LCD	Ericsson F3311	33	LCD (Power Up, Bad LCD)	4126
LCD	Ericsson F5121	27	LCD (Power Up, Bad LCD)	4127
LCD	Ericsson G3311	2	LCD (Power Up, Bad LCD)	4128
LCD	Ericsson LT36	7	LCD (Power Up, Bad LCD)	4129
LCD	Ericsson ST26i	7	LCD (Power Up, Bad LCD)	4130

Brand	Model	Total - QTY	Grade	Line
LCD	Ericsson X12	14	LCD (Power Up, Bad LCD)	4131
LCD	LG D855	454	LCD (Power Up, Bad LCD)	4132
LCD	LG H850	328	LCD (Power Up, Bad LCD)	4133
LCD	LG V700	20	LCD (Power Up, Bad LCD)	4134
LCD	Motorola XT1072	15	LCD (Power Up, Bad LCD)	4135
LCD	Other Lenovo S960	1	LCD (Power Up, Bad LCD)	4136
LCD	Other Xiaomi Mi 4	2	LCD (Power Up, Bad LCD)	4137
LCD	Other Xiaomi Redmi Note 4	7	LCD (Power Up, Bad LCD)	4138
LCD	Other Xiaomi Redmi Note 4G	1	LCD (Power Up, Bad LCD)	4139
LCD	Samsung A520	272	LCD (Power Up, Bad LCD)	4140
LCD	Samsung A720	331	LCD (Power Up, Bad LCD)	4141
LCD	Samsung G925F	684	LCD (Power Up, Bad LCD)	4142
LCD	Samsung J510F	2	LCD (Power Up, Bad LCD)	4143
LCD	Samsung J710F	3	LCD (Power Up, Bad LCD)	4144
LCD	Samsung N910F	4	LCD (Power Up, Bad LCD)	4145
LCD	Samsung N920	790	LCD (Power Up, Bad LCD)	4146
LCD	A2016	15	LCD (Power Up, Bad LCD)	4147
LCD	Blade S6	25	LCD (Power Up, Bad LCD)	4148
LCD	Blade VEC	7	LCD (Power Up, Bad LCD)	4149
Other	Gini E6	308	LCD (Power Up, Bad LCD)	4150
Other	Gini S4	1406	LCD (Power Up, Bad LCD)	4151
Other	Gini W5	1095	LCD (Power Up, Bad LCD)	4152
Other	Meizu M2	9	LCD (Power Up, Bad LCD)	4153
Other	Meizu M2 Note	5	LCD (Power Up, Bad LCD)	4154
Other	Meizu M3 Max	8	LCD (Power Up, Bad LCD)	4155
Other	Meizu M3 Note	68	LCD (Power Up, Bad LCD)	4156
Other	Meizu M3s	154	LCD (Power Up, Bad LCD)	4157
Other	Meizu M5	33	LCD (Power Up, Bad LCD)	4158
Other	Meizu M5 Note	18	LCD (Power Up, Bad LCD)	4159
Other	Meizu M5s	9	LCD (Power Up, Bad LCD)	4160
Other	Meizu MX5	23	LCD (Power Up, Bad LCD)	4161
Other	Meizu MX6	22	LCD (Power Up, Bad LCD)	4162
Other	Meizu U20	15	LCD (Power Up, Bad LCD)	4163
Other	Nubia Z11 Mini	4	LCD (Power Up, Bad LCD)	4164
Apple	iPad 2 Wi-Fi (16GB)	25	Main Board	4165
Apple	iPad 2 Wi-Fi (32GB)	6	Main Board	4166
Apple	iPad 2 Wi-Fi (64GB)	1	Main Board	4167
Apple	iPad 2 Wi-Fi 3G (16GB)	10	Main Board	4168
Apple	iPad 2 Wi-Fi 3G (32GB)	1	Main Board	4169
Apple	iPad 2 Wi-Fi 3G (64GB)	2	Main Board	4170
Apple	iPad 4 Wi-Fi (16GB)	5	Main Board	4171
Apple	iPad 4 Wi-Fi 4G (16GB)	3	Main Board	4172
Apple	iPad Air 2 Wi-Fi (16GB)	5	Main Board	4173
Apple	iPad Mini 2 Wi-Fi (16GB)	11	Main Board	4174
Apple	iPad Mini 2 Wi-Fi 4G (16GB)	1	Main Board	4175
Apple	iPad Mini 3 Wi-Fi 4G (16GB)	4	Main Board	4176
Apple	iPad Mini Wi-Fi (16GB)	47	Main Board	4177
Apple	iPad Mini Wi-Fi 4G (16GB)	8	Main Board	4178
Apple	iPad Pro Wi-Fi (32GB)	1	Main Board	4179
Apple	iPad Wi-Fi (16GB)	8	Main Board	4180
Apple	iPad Wi-Fi (64GB)	1	Main Board	4181
Apple	iPad Wi-Fi 3G (16GB)	1	Main Board	4182
Apple	iPhone 3G (16GB)	1	Main Board	4183
Apple	iPhone 3G (8GB)	19	Main Board	4184
Apple	iPhone 3GS (16GB)	14	Main Board	4185
Apple	iPhone 3GS (32GB)	1	Main Board	4186
Apple	iPhone 3GS (8GB)	4	Main Board	4187
Apple	iPhone 4 (16GB)	8	Main Board	4188
Apple	iPhone 4 (32GB)	7	Main Board	4189
Apple	iPhone 4 (32GB) (CDMA)	1	Main Board	4190
Apple	iPhone 4 (8GB)	568	Main Board	4191
Apple	iPhone 4s (16GB)	54	Main Board	4192
Apple	iPhone 4s (32GB)	1	Main Board	4193
Apple	iPhone 4s (8GB)	338	Main Board	4194
Apple	iPhone 5c (8GB)	1	Main Board	4195
Apple	iPhone 5s (16GB)	310	Main Board	4196
Apple	iPhone 5s (32GB)	2	Main Board	4197
Apple	iPhone 5s (64GB)	1	Main Board	4198
Apple	iPhone 6 (16GB) SIM Free	71	Main Board	4199
Apple	iPhone 6 Plus (16GB)	47	Main Board	4200
Apple	iPhone 6s (16GB)	57	Main Board	4201
Apple	iPhone 6s Plus (16GB)	24	Main Board	4202
Apple	iPhone 7 (32GB)	56	Main Board	4203
Apple	iPhone 7 (32GB) SIM Free	77	Main Board	4204
Apple	iPhone 7 Plus (32GB)	8	Main Board	4205
Apple	iPhone 7 Plus (32GB) SIM Free	54	Main Board	4206
Apple	iPhone 8 (64GB)	1	Main Board	4207
Apple	iPhone SE (16GB)	26	Main Board	4208
Apple	The New iPad Wi-Fi (16GB)	5	Main Board	4209
Apple	The New iPad Wi-Fi (32GB)	1	Main Board	4210
Apple	The New iPad Wi-Fi 4G (16GB)	3	Main Board	4211
Apple	The New iPad Wi-Fi 4G (64GB)	2	Main Board	4212
Samsung	A310F	14	Main Board	4213
Samsung	A510F	18	Main Board	4214
Samsung	B2710	1	Main Board	4215
Samsung	B5510	4	Main Board	4216
Samsung	B7330	1	Main Board	4217
Samsung	B7510	27	Main Board	4218
Samsung	C101	3	Main Board	4219
Samsung	C105	1	Main Board	4220
Samsung	C115	1	Main Board	4221
Samsung	C3050	3341	Main Board	4222
Samsung	C3300	3729	Main Board	4223
Samsung	C3520	22	Main Board	4224
Samsung	C3570	2	Main Board	4225
Samsung	C3595	4	Main Board	4226
Samsung	C5010	1	Main Board	4227
Samsung	C5130	4127	Main Board	4228
Samsung	E1050	1	Main Board	4229
Samsung	E1080	6	Main Board	4230
Samsung	E1150	3	Main Board	4231
Samsung	E1151	6	Main Board	4232
Samsung	E1200	9	Main Board	4233
Samsung	E1202	3	Main Board	4234
Samsung	E1230	1	Main Board	4235
Samsung	E1270	8	Main Board	4236
Samsung	E1272	7	Main Board	4237
Samsung	E1310	324	Main Board	4238
Samsung	E2120	1	Main Board	4239
Samsung	E2200	3	Main Board	4240
Samsung	E2370	33	Main Board	4241
Samsung	E2530	6	Main Board	4242
Samsung	E2550	5	Main Board	4243
Samsung	E2600	5	Main Board	4244
Samsung	E3300	148	Main Board	4245
Samsung	E500	2	Main Board	4246
Samsung	E500F	4	Main Board	4247
Samsung	E700F	4	Main Board	4248
Samsung	F210	1	Main Board	4249
Samsung	F480	103	Main Board	4250

Brand	Model	Total - QTY	Grade	Line
Samsung	G110	8	Main Board	4251
Samsung	G310	12	Main Board	4252
Samsung	G313	5	Main Board	4253
Samsung	G318	7	Main Board	4254
Samsung	G350	13	Main Board	4255
Samsung	G357F	1	Main Board	4256
Samsung	G360F	1	Main Board	4257
Samsung	G361F	1	Main Board	4258
Samsung	G386F	3	Main Board	4259
Samsung	G388F	1	Main Board	4260
Samsung	G390F	1	Main Board	4261
Samsung	G531F	4	Main Board	4262
Samsung	G570F	1	Main Board	4263
Samsung	G800F	4	Main Board	4264
Samsung	G850	1	Main Board	4265
Samsung	G850F	8	Main Board	4266
Samsung	G900	3	Main Board	4267
Samsung	G900 (Non-F Version)	56	Main Board	4268
Samsung	G901F	7	Main Board	4269
Samsung	G920	4	Main Board	4270
Samsung	G920 (Non-F Version)	29	Main Board	4271
Samsung	G925 (Demo)	1	Main Board	4273
Samsung	G928	2	Main Board	4274
Samsung	G928F	2	Main Board	4275
Samsung	G935f	1	Main Board	4277
Samsung	G955	1	Main Board	4278
Samsung	i337	1	Main Board	4279
Samsung	i605	11	Main Board	4280
Samsung	i747	1	Main Board	4281
Samsung	i8000	1	Main Board	4282
Samsung	i8160	32	Main Board	4283
Samsung	i8200	2	Main Board	4284
Samsung	i8260	1	Main Board	4285
Samsung	i8262	2	Main Board	4286
Samsung	i9000	6	Main Board	4287
Samsung	i9003	1	Main Board	4288
Samsung	i9070	8	Main Board	4289
Samsung	i9082	2	Main Board	4290
Samsung	i9100	20	Main Board	4291
Samsung	i9103	2	Main Board	4292
Samsung	i9190	1	Main Board	4293
Samsung	i9195	9	Main Board	4294
Samsung	i9220	1	Main Board	4295
Samsung	J100	1	Main Board	4298
Samsung	L700	2	Main Board	4300
Samsung	N5100	1	Main Board	4301
Samsung	N7000	9	Main Board	4302
Samsung	N7505	8	Main Board	4303
Samsung	N910 (Demo)	1	Main Board	4304
Samsung	P1000	2	Main Board	4305
Samsung	P5100	1	Main Board	4306
Samsung	P7300	1	Main Board	4307
Samsung	R530	2	Main Board	4308
Samsung	S3370	1077	Main Board	4309
Samsung	S3572	14	Main Board	4310
Samsung	S3650	5	Main Board	4311
Samsung	S5220	1	Main Board	4312
Samsung	S5230	6	Main Board	4313
Samsung	S5260	7	Main Board	4314
Samsung	S5282	2	Main Board	4315
Samsung	S5300	9	Main Board	4316
Samsung	S5310	2	Main Board	4317
Samsung	S5360	51	Main Board	4318
Samsung	S5360T	49	Main Board	4319
Samsung	S5380	17	Main Board	4320
Samsung	S5510	1255	Main Board	4321
Samsung	S5570	352	Main Board	4322
Samsung	S5600	1092	Main Board	4323
Samsung	S5610	4	Main Board	4324
Samsung	S5620	2779	Main Board	4325
Samsung	S5660	154	Main Board	4326
Samsung	S5690	2	Main Board	4327
Samsung	S5830	136	Main Board	4328
Samsung	S6790	10	Main Board	4329
Samsung	S6802	6	Main Board	4330
Samsung	S6810	2	Main Board	4331
Samsung	S6812	1	Main Board	4332
Samsung	S7230	155	Main Board	4333
Samsung	S7250	6	Main Board	4334
Samsung	S7500	6	Main Board	4335
Samsung	S8000	138	Main Board	4336
Samsung	S8300	2006	Main Board	4337
Samsung	S8600	12	Main Board	4338
Samsung	T210	10	Main Board	4339
Samsung	T230	1	Main Board	4340
Samsung	T520	1	Main Board	4341
Samsung	T805	1	Main Board	4342
Samsung	T999	2	Main Board	4343
Acer	E310	1	Main Board	4344
Alcatel	OT2045	21	Main Board	4345
Alcatel	OT2067	1	Main Board	4346
Alcatel	OT5020	6	Main Board	4347
Alcatel	OT5036	1	Main Board	4348
Alcatel	OT6010	2	Main Board	4349
Alcatel	OT6012	3	Main Board	4350
Alcatel	OT6033	1	Main Board	4351
Alcatel	OT7041	1	Main Board	4352
Alcatel	OT8008	2	Main Board	4353
Alcatel	OT8010	1	Main Board	4354
Alcatel	OT8020	1	Main Board	4355
Alcatel	OT918	171	Main Board	4356
Alcatel	OT991	5	Main Board	4357
Alcatel	OT992	1	Main Board	4358
Alcatel	OT995	2	Main Board	4359
Alcatel	OT997	4	Main Board	4360
BlackBerry	BB8520	73	Main Board	4361
BlackBerry	BB9300	209	Main Board	4362
BlackBerry	BB9320	11	Main Board	4363
BlackBerry	BB9360	4	Main Board	4364
BlackBerry	BB9700	115	Main Board	4365
BlackBerry	BB9720	2	Main Board	4366
BlackBerry	BB9780	40	Main Board	4367
BlackBerry	BB9780 (Non-qwerty)	23	Main Board	4368
BlackBerry	BB9800	2	Main Board	4369
BlackBerry	BB9860	1	Main Board	4370
BlackBerry	BB9900	6	Main Board	4371
BlackBerry	Z3	1	Main Board	4372
Ericsson	C510	1466	Main Board	4373
Ericsson	C5303	1	Main Board	4374
Ericsson	C5503	1	Main Board	4375

Brand	Model	Total - QTY	Grade	Line
Ericsson	C6903	1	Main Board	4376
Ericsson	C702	1	Main Board	4377
Ericsson	C902	75	Main Board	4378
Ericsson	CK15i	1	Main Board	4379
Ericsson	D2005	1	Main Board	4380
Ericsson	D2403	1	Main Board	4381
Ericsson	F100	19	Main Board	4382
Ericsson	F5321	1	Main Board	4383
Ericsson	J105	3149	Main Board	4384
Ericsson	J108	1667	Main Board	4385
Ericsson	K530	506	Main Board	4386
Ericsson	K800	27	Main Board	4387
Ericsson	LT18i	1	Main Board	4388
Ericsson	LT26W	1	Main Board	4389
Ericsson	LT30P	1	Main Board	4390
Ericsson	MK16i	10	Main Board	4391
Ericsson	MT15i	2	Main Board	4392
Ericsson	R800	16	Main Board	4393
Ericsson	SK17i	12	Main Board	4394
Ericsson	ST17i	1	Main Board	4395
Ericsson	ST23i	2	Main Board	4396
Ericsson	T650	89	Main Board	4397
Ericsson	T700	1	Main Board	4398
Ericsson	U100i	1375	Main Board	4399
Ericsson	U10i	42	Main Board	4400
Ericsson	W20i	1158	Main Board	4401
Ericsson	W508	18	Main Board	4402
Ericsson	W580	1	Main Board	4403
Ericsson	W595	1992	Main Board	4404
Ericsson	W705	1498	Main Board	4405
Ericsson	W715	5	Main Board	4406
Ericsson	W910	4	Main Board	4407
Ericsson	W980	456	Main Board	4408
Ericsson	W995	2775	Main Board	4409
Ericsson	X10 Mini	14	Main Board	4410
HTC	7 Mozart	1	Main Board	4411
HTC	7 Trophy	1	Main Board	4412
HTC	8S	5	Main Board	4413
HTC	8X	1	Main Board	4414
HTC	Chacha	2	Main Board	4415
HTC	Desire	1	Main Board	4416
HTC	Desire 510	1	Main Board	4417
HTC	Desire 601	1	Main Board	4418
HTC	Desire 610	2	Main Board	4419
HTC	Desire 620	1	Main Board	4420
HTC	Desire 820	3	Main Board	4421
HTC	Desire C	1	Main Board	4422
HTC	Desire Eye	2	Main Board	4423
HTC	Desire HD	7	Main Board	4424
HTC	Desire S	58	Main Board	4425
HTC	Desire X	9	Main Board	4426
HTC	Explorer	1	Main Board	4427
HTC	Incredible S	6	Main Board	4428
HTC	One	5	Main Board	4429
HTC	One E9	1	Main Board	4430
HTC	One SV	1	Main Board	4431
HTC	One V	3	Main Board	4432
HTC	One X	2	Main Board	4433
HTC	One X+	1	Main Board	4434
HTC	Rhyme	2	Main Board	4435
HTC	Sensation	7	Main Board	4436
HTC	Sensation XL	3	Main Board	4437
HTC	Wildfire	1	Main Board	4438
HTC	Wildfire S	1	Main Board	4439
Huawei	G630	3	Main Board	4440
Huawei	P9	1	Main Board	4441
Huawei	U8110	1155	Main Board	4442
Huawei	U8833	8	Main Board	4443
Huawei	Y530	1	Main Board	4444
LG	D290	2	Main Board	4445
LG	D722	1	Main Board	4446
LG	D802	1	Main Board	4447
LG	D855	4	Main Board	4448
LG	E400	110	Main Board	4449
LG	E425	1	Main Board	4450
LG	E610	1	Main Board	4451
LG	E900	1	Main Board	4452
LG	G350	1	Main Board	4453
LG	H791	1	Main Board	4454
LG	H840	1	Main Board	4455
LG	H850	1	Main Board	4456
LG	H960	2	Main Board	4457
LG	K120	1	Main Board	4458
LG	K350n	2	Main Board	4459
LG	K420n	1	Main Board	4460
LG	KP500	25	Main Board	4461
LG	KP501	2	Main Board	4462
LG	KP505	1	Main Board	4463
LG	LS970 (CDMA)	1	Main Board	4464
LG	P500	443	Main Board	4465
LG	P700	9	Main Board	4466
LG	P705	1	Main Board	4467
LG	P710	1	Main Board	4468
LG	P769	1	Main Board	4469
LG	P920	13	Main Board	4470
LG	P970	4	Main Board	4471
Motorola	M8511	1	Main Board	4472
Motorola	M8525	1573	Main Board	4473
Motorola	M8526	1019	Main Board	4474
Motorola	M8860	75	Main Board	4475
Motorola	V8	1	Main Board	4476
Motorola	V9	32	Main Board	4477
Motorola	XT1022	1	Main Board	4478
Motorola	XT1542	2	Main Board	4479
Nokia	203	602	Main Board	4480
Nokia	208	224	Main Board	4481
Nokia	225	1	Main Board	4482
Nokia	306	266	Main Board	4483
Nokia	435	2	Main Board	4484
Nokia	500	4	Main Board	4485
Nokia	505	9	Main Board	4486
Nokia	520	3	Main Board	4487
Nokia	535	1	Main Board	4488
Nokia	625	9	Main Board	4489
Nokia	640	1	Main Board	4490
Nokia	710	1	Main Board	4491
Nokia	720	1	Main Board	4492
Nokia	820	1	Main Board	4493
Nokia	1020	2	Main Board	4494
Nokia	1208	346	Main Board	4495

Brand	Model	Total - QTY	Grade	Line
Nokia	1661	3	Main Board	4496
Nokia	2610	201	Main Board	4497
Nokia	2760	1	Main Board	4498
Nokia	3100	6	Main Board	4499
Nokia	5220	15	Main Board	4500
Nokia	5228	110	Main Board	4501
Nokia	5230	33	Main Board	4502
Nokia	5310	8	Main Board	4503
Nokia	5610	14	Main Board	4504
Nokia	5700	29	Main Board	4505
Nokia	5800	113	Main Board	4506
Nokia	6070	222	Main Board	4507
Nokia	6085	79	Main Board	4508
Nokia	6131	33	Main Board	4509
Nokia	6267	705	Main Board	4510
Nokia	6288	1867	Main Board	4511
Nokia	6300	16	Main Board	4512
Nokia	2323C	307	Main Board	4513
Nokia	2330C	601	Main Board	4514
Nokia	2600C	2929	Main Board	4515
Nokia	2700C	5	Main Board	4516
Nokia	2720A	1527	Main Board	4517
Nokia	2730C	20	Main Board	4518
Nokia	3109C	5	Main Board	4519
Nokia	3110C	13	Main Board	4520
Nokia	3120C	49	Main Board	4521
Nokia	3610A	276	Main Board	4522
Nokia	3710a	5585	Main Board	4523
Nokia	3720C	23	Main Board	4524
Nokia	5130C	2	Main Board	4525
Nokia	5630C	408	Main Board	4526
Nokia	6120C	117	Main Board	4527
Nokia	6124C	1	Main Board	4528
Nokia	6210S	85	Main Board	4529
Nokia	6303C	5	Main Board	4530
Nokia	640XL	1	Main Board	4531
Nokia	6500C	24	Main Board	4532
Nokia	6500S	966	Main Board	4533
Nokia	6600S	42	Main Board	4534
Nokia	6700s	834	Main Board	4535
Nokia	6730C	525	Main Board	4536
Nokia	6760s	2	Main Board	4537
Nokia	6788I	8	Main Board	4538
Nokia	7210S	352	Main Board	4539
Nokia	7230S	2516	Main Board	4540
Nokia	C2-01	2	Main Board	4541
Nokia	C2-02	96	Main Board	4542
Nokia	C3-01	1	Main Board	4543
Nokia	C5	7	Main Board	4544
Nokia	C5-01	7	Main Board	4545
Nokia	C5-03	489	Main Board	4546
Nokia	C5-06	164	Main Board	4547
Nokia	C6	50	Main Board	4548
Nokia	C6-01	7	Main Board	4549
Nokia	E5	52	Main Board	4550
Nokia	E52	3	Main Board	4551
Nokia	E55	12	Main Board	4552
Nokia	E61-1	35	Main Board	4553
Nokia	E61i	1	Main Board	4554
Nokia	E63	24	Main Board	4555
Nokia	E65	331	Main Board	4556
Nokia	E66	11	Main Board	4557
Nokia	E7	1	Main Board	4558
Nokia	E71-1	158	Main Board	4559
Nokia	E72	2	Main Board	4560
Nokia	N70	5	Main Board	4561
Nokia	N73	16	Main Board	4562
Nokia	N78	11	Main Board	4563
Nokia	N79	3	Main Board	4564
Nokia	N81	5	Main Board	4565
Nokia	N81 (8GB)	2	Main Board	4566
Nokia	N82	8	Main Board	4567
Nokia	N85	3746	Main Board	4568
Nokia	N95	16	Main Board	4569
Nokia	N95-2	3	Main Board	4570
Nokia	N96	13	Main Board	4571
Nokia	XL	1	Main Board	4572
Nokia	X3	548	Main Board	4573
Nokia	X3-02	144	Main Board	4574
Nokia	X5-01	11	Main Board	4575
Nokia	X7	4	Main Board	4576
Other	Amazon Kindle Fire 7	1	Main Board	4577
Other	Archos 50	3	Main Board	4578
Other	Xiaomi Redmi Note 4G	1	Main Board	4579
SFR	SFR STARADDICT II	1	Main Board	4580
SFR	SFR STARSHINE	1	Main Board	4581
ZTE	Blade VEC 4G	9	Main Board	4582
ZTE	P729	2	Main Board	4583
Samsung	C300	36	Main Board-New	4584
Samsung	C450	12	Main Board-New	4585
Samsung	E250	7	Main Board-New	4586
Samsung	i607	7	Main Board-New	4587
Samsung	i900	30	Main Board-New	4588
Samsung	X160	7	Main Board-New	4589
Samsung	X200	7	Main Board-New	4590
Samsung	X510	8	Main Board-New	4591
Samsung	X820	7	Main Board-New	4592
Samsung	Z230	7	Main Board-New	4593
Samsung	Z240	20	Main Board-New	4594
Samsung	Z370	37	Main Board-New	4595
Samsung	Z500	30	Main Board-New	4596
Samsung	Z720	6	Main Board-New	4597
BlackBerry	BB7290	3	Main Board-New	4598
BlackBerry	BB8310	10	Main Board-New	4599
BlackBerry	BB8707	9	Main Board-New	4600
BlackBerry	BB8900	70	Main Board-New	4601
Ericsson	C702	7	Main Board-New	4602
Ericsson	C902	8	Main Board-New	4603
Ericsson	G502	50	Main Board-New	4604
Ericsson	K510	20	Main Board-New	4605
Ericsson	K530	30	Main Board-New	4606
Ericsson	K610	7	Main Board-New	4607
Ericsson	K660	7	Main Board-New	4608
Ericsson	K800	8	Main Board-New	4609
Ericsson	R306	100	Main Board-New	4610
Ericsson	W800	2	Main Board-New	4611
Ericsson	W880	5	Main Board-New	4612
HTC	Diamond	20	Main Board-New	4613
Huawei	U8330	4	Main Board-New	4614
LG	KU990	18	Main Board-New	4615

Brand	Model	Total - QTY	Grade	Line
MDA	MDA Vario II	6	Main Board-New	4616
Motorola	C168	20	Main Board-New	4617
Motorola	C390	15	Main Board-New	4618
Motorola	K3	60	Main Board-New	4619
Motorola	W220	30	Main Board-New	4620
Nokia	2610	13	Main Board-New	4621
Nokia	5700	25	Main Board-New	4622
Nokia	6101	3	Main Board-New	4623
Nokia	6288	100	Main Board-New	4624
Nokia	2323C	41	Main Board-New	4625
Nokia	2680S	2658	Main Board-New	4626
Nokia	6730C	13	Main Board-New	4627
Nokia	6760s	1087	Main Board-New	4628
Nokia	7100S	2	Main Board-New	4629
Nokia	C6	139	Main Board-New	4630
Nokia	C6-01	17	Main Board-New	4631
Nokia	N73	9	Main Board-New	4632
Nokia	N76	14	Main Board-New	4633
ACC	Mixed Home Telephone (Handset)	4	Accessories	4634
LCD	Apple iPhone 5c	80	Accessories	4635
LCD	Apple iPhone 5s	575	Accessories	4636
LCD	Apple iPhone 6 Plus (Non-original)	171	Accessories	4637
LCD	Apple iPhone 6 (Non-original)	786	Accessories	4638
Other	Blue Ant Supertooth Bluetooth Handsfree	2	Accessories	4639
Other	Butterfly High Quality Speaker	3	Accessories	4640
Other	Color Block On-ear Headphone	19	Accessories	4641
Other	DT150 (in box)	14	Accessories	4642
Other	Epson Printer	8	Accessories	4643
Other	ETS 3 (in box)	5	Accessories	4644
Other	K1 (in box)	51	Accessories	4645
Other	LG W100	2	Accessories	4646
Other	LG W110	7	Accessories	4647
Other	Logitech Clock Radio Dock S400I	1	Accessories	4648
Other	Moto 360	3	Accessories	4649
Other	Moto Carretera ASMTK30	6	Accessories	4650
Other	NEO1100 (in box)	4	Accessories	4651
Other	NEO3750 (in box)	10	Accessories	4652
Other	Loopset LPS-S	64	Accessories	4653
Other	Nokia Digital Photo Frame SU-4	1	Accessories	4654
Other	O2 Jogger	1	Accessories	4655
Other	OXX Digital Subscription Free Internet Radio	1	Accessories	4656
Other	Plantronic HW 111N Earphone	4	Accessories	4657
Other	POP Phone Earphone (in box)	102	Accessories	4658
Other	PSP	4	Accessories	4659
Other	Rodak Digital Photo Frame	1	Accessories	4660
Other	Samsung DVD Writer	1	Accessories	4661
Other	Samsung External DVD Writer SE-S184	1	Accessories	4662
Other	Smart Watch	3	Accessories	4663
Other	Sony MN 2	2	Accessories	4664
Other	Sony MN800	3	Accessories	4665
Other	Sony RD-0140	2	Accessories	4666
Other	Sony SW 2	12	Accessories	4667
Other	Sony SW2	14	Accessories	4668
Other	Sony SWR 10	214	Accessories	4669
Other	Sony SWR 30	7	Accessories	4670
Other	Sony SWR 50	6	Accessories	4671
Other	Sony Speaker	76	Accessories	4672
Other	Supertooth Bluetooth Stereo Speaker	1	Accessories	4673
Other	VF Visor Kit	83	Accessories	4674
Other	Charger 2200mAh	2	Accessories	4675
Other	Charger 2500mAh	1	Accessories	4676
Other	Charger 3000mAh	9	Accessories	4677
Other	Bluetooth Car Kit	19	Accessories	4678
Other	Bluetooth Car KitSpeaker (Handset)	11	Accessories	4679
Other	Speaker P610	19	Accessories	4680
Other	Set Top Box	25	Accessories	4681
Other	BlueTooth Earphone CS540	10	Accessories	4682
Other	BlueTooth Earphone SAVI 440	9	Accessories	4683
Other	BlueTooth Earphone (Handset)	200	Accessories	4684
Other	BlueTooth Earphone BH-200	440	Accessories	4685
Other	BlueTooth Earphone BTH-10	449	Accessories	4686
Other	Mixed GPS	51	Accessories	4687
Other	Mixed Watch	121	Accessories	4688
Other	Mixed Earphone	40	Accessories	4689
Other	Mixed Speaker	18	Accessories	4690
Other	Mixed BlueTooth	34	Accessories	4691
Other	Mixed Earphone Box	4	Accessories	4692